

Operating Manual

**pMDDL2350
pMDDL2450
pMDDL2550**

2x2 MIMO OEM Wireless Digital Data Link

**Document: pMDDL.Operating Manual.v1.2.1.pdf
FW: v1.4.0 Build 1005**



150 Country Hills Landing NW
Calgary, Alberta
Canada T3K 5P3

Phone: (403) 248-0028
Toll Free: 1-855-353-0028
www.microhardcorp.com

3

Important User Information (continued)

Regulatory Requirements / Exigences Réglementaires



WARNING:

To satisfy FCC RF exposure requirements for mobile transmitting devices, a separation distance of 23 cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended. The antenna used for this transmitter must not be co-located in conjunction with any other antenna or transmitter.



WARNING:

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.



WARNING:

Changes or modifications not expressly approved by Microhard Systems Inc. could void the user's authority to operate the equipment. This device has been tested with UFL to Reverse Polarity SMA connectors with the antennas listed in Appendix A. When integrated in OEM products, fixed antennas require installation preventing end-users from replacing them with non-approved antennas. Antennas not listed in the tables must be tested to comply with FCC Section 15.203 (unique antenna connectors) and Section 15.247 (emissions).



WARNING:

MAXIMUM EIRP

FCC Regulations allow up to 36 dBm equivalent isotropically radiated power (EIRP). Therefore, the sum of the transmitted power (in dBm), the cabling loss and the antenna gain cannot exceed 36 dBm.



WARNING:

EQUIPMENT LABELING

The FCC and IC numbers depend on the model of the radio module. Do NOT use the Marketing Name of the product but the Model to distinguish the Certifications Numbers. This device has been modularly approved. The manufacturer, product name, and FCC and Industry Canada identifiers of this product must appear on the outside label of the end-user equipment.



WARNING:

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

(1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

SAMPLE LABEL REQUIREMENT / EXIGENCE D'ÉTIQUETTE:

pMDDL2450:

FCCID: NS918PMDDL2450
IC: 3143A-18PMDDL2450

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

Applicable Regulatory Approvals

Model	FCC	Industry Canada
pMDDL2450	NS918PMDDL2450	3143A-18PMDDL2450
pMDDL2350	Not Applicable	Not Applicable
pMDDL2550	Not Applicable	Not Applicable

Please Note: These are only sample labels; different products contain different identifiers. The actual identifiers should be seen on your devices if applicable.

Important User Information (continued)

Regulatory Requirements / Exigences Réglementaires



WARNING:

Pour satisfaire aux exigences de la FCC d'exposition RF pour la base et mobiles sur une distance de séparation de 23 cm ou plus doit être maintenue entre l'antenne de cet appareil et des personnes lors de fonctionnement du dispositif. Pour assurer la conformité des opérations au plus près que cette distance n'est pas recommandée. L'antenne utilisée pour ce transmetteur ne doit pas être co-localisés en conjonction avec toute autre antenne ou transmetteur.



WARNING:

Son fonctionnement est soumis aux deux conditions suivantes : (1) ce dispositif ne doit pas causer d'interférences nuisibles et (2) cet appareil doit accepter toute interférence reçue, incluant les interférences qui peuvent provoquer un fonctionnement indésirable .



WARNING:

Les changements ou modifications non expressément approuvés par Microhard Systems Inc. pourraient annuler l'autorité de l'utilisateur à utiliser l'équipement . Ce dispositif a été testé avec MCX et connecteurs SMA à polarité inverse sur les antennes répertoriées à l'annexe A Lorsqu'il est intégré dans les produits OEM , antennes fixes nécessitent une installation empêchant les utilisateurs finaux de les remplacer par des antennes non approuvées . Antennes ne figurant pas dans les tableaux doivent être testés pour se conformer à la Section 15.203 (connecteurs d'antenne uniques) et à la Section 15.247 (émissions) .



WARNING:

MAXIMUM EIRP

Règlement FCC permettent jusqu'à 36 dBm puissance isotrope rayonnée équivalente (EIRP) . Par conséquent, la somme de la puissance émise (en dBm), la perte de câblage et le gain d'antenne ne peut pas dépasser 36 dBm.



WARNING:

ÉQUIPEMENT DE MARQUAGE

Les numéros FCC et IC dépendent du modèle du module radio . Ne pas utiliser le nom marketing du produit, mais le modèle de distinguer les numéros Certifications . Ce dispositif a été approuvé de façon modulaire . Le fabricant , nom du produit, et les identificateurs de la FCC et d'Industrie Canada de ce produit doivent figurer sur l'étiquette à l'extérieur de l'équipement de l'utilisateur final .



WARNING:

Cet appareil est conforme aux CNR exempts de licence d'Industrie Canada . Son fonctionnement est soumis aux deux conditions suivantes : (1) Ce dispositif ne peut causer des interférences ; et (2) Ce dispositif doit accepter toute interférence , y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

SAMPLE LABEL REQUIREMENT / EXIGENCE D'ÉTIQUETTE:

pMDDL2450:

FCCID: Pending
IC: Pending

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference,
and (2) this device must accept any interference received including interference that may cause undesired operation.

Approbations Réglementaires Applicables

Type	FCC	Industrie Canada
pMDDL2450	En Attendant	En Attendant
pMDDL2350	Non Utilisé	Non Utilisé
pMDDL2550	Non Utilisé	Non Utilisé

Please Note: S'il vous plaît noter: Ce sont des exemples d'étiquettes seulement; différents produits contiennent des identifiants différents. Les identifiants réels devrait être vu sur vos périphériques le cas échéant.

Revision History

[illegible]

Table of Contents

1.0 Overview	10
1.1 Performance Features	10
1.2 Specifications	11
1.3 pMDDL Performance	13
2.0 QUICK START.....	14
2.1 Getting Started	14
2.2 Simple Master and Slave (Auto - Using Defaults).....	16
2.3 Simple Master and Slave (Manual).....	17
2.3.1 Configuring the Master	17
2.3.2 Configuring the Slave /Remote	19
2.3.3 Testing the Connection	21
3.0 Hardware Features	22
3.1 pMDDL OEM	22
3.1.1 Mechanical Drawings	23
3.1.2 Recommended Solder Mask (Pad Landing)	24
3.1.3 Recommended Solder Paste Pattern	25
3.1.4 OEM Connectors	25
3.1.5 SMT Temperature Profile	26
3.1.6 SMT Baking Instructions (MSL).....	26
3.1.7 Heat Dissipation	27
3.1.8 OEM Pin Descriptions	28
3.1.9 USB Device Mode	30
3.2 pMDDL Enclosed	31
3.2.1 Mechanical Drawings	32
3.2.2 Connectors & Indicators	33
3.3 pMDDL Development Board	36
3.3.1 Mechanical Drawings	37
3.3.2 Connectors & Indicators	38
4.0 Configuration.....	40
4.0 Web User Interface.....	40
4.0.1 Logon Window	41
4.1 System.....	42
4.1.1 Summary	42
4.1.2 Settings.....	43
Host Name.....	43
Date/Time	44
4.1.3 Services	46
SSH	46
Telnet.....	46
HTTP/HTTPS	46
4.1.4 Maintenance	47
Firmware Upgrade.....	47
Backup & Restore Configurations	48
4.1.5 Reboot.....	49

Table of Contents

4.2 Network	50
4.2.1 Status	50
4.2.2 LAN	51
LAN DHCP	53
4.2.3 WAN	55
4.2.4 USB	57
4.2.5 DHCP (MAC Binding)	58
4.2.6 Routes	59
4.2.7 Ports	61
4.2.8 Device List	62
4.3 Wireless	63
4.3.1 Status	63
4.3.2 Radio1	64
Radio On/Off	64
Channel Bandwidth	65
Radio Channel (Frequency)	65
TX Power	65
MIMO On/Off	65
Operating Mode	66
TX Rate	66
Network ID	67
Encryption	67
4.4 Firewall	68
4.4.1 Summary	68
4.4.2 General	69
4.4.3 Port Forwarding	70
4.4.4 MAC-IP List	72
4.4.5 Rules	74
4.4.4 Default	76
4.5 Serial	77
4.5.1 Summary	77
4.5.2 RS232 Port Settings	78
Data Baud Rate	79
IP Protocol Config	81
TCP Client	81
TCP Server	81
TCP Client/Server	82
UDP Point-to-Point	82
PPP	83
4.5.3 GS0 (USB - Device Mode)	84
4.6 Diag	85
4.6.1 Ping	85
4.6.2 Traceroute	85
4.6.3 Iperf	86
4.6.4 USB Tethering	87
4.7 Admin	88
4.7.1 Users	88
4.7.2 SNMP	90
4.7.3 Discovery	95
4.7.4 Logout	96

5.0 AT Command Line Interface	97
5.1 AT Command Overview	97
5.1.1 Telnet (TCP/IP)	97
5.2 AT Command Syntax	98
5.3 Supported AT Commands	99
 6.0 Installation	 110
6.1 Path Calculation	112
6.2 Installation of Antenna System Components	113
6.2.1 Antennas	113
6.2.2 Antenna Selection, Placement & Orientation	114
6.2.3 Coaxial Cable	115
6.2.4 Surge Arrestors	115
6.2.5 External Filter	115
 Appendices	 116
Appendix A: Serial Interface	116
Appendix B: Firmware Recovery	117
Appendix C: Sample Interface Schematic	118
Appendix D: Serial Port Extension	119
Appendix E: Troubleshooting/FAQ	120

1.0 Overview

The pMDDL is a feature rich, high power, 2x2 MIMO Wireless OEM Digital Data Link. The pMDDL is designed to provide high performance wireless capabilities in a compact and rugged OEM module for system integration. The pMDDL features simultaneous dual 10/100 Ethernet & Serial (RS232) Gateway capabilities for high speed wireless applications

The pMDDL can be configured using a built-in WebUI interface which does not require any additional software or tools to setup or download. The unit can operate as a Master, Slave or Relay (future) to establish robust long range wireless links between locations.

Providing reliable wireless Ethernet bridge functionality as well gateway service for most equipment types which employ an RS232 interface, the pMDDL can be used in various types of applications such as:

- High-speed backbone
- IP video surveillance
- Voice over IP (VoIP)
- Ethernet wireless extension
- UAV/UAS
- Legacy network/device migration
- SCADA
- Remote Telemetry
- Multicast Video

1.1 Performance Features

Key performance features of the pMDDL include:

- Adjustable, High Power Tx (up to 1W Total) w/ Excellent Rx Sensitivity
- Up to 25 Mbps data rate*
- Master, Slave/Remote, Relay (future) operating modes
- Point to Point, Point to Multipoint topology support
- Firewall with ACL Security, Port Forwarding
- Serial Gateway (RS232)
- Dual 10/100 Ethernet Ports
- RSSI LED pins for Antenna Alignments
- Industrial grade operating temperature (-40°C to +85°C)
- Administration via local console, telnet, web browser, SNMP
- Local and remote wireless firmware upgradable

* See Section 1.3 Performance Specifications

1.0 Overview

1.2 Specifications

For detailed specifications, please see the specification sheets available on the Microhard website @ <http://www.microhardcorp.com> for your specific model.

Electrical/General

Frequency:	pMDDL2350: 2.304 - 2.390 GHz pMDDL2450: 2.402 - 2.482 GHz pMDDL2550: 2.500 - 2.570 GHz
Link Rate:	See Section 1.3 Performance Specifications
TX Power:	20 dBm - 30 dBm Total (Adjustable)
Channel Bandwidth:	4, 8 MHz (Selectable)
Error Detection/Control:	CRC, ARQ
Data Encryption*: <i>(*Requires Export Permit)</i>	128-bit AES (Optional 256-bit)
Serial Port:	300bps to 921kbps - TTL Level RS232
Ethernet:	Dual 10/100 BaseT, Auto - MDI/X, IEEE 802.3
USB:	2.0
Network Protocols:	TCP, UDP, TCP/IP, ARP, ICMP, DHCP, HTTP, HTTPS*, SSH*, SNMP, FTP, DNS, Serial over IP (*May require an export permit)
Operating Modes:	Master, Slave/Remote, Relay (Future)
Management:	Local Serial Console, Telnet, WebUI, SNMP, FTP & Wireless Upgrade
Diagnostics:	Status LED's, RSSI, remote diagnostics, SNR
Input Voltage:	OEM: Digital Voltage: 3.3 VDC (500mA) RF Voltage: 5.0 VDC (1.5A) Enclosed: 7 - 30 VDC

Current:

	MIMO ON			MIMO OFF	
	Tx Power (dBm)	Vcc @ 3.3V	VRF @ 5V	Vcc @ 3.3V	VRF @ 5V
Peak Avg. Transmit Current (mA)	20	400 - 460	640	400 - 460	340
	22	400 - 460	720	400 - 460	390
	24	400 - 460	780	400 - 460	450
	26	400 - 460	860	400 - 460	520
	28	400 - 460	1000	400 - 460	620
	30	400 - 460	1200	400 - 460	790
Instantaneous Current Draw	-	500	1500	500	1000
Typical Receive Current Draw (mA)	-	400 - 460	-	400 - 460	-

Table 1-1: pMDDL Current Consumption

1.0 Overview

Environmental

Operation Temperature: -40°F(-40°C) to 185°F(85°C)

Humidity: 5% to 95% non-condensing

Mechanical

Dimensions: OEM: 1.05" (26.5mm) X 1.3" (33mm) X 0.13" (3.5mm)
ENC: 3.05" (77mm) X 2.2" (55mm) X 1.1" (28mm)

Weight: OEM: Approx. 7 grams
ENC: Approx. 170 grams

Connectors: OEM: Antenna: UFL x2 (ANT1, ANT2)
Data: 80 Pin SMT
ENC: RP-SMA Female x3
Data: RJ-45 x2 (Ethernet)
Female DB9 (Serial)
USB Type A
Micro-AB USB (Console)
4 PIN Interlock (Vin)

1.0 Overview

1.3 Performance Specifications

MIMO (2X2) ON			
Modulation	IPerf Throughput (Mbps)	Throughput @ Sensitivity (dBm)	Maximum Total Tx Power (dBm) +/- 1dB
8 MHz Channel Bandwidth			
BPSK_1/2	3	-99.5	30dBm
QPSK_1/2	5.9	-98	30dBm
QPSK_3/4	8.8	-96	30dBm
16QAM_1/2	11.6	-92	30dBm
16QAM_3/4	17.1	-90	30dBm
64QAM_2/3	22.8	-85	30dBm
64QAM_3/4	25.5	-83.5	30dBm
64QAM_5/6	27.8	-81	30dBm
4 MHz Channel Bandwidth			
BPSK_1/2	1.51	-102.5	30dBm
QPSK_1/2	2.98	-101	30dBm
QPSK_3/4	4.4	-99	30dBm
16QAM_1/2	5.8	-95.5	30dBm
16QAM_3/4	8.6	-93	30dBm
64QAM_2/3	11.4	-88	30dBm
64QAM_3/4	12.8	-86	30dBm
64QAM_5/6	14	-83.5	30dBm
MIMO OFF			
Modulation	IPerf Throughput (Mbps)	Throughput @ Sensitivity (dBm)	Maximum Tx Power (dBm) +/- 1dB
8 MHz Channel Bandwidth			
BPSK_1/2	3	-96.5	30dBm
QPSK_1/2	5.8	-95	30dBm
QPSK_3/4	8.6	-93	30dBm
16QAM_1/2	11.5	-89	30dBm
16QAM_3/4	16.9	-87	30dBm
64QAM_2/3	22.2	-82	28dBm
64QAM_3/4	24.7	-80.5	28dBm
64QAM_5/6	27.4	-78	27dBm
4 MHz Channel Bandwidth			
BPSK_1/2	1.5	-99.5	30dBm
QPSK_1/2	2.9	-98	30dBm
QPSK_3/4	4.3	-96	30dBm
16QAM_1/2	5.7	-92.5	30dBm
16QAM_3/4	8.4	-90	30dBm
64QAM_2/3	11.3	-85	28dBm
64QAM_3/4	12.5	-83	28dBm
64QAM_5/6	14	-80.5	27dBm

Table 1-2: pMDDL Performance Specifications

2.0 Quick Start

This QUICK START guide will walk you through the setup and configuration of a few basic applications. The QUICK START will rely on the *WebUI* for configuration. This walkthrough also assumes the units used are installed in microhard interface/development boards or custom boards that allow access to the LAN port. See the appropriate section for pin-outs.


Note that the units arrive from the factory with a Radio Configuration of 'Master' and the Local Network setting configured as 'Static' (IP Address **192.168.168.1**, Subnet Mask 255.255.255.0). DHCP is enabled by default, and will assign an IP to a connected device or computer with DHCP enabled.

2.1 Getting Started

- ✓ Connect an appropriate Antenna to the **ANTENNA** connector of the pMDDL.
- ✓ Connect and/or apply a suitable power source to the unit. Allow the unit to boot up fully, the CPU LED (Blue) should be on in a solid state
- ✓ Connect A PC to the **LAN** port (eth0) of the pMDDL, using an Ethernet Cable.



To reset to factory defaults, press and hold the CONFIG for 8 seconds with the pMDDL powered up. The pMDDL will reboot with factory default settings.




LAN



The factory default network settings:

IP: **192.168.168.1**
Subnet: **255.255.255.0**

- ✓ The PC must have its Network Setting (TCP/IP Properties) set to DHCP (The modem will assign a IP address to you), or STATIC with an IP Address of (e.g.) 192.168.168.10 and a Subnet Mask of 255.255.255.0.
- ✓ Open a Browser Window and enter the IP address 192.168.168.1 into the address bar.



192.168.168.1

2.0 Quick Start


- ✓ The pMDDL will then ask for a Username and Password. Enter the factory defaults listed below.



The factory default login:

User name: **admin**
Subnet: **admin**

You will be forced to change the default password upon logging in for the first time.



The dialog box titled "Authentication Required" contains the following text: "The server http://192.168.168.1:80 requires a username and password. The server says: WebUI." Below this text are two input fields: "User Name:" with the value "admin" and "Password:" with the value "*****". At the bottom are two buttons: "Log In" and "Cancel".

The Factory default login:

User name: **admin**
Password: **admin**

Once successfully logged in for the first time, the pMDDL will force a password change

- ✓ Once successfully logged in, the System Summary window will be displayed.

SystemNetworkWirelessFirewallSerialDiagAdmin

SummarySettingsServicesMaintenanceReboot

System Information

System Information

Host Name	UserDevice	Description	mypDDL-MIMO
Product Name	pDDL-MIMO	System Date	2017-07-04 15:20:35
Hardware Version	Rev A	System Uptime	3:44
Software Version	v1.4.0	Build Date	2017-07-04
Software Build	1005	Build Time	11:31:18

LAN Status

MAC Address	00:0F:92:04:22:84		
IP Address	192.168.168.1	Connection Type	static
Subnet Mask	255.255.255.0	Gateway	192.168.168.1

WAN Status

MAC Address	00:0F:92:05:22:84		
IP Address	N/A	Connection Type	dhcp
Subnet Mask	N/A	Gateway	N/A
Primary DNS	N/A	Secondary DNS	N/A

RF Status

General Status

MAC Address	Operation Mode	Network ID	Compatibility Mode	Bandwidth	Frequency	Tx Power	Encryption Type
00:0F:92:FA:94:CF Master		MHK_Alpha	pDDL	8 MHz	2477 MHz	20 dBm	AES-128

Traffic Status


Receive Bytes	Receive Packets	Transmit Bytes	Transmit Packets
0B	0	71.666KB	586

Stop RefreshingInterval: 20(in seconds)

2.0 Quick Start

2.2 Simple Master and Slave - Auto (Using Defaults)

This **Quick Start** example requires (2) pMDDL units, one will be configured as a Master (M), the second unit will be configured as a Slave/Remote (S). This example will use factory defaults to set up each unit so that a simple network will be established.



- ✓ Use [Section 2.1 Getting Started](#) to power up a pair of pMDDL modules mounted in a Pico Ethernet Motherboard.
- ✓ Master: Once the pMDDL is fully booted (solid blue CPU LED), press and hold the CFG button. Once the CPU LED begins to flash, continue to hold for at least **10 seconds**, then release.



Press and hold **CFG** button for at least **10 seconds** to reset to a default Master pMDDL.

Press and hold **CFG** button for **5 seconds**
to reset to a default Slave pMDDL

CPU LED (Blue)


RSSI LEDS (Green)

- ✓ The pMDDL will then reset all settings to default values, and set the following settings that are required to automatically create a link with a slave:
 - IP Address: **192.168.168.1**, Operating Mode: **Master**
 - Network ID: **MHK_Alpha**, Channel Bandwidth: **8 MHz**
 - Channel-Frequency: **76 - 2477 MHz**
- ✓ Slave: Ensure the pMDDL is fully booted (solid blue CPU LED), then press and hold the CFG button. Once the CPU LED begins to flash, continue to hold for **5 seconds**, then release.
- ✓ The pMDDL will then reset all settings to default values, and set the following settings that are required to automatically create a link with a slave:
 - IP Address: **192.168.168.2**, Operating Mode: **Slave**
 - Network ID: **MHK_Alpha**, Channel Bandwidth: **8 MHz**
 - Channel-Frequency: **76 - 2477 MHz**
- ✓ Once both units have finished changing settings (~60 seconds) a wireless link should automatically be established between them, this can be seen by observing the RSSI LEDs, they should be on solid, indicating a link (the more LEDs illuminated = stronger the link).

2.0 Quick Start

2.3 Simple Master and Slave — Manual Setup

This **Quick Start** example requires (2) pMDDL units, one will be configured as a Master (M), the second unit will be configured as a Slave/Remote (S). This example will show the basic steps required to set up each unit so that a simple network will be established.



For the best performance it is required to connect the Master to the video source (camera) and the remote to the video receiver. The pMDDL can support Point-to-Multipoint applications and multiple remotes could be used to view the video from multiple locations.

2.3.1 Configuring the Master

- ✓ Use **Section 2.1 Getting Started** to connect, power up and log in to a pMDDL unit.
- ✓ Give the pMDDL unit a unique IP address.



To connect to an existing network, contact your Network Administrator for valid network settings.

Select **Network** from the top/main navigation.

Select **LAN** from the submenu list. Select Edit on the LAN interface 1.

System	Network	Wireless	Firewall
Status	LAN	WAN	Routes
Ports	Device		
Network LAN Configuration			
LAN Interfaces Settings			
No.	Name	Static IP Address	
1	lan	192.168.168.1	

Choose **Static IP** for the **Connection Type**.

Enter the following Network Information:

IP Address: 192.168.168.11
IP Subnet Mask: 255.255.255.0

LAN Configuration	
Spanning Tree (STP)	Off ▼
Connection Type	Static IP ▼
IP Address	192.168.168.11
Netmask	255.255.255.0
Default Gateway	

Click on the **Submit** button to write the changes to the pMDDL. The **Cancel** button will revert back to last values saved to the unit.

Refer to **Section 5.2.2 LAN** for additional information.

Once the IP Address is changed, you will need to type the new address into your browser to continue the configuration.

2.0 Quick Start

2.3.1 Configuring the Master (Con't)

- ✓ Configure the pMDDL as a Master

Select **Wireless** from the top/main navigation, and then **RF** from the submenu list.



RF Configuration

Radio ☒ On ☐ Off

Channel Bandwidth

Channel-Frequency

Tx Power

Wireless Distance

MIMO ☒ On ☐ Off

In the RF Configuration, ensure the **Compatibility Mode**, **Channel Bandwidth** and **Channel-Frequency** are set the same on each module.

For bench or close proximity testing it is best to use a lower power setting to prevent RF saturation. Select 20dBm from the **TX Power** setting.

Select **Master** from the **Operation Mode** dropdown box.

Set a **Network ID**, which will need to be the same on each unit in the network. This example uses **TEST_ID**.

Operation Mode	Master ▾
TX Rate	Auto ▾
Extended Addressing	<input checked="" type="radio"/> On <input type="radio"/> Off
Network ID	TEST_ID
Encryption Type	AES-128 ▾
Encryption Key	1234567890
Show password	<input checked="" type="checkbox"/>

The remaining settings in the **Wireless** menu should be left as defaults for this exercise.

Refer to **Section 5.3 Wireless** for additional information.

Click on the **Submit** button to write the changes to the pMDDL. The **Cancel** button will revert back to previously saved values



If any additional settings need to be changed, ensure they are also changed on the Slave.

System	Network	Wireless	Firewall	Serial	Diag	Admin
Status	RF					
Wireless Configuration						
RF Configuration						
Radio	<input checked="" type="radio"/> On <input type="radio"/> Off					
Channel Bandwidth	8MHz ▾					
Channel-Frequency	76 - 2477 MHz ▾					
Tx Power	20 dbm ▾					
Wireless Distance	<input type="text" value="3000"/> (m)					
MIMO	<input checked="" type="radio"/> On <input type="radio"/> Off					
Operation Mode	Master ▾					
TX Rate	Auto (recommended) ▾					
Extended Addressing	ON ▾					
Network ID	<input type="text" value="TEST_ID"/>					
Encryption Type	AES-128 ▾					
Encryption Key	<input type="text" value="1234567890"/>					
Show password	<input checked="" type="checkbox"/>					

2.0 Quick Start

2.3.2 Configuring the Slave/Remote

The following procedure describes the steps required to set up a pMDDL unit as a Slave (S). A Slave provides a single wireless connection (i.e to an Master) and provides a wired connection to a PC or other devices.

- ✓ Use [Section 2.1 Getting Started](#) to connect, power up and log in to a second pMDDL unit.
- ✓ Give the pMDDL unit an unique IP address.

Select [Network](#) from the top/main navigation.

Select [LAN](#) from the submenu list.
Select Edit on the LAN interface 1.

System	Network	Wireless	Firewall
Status	LAN	WAN	Routes
Ports	Device		
Network LAN Configuration			
LAN Interfaces Settings			
No.	Name	Static IP Address	
1	lan	192.168.168.1	



To connect to an existing network, contact your Network Administrator for valid network settings.

LAN Configuration	
Spanning Tree (STP)	Off ▼
Connection Type	Static IP ▼
IP Address	192.168.168.12
Netmask	255.255.255.0
Default Gateway	192.168.168.11

Choose [Static IP](#) for the [Connection Type](#).

Enter the following Network Information:

IP Address: 192.168.168.12
IP Subnet Mask: 255.255.255.0
Default Gateway: 192.168.168.11

Refer to [Section 5.2.2 LAN](#) for additional information.

Click on the [Submit](#) button to write the changes to the pMDDL. The [Cancel](#) button will revert back to last values saved to the unit.

Once the IP Address is changed, you will need to type the new address into your browser to continue the configuration.

2.0 Quick Start

2.3.3 Configuring the Slave/Remote (Con't)

- ✓ Configure the pMDDL as a Slave

Select **Wireless** from the top/main navigation, and then **RF** from the submenu list.



RF Configuration	
Radio	<input checked="" type="radio"/> On <input type="radio"/> Off
Channel Bandwidth	8MHz ▼
Channel-Frequency	76 - 2477 MHz ▼
Tx Power	20 dbm ▼
Wireless Distance	3000
MIMO	<input checked="" type="radio"/> On <input type="radio"/> Off

In the **RF Configuration** ensure the **Compatibility Mode**, **Channel Bandwidth** and **Channel-Frequency** are set the same on each module.

For bench or close proximity testing it is best to use a lower power setting to prevent RF saturation. Select 20dBm from the **TX Power** setting.

Select **Slave** from the **Operating Mode** dropdown box.

Set a **Network ID**, which will need to be the same on each unit in the network. This example uses **TEST_ID**.

Operation Mode	Slave ▼
TX Rate	Auto (recommended) ▼
Extended Addressing	<input checked="" type="radio"/> On <input type="radio"/> Off
Network ID	TEST_ID
Encryption Type	AES-128 ▼
Encryption Key	1234567890
Show password	<input checked="" type="checkbox"/>



If any additional settings need to be changed, ensure they are also changed on the Slave.

System	Network	Wireless	Firewall	Serial	Diag	Adm
Status	RF					
Wireless Configuration						
RF Configuration						
Radio	<input checked="" type="radio"/> On <input type="radio"/> Off					
Channel Bandwidth	8MHz ▼					
Channel-Frequency	76 - 2477 MHz ▼					
Tx Power	20 dbm ▼					
Wireless Distance	3000 (m)					
MIMO	<input checked="" type="radio"/> On <input type="radio"/> Off					
Operation Mode	Slave ▼					
TX Rate	Auto (recommended) ▼					
Extended Addressing	ON ▼					
Network ID	TEST_ID					
Encryption Type	AES-128 ▼					
Encryption Key	1234567890					
Show password	<input checked="" type="checkbox"/>					

The remaining settings in the **Wireless** menu should be left as defaults for this exercise.

Refer to **Section 5.3 Wireless** for additional information.

Click on the **Submit** button to write the changes to the pMDDL. The **Cancel** button will revert back to previously saved values

2.0 Quick Start

2.3.3 Testing the Connection

- ✓ Visually check to see if the pMDDL units are communicating.



RSSI LED's that are 'cycling' or 'scanning' indicate that the unit is searching for a signal.

The **RSSI** LED's represent signal strength, the more LED's that are illuminated, the stronger the signal. The **Wireless > Status** window also has a Connection Status section similar to that seen below:

RF Status

General Status

MAC Address	Operation Mode	Network ID	Compatibility Mode	Bandwidth	Frequency	Tx Power	Encryption Type
00:0F:92:FA:37:C5 Master		TEST_ID	pDDL	8 MHz	2.477 GHz	20 dBm	AES-128



Traffic Status

Receive Bytes	Receive Packets	Transmit Bytes	Transmit Packets
104.895KB	404	77.873KB	562

Connection Info (1)

MAC Address	Tx Mod	Rx Mod	SNR (dB)	RSSI (dBm)	Signal Level	RSSI Graph
00:0F:92:FA:37:CE	64-QAM FEC 5/6	64-QAM FEC 5/6	29	-62	<div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div>	

- ✓ With a PC connected to the Master (M), type in the IP address of the Slave (S) into the URL address bar of your browser. You should be able to connect, log in and view the WebUI of the Slave via the wireless connection.



Open a browser and type in the address of the slave: **192.168.168.12**

Log into the unit.

The System Summary screen should be displayed



If any additional settings need to be changed, ensure they are also changed on all radios.

Warning: This server is requesting that your user password be sent in an insecure manner (basic without a secure connection).

User name:

Password:

☐ Remember my password

System	Network	Wireless	Firewall	Serial	Diag	Admin
Summary	Settings	Services	Maintenance	Reboot		
System Information						
System Information						
Host Name	User/Device	Description	mpeDDL-MIMO			
Product Name	pDDL-MIMO	System Date	2017-07-04 11:40:13			
Hardware Version	Rev A	System Uptime	3 min			
Software Version	v1.4.0	Build Date	2017-07-04			
Software Build	1005	Build Time	11:31:18			
LAN Status						
MAC Address	00:0F:92:04:22:84					
IP Address	192.168.168.2	Connection Type	static			
Subnet Mask	255.255.255.0	Gateway	192.168.168.1			
WAN Status						
MAC Address	00:0F:92:05:22:84					
IP Address	N/A	Connection Type	dhcp			
Subnet Mask	N/A	Gateway	N/A			
Primary DNS	N/A	Secondary DNS	N/A			

3.0 Hardware Features

3.1 pMDDL OEM Module

The pMDDL modems are available as OEM modules for complete integration into custom designs. The OEM module supplies all the required raw signals to allow the unit to be tightly integrated into applications to efficiently maximize space and power requirements. The Microhard development board can provide a convenient evaluation platform to test and design with the module. (Contact Microhard Systems for details)

Any pMDDL module may be configured as a Master, Slave(Remote), or Relay (future). This versatility is very convenient from a 'sparing' perspective, as well for convenience in becoming familiar and proficient with using the module: if you are familiar with one unit, you will be familiar with all units.




Image 3-1: pMDDL2450 Top View





Image 3-2: pMDDL2450 Bottom View

3.0 Hardware Features

3.1.1 Mechanical Drawings

The pMDDL OEM Modules have an extremely small form factor as seen *below*.




Units: millimeters

1. Ground plane must be connected to GND for required heat dissipation.
2. Due to manufacturing methods additional PCB material may be present on the corners that cannot be removed. Designs should allow for a small tolerance of this additional material, $\pm 0.25\text{mm}$


Drawing 3-1: pMDDL OEM Mechanical

3.0 Hardware Features

3.1.2 Recommended Solder Mask (Pad Landing)




Units: millimeters



Drawing 3-2: pMDDL Recommended Solder Mask

3.0 Hardware Features

3.1.5 SMT Temperature Profile



Drawing 3-4: pMDDL Reflow Profile

Temperature Zone	Time	Parameter
Preheat zone: (40°C - 165°C)	-	Heating rate: 0.5°C/s-2°C/s
Soak Zone: (165°C - 217°C)	60 - 100s	-
Reflow zone: (>217°C)	120s	Peak reflow: 255°C
Cooling zone	Cooling rate: 2°C/s ≤ Slope ≤ 5°C/s	

Table 3-1: pMDDL Reflow Parameters

Zone	Temperature (°C)
1	120
2	140
3	160
4	180
5	215
6	255
7	255
8	255
9	250
10	130

Chain Speed: 60cm/min

Table 3-2: pMDDL Oven Temperature Profile


3.1.6 SMT Baking Instructions (MSL)

The pMDDL OEM modules must be baked before mounting, the following baking instruction should be followed for the best results:

- Minimum of 8 to 12 hours at 125°C +/- 5°C for high-temperature device containers.
- Unused modules should be stored at ≤ 10% RH

3.0 Hardware Features

3.1.8 pMDDL OEM Pin Descriptions



Drawing 3-5: pMDDL 80-pin OEM Connection Info



Inputs and outputs are 3.3V nominal (3.0V min — 3.6V max) unless otherwise specified.

The above drawing depicts a top view of the pMDDL OEM Module. A full description of the connections and function of each pin is provided on the pages that follow.

Heat Dissipation

For optimal performance it is important to include adequate heat dissipation including a heat sink in any designs that integrate the pMDDL OEM module (also required for designs that incorporate the optional socket).

3.0 Hardware Features



Caution: During power up or reset, output pins from the Pico are in an unknown state. It is advised to use pull up or pull down resistors as appropriate.

Pin Name	No.	Description	Dir
GND	1,17,25-26,39-40,65-80	Ground reference for logic, radio, and I/O pins.	
DNC	2,3,4,5,6	Reserved for factory use only.	
NC	7,8,9,10,12,27,33,35,36,37,38,45,46,47,48,50,51,52,53,54,59	<i>*Currently Not Supported. For Future Expansion*</i>	
CPU STATUS LED	11	Active high output indicates CPU/Module status. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
ETH_BIAS	13	Bias Voltage to Ethernet PHY transformer	
USB_MODE	14	Indicates if the interface is in host/device mode. 0 = Device (Connected through 1K resistor to GND), 1 = Host.	I
Config	15	Active low. In normal mode, pull it low and hold for more than 8 seconds will reset the system to default settings. Pull it low upon power up will put the module into recovery mode.	I
RESET	16	Active low input will reset module	I
USBDP	18	USB D+ signal; carries USB data to and from the USB 2.0 PHY	
USBDM	19	USB D- signal; carries USB data to and from the USB 2.0 PHY	
LED_1 (RSSI1)	20	Receive Signal Strength Indicator 1. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
LED_2 (RSSI2)	21	Receive Signal Strength Indicator 2. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
LED_3 (RSSI3)	22	Receive Signal Strength Indicator 3. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
LED_RX	23	Active high output indicates receive and synchronization status. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
LED_TX	24	Active high output indicates module is transmitting data over the RF channel. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
Serial RxD	28	Receive Data. Logic level input into the modem. It is recommended to wire this pin out through a zero ohm resistor to a header and jumper block for external access to the serial port for modem recovery procedures.	I
Serial TxD	29	Transmit Data. Logic level Output from the modem. It is recommended to wire this pin out through a zero ohm resistor to a header and jumper block for external access to the serial port for modem recovery procedures.	O
Serial DSR	30	Data Set Ready. Active low output. <i>The DSR line set high enables the transmitter of the RS485 driver.</i>	O
Serial CTS	31	Clear To Send. Active low output.	O
Serial DTR	32	Data Terminal Ready. Active Low output.	O
Serial RTS	34	Request To Send. Active low input.	I

Table 3-3: pMDDL Pin Description

All serial communications signals are logic level (0 and 3.3V). DO NOT connect RS-232 level (+12, -12VDC) signals to these lines without shifting the signals to logic levels.

3.0 Hardware Features



Caution: During power up or reset, output pins from the Pico are in an unknown state. It is advised to use pull up or pull down resistors as appropriate.

Pin Name	No.	Description	Dir
RX_N4	41	Ethernet Port 4 (WAN) Receive Pair	
RX_P4	42		
TX_N4	43	Ethernet Port 4 (WAN) Transmit Pair	
TX_P4	44		
ETH4 LINK_LED	49	Active high output indicates Ethernet port 4 link status. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
TX_P0	55	Ethernet Port 0 (LAN) Transmit Pair	
TX_N0	56		
RX_N0	57	Ethernet Port 0 (LAN) Receive Pair	
RX_P0	58		
ETH0 LINK_LED	60	Active high output indicates Ethernet port 0 link status. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
Vdd	61,62	Positive voltage supply voltage for the digital section of the module (3.3V).	I
Vpa	63,64	Positive voltage supply voltage for the radio module (3.3-5V).	I


Table 3-3: pMDDL Pin Description (continued)

All serial communications signals are logic level (0 and 3.3V). DO NOT connect RS-232 level (+12, -12VDC) signals to these lines without shifting the signals to logic levels.

See **Appendix D: Sample Interface Schematic** for a sample schematic that can be used to interface to the pMDDL OEM module.

3.1.9 USB Device Mode

The pMDDL can be set to operate as a USB Device. When set as a USB device, Microhard Composite Drivers can be installed on a USB Host to provide Ethernet and Serial functionality to the USB port on the pMDDL. To enable USB Device mode, Pin 14 must be connect to GND through a 1K resistor as shown below:



Drawing 3-6: pMDDL USB Device Mode

3.0 Hardware Features

3.2 pMDDL Enclosed

The pMDDL-ENC is a robust and compact enclosed unit that provides easy access to all the standard interfaces for connecting and working with the pMDDL. The enclosed model is ideal for base stations and applications where a full integration is not required and the modem can be used right out of the box with only software configuration required.

The pMDDL-ENC includes the following standard indicators and interfaces:


- 2x RJ45 Ethernet Ports
- DE9 Female Serial Port Interface
- USB Type A (Future)
- Micro-AB USB (Console - Future)
- Power / IO Connector (7-30 VDC)
- Power / CPU Status LED (Blue)
- Wireless Activity (Tx/Rx) LED's (Red/Green)
- RSSI (x3) LED's (Green)
- RS485 LED (Blue)
- Config Button (Reset/Recovery Operations)
- 3x RP-SMA Female Antenna (ANT1, ANT2, Aux)



Image 3-3: pMDDL-ENC

3.0 Hardware Features

3.2.1 pMDDL-ENC Mechanical Drawings



Drawing 3-7: pMDDL-ENC Mechanical

3.0 Hardware Features

3.2.2 pMDDL-ENC Connectors & Indicators




Figure 3-1: pMDDL-ENC Top View

Antennas:

The pMDDL-ENC module uses a RP-SMA Female connectors. ANT1 and ANT2 are marked on the Enclosure. AUX is used to trigger an external amplifier as it goes high (3.3V) during TX.

RSSI LEDs (Green):

The RSSI LEDs indicate the Received Signal Strength on the Wireless Link. On a Master it will indicate an average RSSI value based on connected units. On a Slave the RSSI LEDs will represent the signal strength between the Slave and the Master it is connected to. (The more LEDs illuminated, the stronger the signal)

TX/RX LEDs (Red/Green):

The TX/RX LEDs indicate wireless traffic to/from the pMDDL module.

RS485 LED (Blue):

The RS485 LED indicates that the serial port has been configured as a RS485 port.

CPU/Status (Blue):

The CPU/Status LED indicates that power has been applied to the module. A Solid LED indicates normal operation, while flashing indicates boot or firmware upgrade status.

3.0 Hardware Features




Figure 3-2: pMDDL-ENC Back View

Ethernet LAN:

The Ethernet LAN port is a standard RJ45 port to connect local network devices. The default IP address for this port is 192.168.168.1.

Ethernet WAN:

The Ethernet WAN port is a standard RJ45 Port that can be used as a separate WAN port for Router functions, or can be bridged (via software) to the LAN as a additional switch port for local devices.

The pMDDL-ENC can be powered using **Passive PoE from 12—30 VDC Maximum** on the WAN port using a PoE injector that meets the following requirements:

Ethernet RJ45 Connector Pin Number								
Source Voltage	1	2	3	4	5	6	7	8
12 - 30 Vdc	Data	Data	Data	DC+	DC+	Data	DC-	DC-

Table 3-2: Ethernet (WAN) PoE Connections


Power:

The pMDDL-ENC can powered using an input voltage in the 7-30 VDC range.

Power

Console:

The console port is a Micro-AB USB port that uses a generic FTDI driver as a USB/Serial Interface. When a cable is connected to this port from a PC the FTDI driver should automatically be installed. (Future Development - Coming Soon)



3.0 Hardware Features




Figure 3-3: pMDDL-ENC End View

CFG/RESET Button:

The Config button on the pMDDL can be used to either reset the modem into its factory default configuration, or it can be used to perform a firmware recovery procedure.

Factory Default Settings: While power is applied and the pMDDL in an operational state, press and hold the *Config* Button for more than 10 seconds to reset to a factory default Master, alternatively hold the button for 5 seconds for a factory default Slave.

Firmware Recovery: To load the firmware on the unit it is recommended to use the normal WebUI to perform a firmware update (Maintenance). In the event that the firmware cannot be loaded using the standard WebUI (non responsive unit), pressing and holding the *Config* Button while powering-up the module will force the pMDDL into a firmware recovery mode. There are 3 main modes, HTTP, TFTP and Master Reset. The table below shows the time required to hold the *Config* button while power is applied:

0 to 5 seconds HTTP Recovery	5 to 10 seconds TFTP Recovery	10 to 15 seconds Master Reset	15+ seconds No Effect
---------------------------------	----------------------------------	----------------------------------	--------------------------

HTTP Recovery: Set an IP on a PC to 192.168.1.1. Open a web browser and Navigate to 192.168.1.39. This will open a simple webpage which will allow a firmware file to be loaded.

TFTP Recovery: Set an IP on a PC to 192.168.1.1. Use a TFTP session to push the firmware file to the modems recovery IP of 192.168.1.39. See Appendix for Firmware Recovery Procedure.

Master Reset: Runs Master Reset, file system is erased.

DE9 Serial:

The RS232/485 Serial data port can be used to communicate with Serial devices or it can be configured to operate as a console port. See Table 3-3 for pin assignments.

RS232/RS485 modes are selected through the serial port configuration in the WebUI. The LED on the pMDDL-ENC will illuminate when in RS485 mode.

USB (Type A, 2.0):

(Future Development)

Pin No.	RS232	RS485 Full-Dup	RS485 Half-Dup
1	DCD		
2	RXD	TX-	Data-
3	TXD	RX+	
4	DTR		
5	Ground		
6	DSR		
7	RTS	RX-	
8	CTS	TX+	Data+
9	N/C		

Table 3-3: DE9 Data Pin Assignment

3.0 Hardware Features

3.3 pMDDL Development Board

The pMDDL Development board provides a platform in which to test and evaluate the operation of the pMDDL without the need to design a custom interface PCB right from the start. The pMDDL includes a socket to insert the pMDDL and provides standard interfaces/indicators for:

- Ethernet (RJ45 x2)
- RS232 Serial Port
- USB Port (Type A)
- Power (9-30 VDC)
- CPU Status LED
- Tx/Rx LED's
- RSSI (x3) LED's
- Config Button (Reset/Recovery Operations)





Image 3-3: pMDDL Development Board

3.3.1 pMDDL Development Board Mechanical Drawings



Drawing 3-8: pMDDL Development Board Mechanical Drawings

3.0 Hardware Features

3.3.2 pMDDL Development Board Connectors & Indicators




Figure 3-4: pMDDL Development Board

Antennas:

The pMDDL OEM module uses a UFL connectors, Ensure proper orientation as seen above to prevent damage to the pMDDL module and to the development board. ANT1 and ANT2 are marked on the module.

Ethernet LAN:

The Ethernet LAN port is a standard RJ45 port to connect local network devices. The default IP address for this port is 192.168.168.1.

Ethernet WAN:

The Ethernet WAN port is a standard RJ45 Port that can be used as a separate WAN port for Router functions, or can be bridged (via software) to the LAN as a additional switch port for local devices.

The pMDDL development board can be powered using **Passive PoE from 12—30 VDC Maximum** on the WAN port using a PoE injector that meets the following requirements:


Ethernet RJ45 Connector Pin Number								
Source Voltage	1	2	3	4	5	6	7	8
12 - 30 Vdc	Data	Data	Data	DC+	DC+	Data	DC-	DC-

Table 3-2: Ethernet (WAN) PoE Connections

Power:

The pMDDL development board can powered using an input voltage in the 9-30 VDC range.

Power



3.0 Hardware Features

Config Button:

The Config button on the pMDDL can be used to either reset the modem into its factory default configuration, or it can be used to perform a firmware recovery procedure.

Factory Default Settings: While power is applied and the pMDDL in an operational state, press and hold the *Config* Button for more than 10 seconds to reset to a factory default Master, alternatively hold the button for 5 seconds for a factory default Slave.

Firmware Recovery: To load the firmware on the unit it is recommended to use the normal WebUI to perform a firmware update (Maintenance). In the event that the firmware cannot be loaded using the standard WebUI (non responsive unit), pressing and holding the *Config* Button while powering-up the module will force the pMDDL into a firmware recovery mode. There are 3 main modes, HTTP, TFTP and Master Reset. The table below shows the time required to hold the *Config* button while power is applied:

0 to 5 seconds HTTP Recovery	5 to 10 seconds TFTP Recovery	10 to 15 seconds Master Reset	15+ seconds No Effect
---------------------------------	----------------------------------	----------------------------------	--------------------------

HTTP Recovery: Set an IP on a PC to 192.168.1.1. Open a web browser and Navigate to 192.168.1.39. This will open a simple webpage which will allow a firmware file to be loaded.

TFTP Recovery: Set an IP on a PC to 192.168.1.1. Use a TFTP session to push the firmware file to the modems recovery IP of 192.168.1.39. See Appendix for Firmware Recovery Procedure.

Master Reset: Runs Master Reset, file system is erased.

RS232 Serial:

The RS232 Serial data port can be used to communicate with RS232 Serial devices or it can be configured to operate as a console port. See Table 3-3 for pin assignments.

CPU/Status:

The CPU/Status LED indicates that power has been applied to the module. A Solid LED indicates normal operation, while flashing indicates boot or firmware upgrade status.

TX/RX LEDs:

The TX/RX LEDs indication wireless traffic to/from the pMDDL module.

RSSI LEDs:

The RSSI LEDs indicate the Received Signal Strength on the Wireless Link. On a Master it will indicate an average RSSI value based on connected units. On a Slave the RSSI LEDs will represent the signal strength between the Slave and the Master it is connected to. (The more LEDs illuminated, the stronger the signal)

Name	Data Port	Input or Output
DCD	1	O
RXD	2	O
TXD	3	I
DTR	4	I
SG	5	
DSR	6	O
RTS	7	I
CTS	8	O
RING	9	O

Table 3-3: Data DE9 RS232 Pin Assignment

4.0 Configuration

4.0 Web User Interface




Image 4-0-1: WebUI



The factory default network settings:

IP: 192.168.168.1
Subnet: 255.255.255.0

Initial configuration of an pMDDL using the Web User (Browser) Interface (Web UI) method involves the following steps:

- configure a static IP Address on your PC to match the default subnet or if your PC is configured for DHCP, simply connect a PC to the LAN port of the pMDDL and it will be assigned a IP address automatically.
- connect the pMDDL LAN port to PC NIC card using an Ethernet cable
- apply power to the pMDDL and wait approximately 60 seconds for the system to load
- open a web browser and enter the factory default IP address (192.168.168.1) of the unit:
- logon window appears; log on using default Username: **admin** Password: **admin**
- use the web browser based user interface to configure the pMDDL as required.
- refer to **Section 2.0: Quick Start** for step by step instructions.

In this section, all aspects of the Web Browser Interface, presented menus, and available configuration options will be discussed.

4.0 Configuration

4.0.1 Logon Window


Upon successfully accessing the pMDDL using a Web Browser, the Logon window will appear.



For security, do not allow the web browser to remember the User Name or Password.



It is advisable to change the login Password. Do not FORGET the new password as it cannot be recovered.



Authentication Required

A username and password are being requested by http://192.168.1.120. The site says: "webUI"

User Name:

Password:

OK Cancel

Image 4-0-2: Logon Window

The factory default User Name is: **admin**
The default password is: **admin**


Note that the password is case sensitive. It may be changed (discussed further along in this section), but once changed, if forgotten, may not be recovered.

When entered, the password appears as 'dots' as shown in the image below. This display format prohibits others from viewing the password.

The 'Remember my password' checkbox may be selected for purposes of convenience, however it is recommended to ensure it is deselected - particularly once the unit is deployed in the field - for one primary reason: security.



Authentication Required

 A username and password are being requested by http://192.168.1.120. The site says: "webUI"

User Name:

Password:

Image 4-0-3: Logon Window : Password Entry

After successfully logging into the Pico DDL for the first time, you will be forced, and prompted to change the admin password.

4.0 Configuration

4.1 System

The main category tabs located at the top of the navigation bar separate the configuration of the pMDDL into different groups based on function. The System Tab contains the following submenus:

- Summary - Status summary of entire radio including network settings, version information, and radio connection status.
- Settings - Host Name, System Log Settings, System Time/Date.
- Services - Enable/Disable and configure port numbers for SSH, Telnet, HTTP and HTTPS services.
- Maintenance - Remote firmware Upgrades, reset to defaults, configuration backup and restore.
- Reboot - Remotely reboot the system.

4.1.1 System > Summary

The System Summary screen is displayed immediately after initial login, showing a summary and status of all the functions of the pMDDL in a single display. This information includes System Status, LAN/WAN network information, version info, Radio Status etc.



System Information

System Information			
Host Name	UserDevice	Description	mypDDL-MIMO
Product Name	pDDL-MIMO	System Date	2017-07-04 11:41:50
Hardware Version	Rev A	System Uptime	5 min
Software Version	v1.4.0	Build Date	2017-07-04
Software Build	1005	Build Time	11:31:18

LAN Status

MAC Address	00:0F:92:04:22:84	Connection Type	static
IP Address	192.168.168.1	Gateway	192.168.168.1
Subnet Mask	255.255.255.0		

WAN Status

MAC Address	00:0F:92:05:22:84	Connection Type	dhcp
IP Address	N/A	Gateway	N/A
Subnet Mask	N/A	Secondary DNS	N/A
Primary DNS	N/A		

RF Status

General Status

MAC Address	Operation Mode	Network ID	Compatibility Mode	Bandwidth	Frequency	Tx Power	Encryption Type
00:0F:92:FA:94:CF Master	MHK_Alpha	pDDL	8 MHz	2477 MHz	20 dBm	AES-128	

Traffic Status

Receive Bytes	Receive Packets	Transmit Bytes	Transmit Packets
0B	0	35.734KB	268

[Stop Refreshing](#) Interval: 20(in seconds)

Image 4-1-1: System Summary Window

4.0 Configuration

4.1.2 System > Settings

System Settings

Options available in the System Settings menu allow for the configuration of the Host Name, Description, Console Timeout, System Log server and System Time settings.

System	Network	Wireless	Firewall	Serial	Diag	Admin
Summary	Settings	Services	Maintenance	Reboot		

System Settings

System Settings

Host Name	<input type="text" value="UserDevice"/>
Description	<input type="text" value="mypDDL-MIMO"/>
Console Timeout (s)	<input type="text" value="120"/> [30 ~ 65535] 0-Disable
CFG Reset to Default Button	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
System Log Server IP/Name	<input type="text" value="0.0.0.0"/> 0.0.0.0-Disable
System Log Server Port	<input type="text" value="514"/> Default: 514

Time Settings

Current Date(yyyy-mm-dd)	2017-07-04
Current Time(hh:mm:ss)	11:43:52
Date and Time Setting Mode	<input type="radio"/> Local Time <input checked="" type="radio"/> NTP
Timezone	<input type="text" value="Mountain Time"/> ▼
POSIX TZ String	<input type="text" value="MST7MDT,M3.2.0,M11.1.0"/>
NTP Server IP/Name	<input type="text" value="pool.ntp.org"/>
NTP Local Port	<input type="text" value="123"/>
NTP Client Interval (seconds)	<input type="text" value="0"/> [15 ~ 65535] 0-Disable

Image 4-1-2: System Settings > System Settings

Host Name

The Host Name is a convenient identifier for a specific pMDDL unit. This feature is most used when accessing units remotely: a convenient cross-reference for the unit's WAN IP address. This name appears when logged into a telnet session.

Values (characters)

pMDDL (**varies**)

up to 64 characters

Description

The description is a text field that can be used to describe the unit or system. This value can be viewed on the System > Summary screen.

Values (characters)

pMDDL (**varies**)

up to 64 characters

Console Timeout (s)

This value determines when a console connection (made via Console Port or Telnet) will timeout after becoming inactive.

Values (seconds)

60
0-65535

4.0 Configuration

CFG Reset to Default Button

Enabled by default, when the CFG button on the front of the pMDDL is held down for 10s while the unit is powered up, the unit will reset and all settings will be reset to factory defaults. When disabled the unit will reset, but the settings will not be overwritten.

Values (Selection)

Enable
Disable

System Log Server IP

The pMDDL can report system level events to a third party System Log server, which can be used to monitor events reported by the pMDDL.

IP Address

0.0.0.0

System Log Server Port

Enter the UDP listening port of the System Log Server. The default port number is generally 514, but could vary from Server to Server.

UDP Port

514

Time Settings

The pMDDL can be set to use a local time source, thus keeping time on its own, or it can be configured to synchronize the date and time via a NTP Server. The options and menus available will change depending on the current setting of the Date and Time Setting Mode, as seen below.

Time Settings

Current Date(yyyy-mm-dd)	2016-01-12
Current Time(hh:mm:ss)	15:03:03
Date and Time Setting Mode	<input checked="" type="radio"/> Local Time <input type="radio"/> NTP
Date (yyyy-mm-dd)	<input type="text" value="2016-01-12"/>
Time (hh:mm:ss)	<input type="text" value="15:03:03"/>

Time Settings : Current Date(yyyy.mm.dd) 2015.11.27 Time(hh:mm:ss): 18:07:54

Date and Time Setting Mode	<input type="radio"/> Local Time <input checked="" type="radio"/> NTP
Timezone	<input type="text" value="Mountain Time"/>
POSIX TZ String	<input type="text" value="MST7MDT,M3.2.0,M11.1.0"/>
NTP Server IP/Name	<input type="text" value="pool.ntp.org"/>
NTP Server Port	<input type="text" value="123"/>
NTP Client Interval (seconds)	<input type="text" value="0"/> [0 ~ 65535] 0-Disable



Network Time Protocol (NTP) can be used to synchronize the time and date of computer systems with a centralized, referenced server. This can help ensure all systems on a network have the same time and date.

Image 4-1-3: System Settings > Time Settings

Date and Time Setting Mode

Select the Date and Time Setting Mode required. If set for 'Local Time' the unit will keep its own time and not attempt to synchronize with a network server. If 'NTP' is selected, a NTP server can be defined.

Values (selection)

Local Time
NTP

4.0 Configuration

Date

The calendar date may be entered in this field. Note that the entered value is lost should the pMDDL lose power for some reason.

Values (yyyy-mm-dd)

2016-01-12 (varies)

Time

The time may be entered in this field. Note that the entered value is lost should the pMDDL lose power for some reason.

Values (hh:mm:ss)

11:27:28 (varies)

Timezone

If connecting to a NTP time server, specify the time zone from the dropdown list.

Values (selection)

(varies)

POSIX TZ String

This displays the POSIX TZ String used by the unit as determined by the Timezone setting.

Values (read only)

(varies)

NTP Server

Enter the IP Address or domain name of the desired NTP time server.

Values (address)

pool.ntp.org

NTP Port

Enter the IP Address or domain name of the desired NTP time server.

Values (port#)

123

NTP Client Interval

By default the modem only synchronizes the time and date during system boot up (default: 0), but it can be modified to synchronize at a regular interval. *This process does consume data and should be set accordingly.*

Values (seconds)

0

4.0 Configuration

4.1.3 System > Services

Certain services in the pMDDL can be disabled or enabled for either security considerations or resource/power considerations. The Enable/Disable options are applied after a reboot and will take affect after each start up.

System	Network	Wireless	Firewall	Serial	Diag	Admin
Summary	Settings	Services	Maintenance	Reboot		

Services

Services Status

FTP	<input checked="" type="radio"/> Enable <input type="radio"/> Disable		<input type="button" value="Update"/>
Telnet	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	Port 23	<input type="button" value="Update"/>
SSH	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	Port 22	<input type="button" value="Update"/>
Web UI	<input checked="" type="radio"/> HTTP/HTTPS <input type="radio"/> HTTP <input type="radio"/> HTTPS	Port HTTP 80	<input type="button" value="Update"/>
		Port HTTPS 443	<input type="button" value="Update"/>

Image 4-1-4: System > Services

FTP

The FTP service can be enabled/disabled using the Services Status Menu. The FTP service is used for firmware recovery operations.

Values (port)

Enable / Disable

Telnet

Using the Telnet Service Enable/Disable function, you can disable the Telnet service from running on the pMDDL. The port used by the Telnet service can also be modified. The default is 23.

Values (port)

23

SSH

Using the SSH Service Enable/Disable function, you can disable the SSH service (Port 22) from running on the pMDDL. The port used by the SSH service can also be modified. The default is 22.

Values (port)

22

Web UI

The default web server port for the web based configuration tools used in the modem is port 80 (http) and port 443 (HTTPS).

Values (selection)

Change as required, but keep in mind that if a non standard port is used, it must be specified in a internet browser to access the unit. (example: <http://192.168.168.1:8080>).

HTTP/HTTPS
HTTP
HTTPS

4.0 Configuration

4.1.4 System > Maintenance

Firmware Upgrade

Occasional firmware updates may be released by Microhard Systems which may include fixes and/or new features. The firmware can be updated wirelessly using the WebUI.

System

Network

Wireless

Firewall

Serial

Diag

Admin

Summary

Settings

Services

Maintenance

Reboot

System Maintenance

Version Information

Product Name	Hardware Type	Build Version	Build Date	Build Time
pDDL-MIMO	1.0	v1.4.0 build 1005	2017-07-04	11:31:18

Firmware Upgrade

Erase Current Configurations

Keep All Configurations ▾

Firmware Image

Choose File | No file chosen

Upgrade

Upgrade Firmware

Reset to Default Configurations

Reset to Default Configurations

Reset to Default

☐ Wipeout data and logs

Image 4-1-5: Maintenance > Firmware Upgrade

Erase Current Configuration

Choose to keep or erase the current configuration. Erasing the configuration of the pMDDL unit during the upgrade process will upgrade, and return the unit to factory defaults, including the default IP Address and password.

Values (check box)

Keep ALL Configuration

Firmware Image

Use the Browse button to find the firmware file supplied by Microhard Systems. Select "Upgrade Firmware" to start the upgrade process. This can take several minutes.

Values (file)

(no default)

Reset to Default Configurations

The pMDDL may be set back to factory defaults by using the Reset to Default option under System > Maintenance > Reset to Default. ***Caution* - All configuration settings will be lost!!!**


Additionally you can select the “Wipeout data and logs” check box to delete all data including historical logs and any other data from the device. ***Caution* - All configuration settings & data/logs will be lost!!!**

4.0 Configuration

Security for Configurations / Backup & Restore Configuration

The configuration of the pMDDL can be backed up to a file at any time using the Backup Configuration feature. The file can be restored using the Restore Configuration feature. It is always a good idea to backup any configurations in case of unit replacement.

The configuration files cannot be edited offline, they are used strictly to backup and restore units. A password can be added to the Backup and Restore files. If the password is lost, files that have been backed up with a password can not be restored.



The screenshot displays the 'Security for Configurations' interface. It includes a 'Set Password' field with an 'Update' button. Below this are sections for 'Backup Configurations' and 'Restore Configurations'. The 'Backup Configurations' section shows the 'Configuration File Name' as 'MicrohardpDDL-MIMO.config' and a 'Backup' button. The 'Restore Configurations' section shows 'Select Configuration File' with a 'Choose File' button and 'Check Configuration File' with a 'Check Configuration File' button. A 'Backup Configuration' dialog box is open, showing 'Downloading Configuration File, please wait ...' and a link to 'MicrohardpDDL-MIMO.config'. A 'Restore Configuration' dialog box is also open, displaying 'Configuration Verified!' and a table of configuration details.

Restore Configuration	
Configuration Verified!	
Config file Name	MicrohardpDDL-MIMO.config
Generated	Tue Jul 4 11:48:29 MDT 2017
Vendor	2014-2016 Microhard Systems Inc.
Product	pDDL-MIMO-pDDL2458
Hardware Type	Rev A
Restore	

Image 4-1-6: Maintenance > Reset to Default / Backup & Restore Configuration

Configuration File Name / Backup

Use this field to name the configuration file. The .config extension will automatically be added to the configuration file.

Select Configuration file / Check Configuration File / Restore

Use the 'Browse' button to find the backup file that needs to be restored to the unit. Use the 'Check Restore File' button to verify that the file is valid, and then the option to restore the configuration is displayed, as seen above.

If the selected file is password protected the password must be set before restoring the file using the "Set Password" field under "Security for Configurations".

4.0 Configuration

4.1.5 System > Reboot

The pMDDL can be remotely rebooted using the System > Reboot menu. As seen below a button 'Reboot Now' is provided. Once pressed, the unit immediately reboots and starts its boot up procedure. An automatic Scheduled Reboot (up to 3) can also be configured to force the pMDDL to reboot daily, weekly or monthly.

System	Network	Wireless	Firewall	Serial	Diag	Admin
Summary	Settings	Services	Maintenance	Reboot		

Reboot Now

Config Scheduled Reboot

Schedule No.1

Status	Enable ▼
Type	Reboot Daily ▼
Time	01 ▼ : 01 ▼

Schedule No.2

Status	Enable ▼
Type	Reboot Weekly ▼
Days	1, (Example:1,2,3...)
Time	01 ▼ : 01 ▼

Schedule No.3

Status	Enable ▼
Type	Reboot Monthly ▼
Days	6, (Example:1,2,3...)
Time	01 ▼ : 01 ▼

Image 4-1-7: System > Reboot


Status	
Enable or disable the Scheduled Reboot.	<div>Values (selection)</div> <div>Enable / Disable</div>
Type	
Set the reboot schedule to reboot the modem once a day, week or month at a time and date specified below.	<div>Values (selection)</div> <div>Reboot Daily Reboot Weekly Reboot Monthly</div>
Days / Time	
When set to Weekly, set the day (1 is Sunday, 7 is Saturday) in which to reboot the modem. In a monthly configuration it is simply the date of the month (1 to 31). Once the day or date has been selected, specify the time (24hr clock) in which to initiate the scheduled reboot.	<div>Values</div> <div>(varies)</div>

4.0 Configuration

4.2 Network

4.2.1 Network > Status

The Network Summary display gives a overview of the currently configured network interfaces including the Connection Type (Static/DHCP), IP Address, Net Mask, Default Gateway, DNS, and IPv4 Routing Table.



Network Status

LAN Port Status

General Status			
IP Address	Connection Type	Subnet Mask	MAC Address
192.168.168.1	static	255.255.255.0	00:0F:92:02:AA:15

Traffic Status			
Receive bytes	Receive packets	Transmit bytes	Transmit packets
355.176KB	3849	857.981KB	3322

WAN Port Status

General Status			
IP Address	Connection Type	Subnet Mask	MAC Address
N/A	dhcp	N/A	00:0F:92:03:AA:15

Traffic Status			
Receive bytes	Receive packets	Transmit bytes	Transmit packets
0B	0	0B	0

Default Gateway

Gateway
192.168.168.1

DNS

DNS Server(s)
None

IPv4 Routing Table

Destination	Gateway	Subnet Mask	Flags	Metric	Ref	Use	Interface
0.0.0.0	192.168.168.1	0.0.0.0	UC	0	0	0	(br-lan)
192.168.168.0	0.0.0.0	255.255.255.0	U	0	0	0	(br-lan)

[Stop Refreshing](#) | Interval: 20 (in seconds)


Image 4-2-1: Network > Network Status

4.0 Configuration

4.2.2 Network > LAN

LAN Port Configuration

The LAN Ethernet port(s) on the pMDDL are for connection of devices on a local network. By default, this port has a static IP Address. It also, by default is running a DHCP server to provide IP Addresses to devices that are connected to the physical LAN port (directly or via a switch).




No.	Name	Static IP Address	Connection Type	DHCP Server	Config
1	LAN	192.168.168.1	static	On	Edit
2	usb	N/A	static	Off	Remove Edit

[Add](#)

Image 4-2-2: Network > Network LAN Configuration

LAN Add/Edit Interface

By selecting the Add or Edit buttons the LAN network interface can be configured, or additional LAN interfaces can be created.



Spanning Tree (STP) ☐ Off

IGMP Snooping ☐ On

Connection Type Static IP

IP Address 192.168.168.1

Netmask 255.255.255.0

Default Gateway 192.168.168.1

Default Route ☐ Yes

DNS Mode Manual

Primary DNS

Secondary DNS

Image 4-2-3: Network > LAN Port Configuration



DHCP: Dynamic Host Configuration Protocol may be used by networked devices (Clients) to obtain unique network addresses from a DHCP server.

Advantage:
Ensures unique IP addresses are assigned, from a central point (DHCP server) within a network.

Disadvantage:
The address of a particular device is not 'known' and is also subject to change.

STATIC addresses must be tracked (to avoid duplicate use), yet they may be permanently assigned to a device.



Within any IP network, each device must have its own unique IP address.

Spanning Tree (STP)

Values (selection)

Off
On

This option allows the pMDDL to participate in the Spanning Tree protocol with other devices to prevent local loops. By default this is disabled.

4.0 Configuration



The factory default network settings:

IP: 192.168.168.1
Subnet: 255.255.255.0
Gateway: 192.168.168.1



A SUBNET MASK is a bit mask that separates the network and host (device) portions of an IP address.

The 'unmasked' portion leaves available the information required to identify the various devices on the subnet.



A GATEWAY is a point within a network that acts as an entrance to another network.

In typical networks, a router acts as a gateway.



Within any IP network, each device must have its own unique IP address.

IGMP Snooping

Enable or disable IGMP snooping on the pMDDL. **IGMP snooping** is the process of listening to Internet Group Management Protocol traffic. This allows the pMDDL to listen in on the **IGMP** conversations between network devices. The pMDDL then maintains a map of which links need which IP multicast streams.

Values (selection)

On
Off

Connection Type

This selection determines if the pMDDL will obtain an IP address from a DHCP server on the attached network, or if a static IP address will be entered. If a Static IP Address is chosen, the fields that follow must also be populated.

Values (selection)

DHCP
Static

IP Address

If 'Static' Connection Type is selected, a valid IPv4 Address for the network being used must be entered in the field. If 'DHCP' is chosen this field will not appear and it will be populated automatically from the DHCP server.

Values (IP Address)

192.168.168.1

Netmask

If 'Static' Connection Type is selected, the Network Mask must be entered for the Network. If 'DHCP' is chosen this field will not appear and it will be populated automatically from the DHCP server.

Values (IP Address)

255.255.255.0

Default Gateway

If the pMDDL is integrated into a network which has a defined gateway, then, as with other hosts on the network, this gateway's IP address will be entered into this field. If there is a DHCP server on the network, and the Connection Type (see previous page) is selected to be DHCP, the DHCP server will populate this field with the appropriate gateway address.

Values (IP Address)

(no default)

A simple way of looking at what the gateway value should be is: If a device has a packet of data it does not know where to send, send it to the gateway. If necessary - and applicable - the gateway can forward the packet onwards to another network.

DNS

Set the DNS (Domain Name Server) for use by devices on the LAN port, if required.

Values (IP Address)

(no default)

4.0 Configuration

LAN DHCP

A pMDDL may be configured to provide dynamic host control protocol (DHCP) service to all attached (either wired or wireless devices. By default the DHCP service is enabled, so devices that are connected to the physical Ethernet LAN ports, as well as any devices that are connected by Wireless will be assigned an IP by the pMDDL. The LAN DHCP service is available for each interface, and is located in the add/edit interface menus.




Image 4-2-4: Network > DHCP Server

DHCP Server

The option is used to enable or disable the DHCP service for devices connected to the LAN Port(s).

Values (selection)

Enable / Disable

Start

Select the starting address DHCP assignable IP Addresses. The first octets of the subnet will be pre-set based on the LAN IP configuration, and can not be changed.

Values (IP Address)

192.168.168.100

Limit

Set the maximum number of IP addresses that can be assigned by the pMDDL.

Values (integer)

150

Lease Time

The DHCP lease time is the amount of time before a new request for a network address must be made to the DHCP Server.

Values (minutes)

720

Alternate Gateway

Specify an alternate gateway for DHCP assigned devices if the default gateway is not to be used.

Values (IP Address)

(IP Address)



Prior to enabling this service, verify that there are no other devices - either wired (e.g. LAN) or wireless with an active DHCP SERVER service. (The Server issues IP address information at the request of a DHCP Client, which receives the information.)



Being that the Internet is based on IP addresses, without DNS, if one entered the domain name `www.microhardcorp.com` (for example) into the URL line of a web browser, the website 'could not be found').

(IP Address)

(IP Address)

(IP Address)

(no default)

- none**
- b-node
- p-node
- m-node
- h-node

4.0 Configuration

4.2.3 Network > WAN

WAN Configuration

The WAN configuration refers to the wired WAN connection on the pMDDL. The WAN port can be used to connect the pMDDL to other networks, the internet and/or other network resources.

System	Network	Wireless	Firewall	Serial	Diag	Admin
Status	LAN	WAN	USB	DHCP	Routes	Ports
WAN Port Configuration						
Configuration						
Working Mode		Independent WAN				
WAN Configuration						
Connection Type		Static IP				
IP Address						
Subnet Mask						
Default Route		Yes				
Default Gateway						
DNS Mode		Manual				
Primary DNS						
Secondary DNS						

Image 4-2-6: Network > WAN Configuration



DHCP: Dynamic Host Configuration Protocol may be used by networked devices (Clients) to obtain unique network addresses from a DHCP server.

Advantage:
Ensures unique IP addresses are assigned, from a central point (DHCP server) within a network.

Disadvantage:
The address of a particular device is not 'known' and is also subject to change.

STATIC addresses must be tracked (to avoid duplicate use), yet they may be permanently assigned to a device.

Working Mode

Use this to set the function of the physical WAN port. If set to independent WAN, the physical WAN port will operate as a standard WAN port. Alternatively it can be configured to be bridged to the LAN, and operate as a second LAN port, or even as an independent LAN.

Values (selection)

Independent WAN
Bridged with LAN Port
Independent LAN

Connection Type

This selection determines if the pMDDL will obtain an WAN IP address from a DHCP server, or if a static IP address will be entered. If a Static IP Address is chosen, the fields that follow must also be populated.

Values (selection)

DHCP
Static

IP Address

If 'Static' Connection Type is selected, a valid IPv4 Address for the network being used must be entered in the field. If 'DHCP' is chosen this field will not appear and it will be populated automatically from the DHCP server.

Values (IP Address)

(no default)

Netmask

If 'Static' Connection Type is selected, the Network Mask must be entered for the Network. If 'DHCP' is chosen this field will not appear and it will be populated automatically from the DHCP server.

Values (IP Address)

(no default)

4.0 Configuration

4.2.4 Network > USB

USB Port Configuration

Normally, the pMDDL module is bootstrapped to USB host mode that allows select generic devices to be used to extend Ethernet and serial functions (USB to Ethernet Adapters, USB to Serial Converters).

Alternatively, the pMDDL can be set to Device mode by pulling PIN 14 (on OEM module) low through an 1k resistor to switch the USB mode. Older development boards will not support this and will either need to be modified or new boards will need to be acquired. In USB device mode, there are two functions supported, RNDIS/CDC Ethernet and CDC Serial port, when connected a host machine (PC etc).

RDNIS Ethernet and CDC Serial composite drivers are available from Microhard Systems.

System	Network	Wireless	Firewall	Serial	Diag	Admin	
Status	LAN	WAN	USB	DHCP	Routes	Ports	Device List

USB Port Configuration

Configuration

Working Mode ⓘ Independent LAN ▼

LAN Configuration

Connection Type Static IP ▼

IP Address

Netmask

Default Gateway

Default Route No ▼

DNS Mode Manual ▼

Primary DNS

Secondary DNS

DHCP Server

Mode ⓘ Disable ▼

Image 4-2-7: Network > USB

Working Mode

The RNDIS Ethernet USB port can be configured to operate as an additional LEN Ethernet Port with the current LAN (Bridged) or it can be configured to operate as a independent LAN (Subnet).

Values (selection)

Independent LAN Bridge with LAN Port

LAN Configuration

When bridged with LAN the network parameters are set from the Network > LAN menu. When set to Independent the port can be configured as Static or DHCP. Again refer to the LAN configuration for help with the displayed fields and definitions.

DHCP Server

When in Independent mode the pMDDL can run a DHCP service on the USB port to assign IP addresses and lease information. Refer to Network > LAN > DHCP for help with parameters and definitions.

4.0 Configuration

4.2.5 Network > DHCP

Static IP Addresses (for DHCP Server)

In many applications it is required to know the IP address of connected devices in order to implement security and firewall rules as well as for Port Forwarding rules. The Static IP Address (for DHCP Server) features MAC binding to allow connected devices to automatically obtain a specific IP address.

For configuration of the LAN DHCP Service see Network > LAN > (Edit) > LAN DHCP.

System	Network	Wireless	Firewall	Serial	Diag	Admin
Status	LAN	WAN	USB	DHCP	Routes	Ports
Device List						

DHCP Configuration

Static IP addresses (for DHCP Server)

Name	<input type="text"/>
MAC Address	<input type="text"/>
IP Address	<input type="text"/>

Static Addresses

MAC Address	IP Address	Name	NetStatus

Active DHCP Leases

MAC Address	IP Address	Name	Expires in	
A6:12:20:F4:9A:0D	192.168.168.132	DMKT0002-2	9hr 59min 30sec	Release

Image 4-2-8: Network > DHCP

Static Addresses

Displays the MAC Binding table that is configured in the pMDDL device.

Active DHCP Leases

Displays the active DHCP leases for any IP Addresses that have been assigned. This includes the IP address, the MAC, Device Name as well as the lease expiry.

4.0 Configuration

4.2.6 Network > Routes

Static Routes Configuration

It may be desirable to have devices on different subnets to be able to talk to one another. This can be accomplished by specifying a static route, telling the pMDDL where to send data.



Static Routes Configuration

Add Static Route

Name	route1
Destination Subnet	192.168.168.0
Netmask	255.255.255.0
Gateway	192.168.168.1
Metric	0
Interface	LAN

Add Static Route

Static Route Summary

Name	Destination	Netmask	Gateway	Metric	Interface
------	-------------	---------	---------	--------	-----------

Image 4-2-9: Network > Routes

Name

Routes can be names for easy reference, or to describe the route being added.

Values (characters)

(no default)

Destination

Enter the network IP address for the destination.

Values (IP Address)

(192.168.168.0)

Gateway

Specify the Gateway used to reach the network specified above.

Values (IP Address)

192.168.168.1

Netmask

Enter the Netmask for the destination network.

Values (IP Address)

255.255.255.0

4.0 Configuration

4.2.7 Network > Ports

The Network > Ports menu can be used to determine the characteristics of the physical Ethernet interfaces on the pMDDL. As seen below the Mode (Auto/Manual), Auto-Negotiation, Speed (10/100Mbit/s) and the Duplex (Full/Half) can all be configured on the pMDDL.

System	Network	Wireless	Firewall	Serial	Diag	Admin
Status	LAN	WAN	USB	DHCP	Routes	Ports
Device List						

Ethernet Port Configuration

Port	Mode	Auto-Negotiation	Speed	Duplex
WAN	<input checked="" type="radio"/> Auto <input type="radio"/> Manual	<input checked="" type="radio"/> On <input type="radio"/> Off	<input checked="" type="radio"/> 100Mbit/s <input type="radio"/> 10Mbit/s	<input checked="" type="radio"/> Full <input type="radio"/> Half
LAN	<input checked="" type="radio"/> Auto <input type="radio"/> Manual	<input checked="" type="radio"/> On <input type="radio"/> Off	<input checked="" type="radio"/> 100Mbit/s <input type="radio"/> 10Mbit/s	<input checked="" type="radio"/> Full <input type="radio"/> Half

Ethernet Port Status


Port	Linked 	Auto-Negotiation	Speed	Duplex
WAN	no	on	10Mb/s	Half
LAN	no	on	10Mb/s	Half

Image 4-2-10: Network > Ports

Mode

If set to Auto, the pMDDL will negotiate and determine the best connection speed and mode.

Values (selection)

Auto / Manual

Auto-Negotiation

Enable or disable auto-negotiation.

Values (selection)

On / Off

Speed

If the mode and auto negotiation are set you manual the connection speed can be specified.

Values (selection)

100Mbit/s / 10 Mbit/s

Duplex

Selection between full or half duplex for the direction of data.

Values (selection)

Full / Half

4.0 Configuration

4.2.8 Network > Device List

The Network > Device List shows the current ARP table for the local network adapter. The MAC address and IP address are shown, however not only DHCP assigned devices are listed in the device list, any devices, even those statically assigned, that are connected through the local network interface (s) are displayed, including those connected through a hub or switch.

Devices can also be filtered by the network that they are attached to. Devices with a MAC and no IP and vice versa can also be filtered.



Image 4-2-11: Network > Device List

4.0 Configuration

4.3 Wireless

4.3.1 Wireless > Status

The Status window gives a summary of all radio or wireless related settings and connections.

The **General Status** section shows the MAC address of the current radio, the Operating Mode (Master, Slave etc), the Network ID being used, the Compatibility Mode, Channel Bandwidth and frequency information and the type of security used.

Traffic Status shows statistics about the transmitted and received data.

The pMDDL shows information about all Wireless connections in the **Connection Info** section. The MAC address, TX & RX Modulation, Signal to Noise ratio (SNR), Signal Strength (RSSI), and a graphical representation of the signal level or quality, as well as a RSSI Graph Link.




Image 4-3-1: Wireless > Status (RSSI Graph Shown Below)

4.0 Configuration



Refer to FCC (or as otherwise applicable) regulations to ascertain, and not operate beyond, the maximum allowable transmitter output power and effective isotropic radiated power (EIRP).

Select the channel bandwidth from the list. Refer to the specifications to see the relationship and performance between channel bandwidth, throughput and sensitivity.

Generally a larger channel has greater throughput, at the cost of sensitivity, while a smaller channel tends to be more robust, but at the cost of throughput.

Channel Bandwidth

Values (selection)

8 / 4 MHz

Channel-Frequency

Values (MHz)

pMDDL2350: 2304 - 2390 MHz
pMDDL2450: 2405 - 2479 MHz
pMDDL2550: 2500 - 2570 MHz

Set the Channel-Frequency. This must be the same on each unit in a network. The frequency shown is the center frequency and is available in 1 MHz increments, values shown will vary with the Channel Bandwidth selected above.

The noise floor of the specified channel will dramatically affect the quality of the link, it is essential to select the cleanest channel for superior performance.

TX Power

Values (selection)

This setting establishes the transmit power level which will be presented to the antenna connector(s) of the pMDDL.

Unless required, the Tx Power should be set not for maximum, but rather for the minimum value required to maintain an adequate system fade margin.

TX Power reflects the Total RF power for the pMDDL. In MIMO mode this means that the total RF power is split between antenna interfaces. When MIMO is disabled a total of 30 dBm can be presented to the ANT 1 Antenna.

20 dBm	25 dBm
21 dBm	26 dBm
22 dBm	27 dBm
23 dBm	28 dBm
24 dBm	29 dBm
	30 dBm

Wireless Distance

Values (meters)

The Wireless Distance parameter allows a user to set the expected distance the wireless signal needs to travel. The pMDDL sets various internal timeouts to account for this travel time. Longer distances will require a higher setting, and shorter distances may perform better if the setting is reduced.

3000

MIMO

Values (selection)

MIMO (2X2) features of the pMDDL can be enabled or disabled using this parameter. Disabling MIMO allows up to 30dBm to be presented to ANT1 connector. When MIMO is disabled all communication is through ANT 1.

ON / OFF

4.0 Configuration

		Mode
Master	- A Master may provide a wireless data connection to many slaves/remotes.	Values (selection) Master Slave Relay (Future)
Slave/Remote	- A Slave may sustain one wireless connection, i.e. to an Master.	

For video applications it is required to connect the video source (camera) to the radio designated as the Master. Video receivers would then be connected to the Slave radios, this would allow for multiple viewing stations. See the diagram below for an example.




Diagram 4-3-1: Operating Modes

For multicast traffic sending from the Master to multiple receivers, it is recommended to configure the system with “Extended Addressing” disabled and also select a proper multicast rate defined by the link budget. In this case, the multicast traffic will be delivered on the specified RF rate to multiple receivers without adding extra overhead to the RF link. Devices on the Slaves side just need to subscribe the multicast address being used by the transmitting device connected on the Master side.

TX Rate	
<p>This setting determines the modulation type and in turn the rate at which the data is to be wirelessly transferred.</p> <p>The default and recommended setting for both Master and Slave units is 'Auto'. When in 'Auto' the unit will transfer data at the highest possible rate in consideration of the receive signal strength (RSSI).</p> <p>Refer to Section 1.3 Performance Specifications for a table breakdown of performance at selected rates. If setting a fixed TX Rate It is recommended to retain a fade margin of at least 10 dBm for optimum performance. For example, for a link (8MHz channel) with a signal strength of at least -75dBm, a TX rate of 16-QAM 3/4 FEC is recommended. Setting to the highest rate with a poor link may result in reduced performance.</p>	<p>Values (selection)</p> <p>Auto (recommended)</p> <p>64-QAM 5/6 FEC</p> <p>64-QAM 3/4 FEC</p> <p>64-QAM 2/3 FEC</p> <p>16-QAM 3/4 FEC</p> <p>16-QAM 1/2 FEC</p> <p>QPSK FEC 3/4</p> <p>QPSK FEC 1/2</p>

4.0 Configuration



Change the default value for the Network ID to something unique for your network. Do this for an added measure of security and to differentiate your network from others which may be operating nearby.

Extended Addressing

Enable or disable extended addressing.

For multicast traffic sending from the Master to multiple receivers, it is recommended to configure the system with “Extended Addressing” disabled and also select a proper multicast rate defined by the link budget. In this case, the multicast traffic will be delivered on the specified RF rate to multiple receivers without adding extra overhead to the RF link. Devices on the Slaves side just need to subscribe the multicast address being used by the transmitting device connected on the Master side.

Values (selection)

On / Off

Network ID

Each network of pMDDL modules must have a unique Network ID. This Network ID must be set in each unit on the network.

Values

pMDDL

Encryption Type

The encryption types defines the type of security used for the Wireless Interface, to join a network a device must know the correct Encryption Key. Security options are dependent on the version type. Export versions may not have all optional available to meet regulatory requirements set government policies.

Values (selection)

Disabled
AES-128

Encryption Key

This is the password, or preshared key that is required by any device to connect to the wireless interface of the pMDDL. It is **strongly recommended** to always have a password defined, and changed from the factory default.

Values (string)

1234567890

Show Password

Check this box to show the currently configured password for the encryption passphrase.

Values (selection)

unchecked

Comport Tx Rate

When using Ethernet and Serial data. If the volume of serial data is high, leave at the default (Normal Rate), if the volume of Ethernet data is high set com data to High Rate (Compressed).

Values (selection)

Normal / High

4.0 Configuration

4.4.2 Firewall > General

The General Firewall settings allow users to enable or disable the firewall, and to decide which areas of the modem to protect. The Firewall can also be reset to factory defaults from this area of the WebUI.

System	Network	Wireless	Firewall	Serial	Diag	Admin
Summary	General	Port Forwarding	MAC-IP List	Rules	Firewall Default	

Firewall General

Firewall General Configuration

WAN Remote Management ⓘ

☒ Enable
☐ Disable

WAN Request ⓘ

☒ Block
☐ Allow

LAN to WAN Access Control ⓘ

☐ Block
☒ Allow

Anti-Spoof ⓘ

☐ Enable
☒ Disable

Packet Normalization ⓘ

☐ Enable
☒ Disable

Image 4-4-2: Firewall > General

WAN Remote Management

Allow remote management of the pMDDL on the WAN side using the WebUI on port 80(HTTP), and 443 (HTTPS). If disabled, the configuration can only be accessed from the LAN.

Values

Enable / Disable

WAN Request

When Blocked the pMDDL will block all requests from devices on the WAN unless specified otherwise in the Access Rules, MAC List, IP List configurations. Access to ports 80 (HTTP) and 443 (HTTPS-if enabled), is still available unless disabled in the **WAN Remote Management** option.

Values

Block / Allow

LAN to WAN Access Control

Allows or Blocks traffic from the LAN accessing the WAN unless specified otherwise using the Access Rules, MAC, and IP List configuration.

Values

Block / Allow

Anti-Spoof

The Anti-Spoof protection is to create some firewall rules assigned to the external interface (WAN) of the firewall that examines the source address of all packets crossing that interface coming from outside. If the address belongs to the internal network or the firewall itself, the packet is dropped.

Values

Enable / Disable

Packet Normalization

Packet Normalization is the normalization of packets so there are no ambiguities in interpretation by the ultimate destination of the packet. The scrub directive also reassembled fragmented packets, protecting some operating systems from some forms of attack, and drops TCP packets that have invalid flag combinations.

Values

Enable / Disable

4.0 Configuration

4.4.3 Firewall > Port Forwarding

The pMDDL can be used to provide remote access to connected devices. To access these devices a user must define how incoming traffic is handled by the pMDDL. If all incoming traffic is intended for a specific connected device, DMZ could be used to simplify the process, as all incoming traffic can be directed towards a specific IP address.

In the case where there is multiple devices, or only specific ports need to be passed, Port forwarding is used to forward traffic coming in from the WAN to specific IP Addresses and Ports on the LAN. Port forwarding can be used in combination with other firewall features, but the Firewall must be enabled for Port forwarding to be in effect. If the WAN Request is blocked on the General Tab, additional rules and/or IP Lists must be set up to allow the port forwarding traffic to pass through the firewall.

SystemNetworkWirelessFirewallSerialDiagAdmin

SummaryGeneralPort ForwardingMAC-IP ListRulesFirewall Default

Firewall Port Forwarding

Notice

Port Forwarding Rules are taken into consideration after the General firewall settings are applied. If the WAN traffic is blocked, additional rules must be created:
1. Add rules in the Rules configuration to open ports or allow IP addresses.
2. Create a firewall rule in the Firewall->Rules page to allow desired connections.

Firewall DMZ Configuration

DMZ Source: WAN

DMZ Mode

DMZ Server IP

Exception Ports

Combined with source NAT

Firewall Port Forwarding Configuration

Name

Source

Internal Server IP

Internal Ports

Protocol

External Ports

Combined with source NAT

Add Port Forwarding

Firewall Port Forwarding Summary

Name	Source	Internal IP	Internal Port	Protocol	External Port	SNAT
------	--------	-------------	---------------	----------	---------------	------



If DMZ is enabled and an exception port for the WebUI is not specified, remote management will not be possible. The default port for remote management is TCP 80.

Image 4-4-3: Firewall > Port Forwarding

DMZ Mode	
Enable or disable DMZ Mode. DMZ can be used to forward all traffic to the DMZ Server IP listed below.	Values (selection) Disable / Enable
DMZ Server IP	
Enter the IP address of the device on the LAN side of the pMDDL where all the traffic will be forwarded to.	Values (IP Address) 192.168.100.100

4.0 Configuration

Firewall MAC List Configuration (Continued)

Action
<p>The Action is used to define how the rule handles the connection request.</p> <p>ACCEPT will allow a connection, while REJECT (error) and DROP (quietly dropped), will refuse connections.</p>
Values (selection) ACCEPT DROP REJECT

Firewall IP List Configuration

Rule Name
<p>The Rule Name field is required to give the rule a convenient name for reference. Each rule must have a unique name, up to 10 characters in length.</p>
Values (10 chars) IP_List

Action
<p>The Action is used to define how the rule handles the connection request. ACCEPT will allow a connection, while REJECT (error) and DROP (quietly dropped), will refuse connections.</p>
Values (selection) ACCEPT / DROP / REJECT

Source
<p>Enter the specific zone that the IP List will apply to, LAN, WAN or None (both).</p>
Values (Selection) LAN/LAN1/WAN/USB NONE

Source IP Address
<p>Match incoming traffic from the specified source IP range. Boxes accept single IP Addresses without network masks, example: 192.168.1.0 to 192.168.1.255 represents all IP Addresses in the 192.168.1.0/24 network. (Put same IP in both boxes for a single IP match.)</p>
Values (IP Address) 192.168.0.0

Destination Address
<p>Match incoming traffic from the specified destination IP range. Boxes accept single IP Addresses without network masks, example: 192.168.1.0 to 192.168.1.255 represents all IP Addresses in the 192.168.1.0/24 network. (Put same IP in both boxes for a single IP match.)</p>
Values (IP Address) 192.168.0.0

4.0 Configuration

4.4.5 Firewall > Rules

The Rules configuration can be used to define specific rules on how local and remote devices access different ports and services. MAC List and IP List are used for general access, and are applied before rules are processed.

It is highly recommended to block as much traffic as possible from the modem, especially when using a public IP address. The best security would be to allow traffic only from trusted IP addresses, and only the specific ports being used, and block everything else. Not configuring the firewall and the firewall rules correctly could result in unpredictable data charges from your provider.




Image 4-4-5: Firewall > Rules

Rule Name

The rule name is used to identify the created rule. Each rule must have a unique name and up to 10 characters can be used.

Values (10 Chars)

characters

Action

The Action is used to define how the rule handles the connection request.

Values (selection)

ACCEPT will allow a connection, while REJECT (error) and DROP (quietly dropped), will refuse connections.

ACCEPT
DROP
REJECT

This is configured based on how the **WAN Request** and **LAN to WAN Access Control** are configured in the previous menus.

Source

Select the zone which is to be the source of the data traffic. The LAN/WAN refers to local connections on the pMDDL.

Values

LAN/WAN/Independent
LAN/None

4.0 Configuration

Source IPs	
Match incoming traffic from the specified source IP range. Boxes accept single IP Addresses without network masks, example: 192.168.1.0 to 192.168.1.255 represents all IP Addresses in the 192.168.1.0/24 network. (Put same IP in both boxes for a single IP match.)	Values (IP Address) 192.168.0.0 to 192.168.0.0
Destination	
Select the zone which is the intended destination of the data traffic. The selections shown will reflect any network interfaces configured.	Values (selection) LAN/WAN/None <i>(varies)</i>
Destination IPs	
Match incoming traffic from the specified destination IP range. Boxes accept single IP Addresses without network masks, example: 192.168.1.0 to 192.168.1.255 represents all IP Addresses in the 192.168.1.0/24 network. (Put same IP in both boxes for a single IP match.)	Values (IP Address) 192.168.0.0 to 192.168.0.0
Destination Port	
Match incoming traffic directed at the given destination port or port range. (To specify a port range use a From:To (100:200) format)	Values (port) 0
Protocol	
The protocol field defines the transport protocol type controlled by the rule.	Values TCP UDP Both ICMP

4.0 Configuration

4.4.6 Firewall > Default

The firewall can be returned to default setting without requiring the entire modem to be reset to defaults. It is recommended to restart the modem once changes to the firewall or a reset is performed.



Image 4-4-6: Firewall > Default

4.0 Configuration

4.5 Serial

4.5.1 Serial > Summary


The Serial > Summary window gives a summary of the on board serial data port. A second serial port can be added to the pMDDL OEM by interfacing a FTDI USB to Basic UART IC as shown in **Appendix D: Serial Port Extension**.

GS0 - If the pMDDL has been set to USB Device mode (Pin 14 connected to GND through a 1K resistor), the GS0 tab will appear and the USB port can be used to connect to a USB host that has the Microhard Composite Drivers installed. The USB port will appear as a serial device on the host system.

The Summary window shows a number of status items that aid in viewing the operation, statistics, and troubleshooting of the RS232 & USB Serial Ports.

General Status

- Port Status - Shows if the RS232 has been enabled in the configuration.
- Baud Rate - The current baud rate used to interface with the connected device.
- Connect As - The type of IP Protocol Config is displayed here (TCP, UDP, SMTP, PPP, etc)
- Connect Status - Shows if there are any current connections / if the port is active.



Port	Status	Baud Rate	Connect As	Connect Status	Receive bytes	Receive packets	Transmit bytes	Transmit packets
RS232	Enable	115200	TCP Server	Not Active	0 B	0	0 B	0
GS0	Enable	115200	TCP Server	Not Active	0 B	0	0 B	0


Stop Refreshing Interval: 20 (in seconds)

Image 4-5-1: Serial > Summary

4.0 Configuration

4.6.2 Serial > Settings

This menu option is used to configure the serial device server for the serial communications port. Serial device data may be brought into the IP network through TCP, UDP, or multicast; it may also exit the pMDDL network on another pMDDL serial port. The fully-featured RS232 interface supports hardware



The screenshot shows the 'Serial Port Configuration' web interface. At the top, there is a navigation bar with tabs for System, Network, Wireless, Firewall, Serial, Diag, and Admin. Below this is a sub-navigation bar with Status, Settings, and GSO. The main content area is titled 'Serial Port Configuration' and contains two sections: 'Port Configuration' and 'TCP Configuration'.

Port Configuration

Port status	Data ▼
Escape Sequence	Disabled ▼
Data Baud Rate	115200 ▼
Data Format	8N1 ▼
Data Mode ⓘ	<input type="radio"/> Seamless <input checked="" type="radio"/> Transparent
Character Timeout	24
Maximum Packet Size	256
No-Connection Data ⓘ	<input type="radio"/> Disable <input checked="" type="radio"/> Enable
MODBUS TCP Status	<input checked="" type="radio"/> Disable <input type="radio"/> Enable
IP Protocol Config	TCP Server ▼

TCP Configuration

Server Mode	<input checked="" type="radio"/> Monitor <input type="radio"/> Polling
Polling Timeout (seconds)	10
Local Listening port	20002
Incoming Connection Timeout(seconds)	300
Fast Recovery ⓘ	<input checked="" type="radio"/> Disable <input type="radio"/> Enable

Image 4-5-2: Serial > Settings Configuration

4.0 Configuration



Note: Most PCs do not readily support serial communications greater than 115200bps.

Port Status																			
Select operational status of the Serial Port. The port is in console mode by default.	Values (selection) Data / Console																		
Escape Sequence																			
Enabling the escape sequence allows users to temporarily exit data mode and enter console mode for the serial port.	Values (selection) Enabled / Disabled																		
Escape Guard Interval																			
Appears only when the Escape Sequence is enabled. Enter the time interval in which the escape sequence must be entered fully.	Values (seconds) 1																		
Escape Sequence String																			
Only shown when the escape sequence is enabled. Enter the characters to be used for the escape sequence.	Values (characters) +++																		
Data Baud Rate																			
The serial baud rate is the rate at which the modem is to communicate with the attached local asynchronous device.	Values (bps) <table border="0"> <tr> <td>921600</td> <td>9600</td> </tr> <tr> <td>460800</td> <td>7200</td> </tr> <tr> <td>230400</td> <td>4800</td> </tr> <tr> <td>115200</td> <td>3600</td> </tr> <tr> <td>57600</td> <td>2400</td> </tr> <tr> <td>38400</td> <td>1200</td> </tr> <tr> <td>28800</td> <td>600</td> </tr> <tr> <td>19200</td> <td>300</td> </tr> <tr> <td>14400</td> <td></td> </tr> </table>	921600	9600	460800	7200	230400	4800	115200	3600	57600	2400	38400	1200	28800	600	19200	300	14400	
921600	9600																		
460800	7200																		
230400	4800																		
115200	3600																		
57600	2400																		
38400	1200																		
28800	600																		
19200	300																		
14400																			
Data Format																			
This setting determines the format of the data on the serial port. The default is 8 data bits, No parity, and 1 Stop bit.	Values (selection) 8N1 8E1 8O1																		

4.0 Configuration

IP Protocol Config

This setting determines which protocol the serial server will use to transmit serial port data over the pMDDL network.

The protocol selected in the IP Protocol Config field will determine which configuration options appear in the remainder of the RS232 Configuration Menu.

Values (selection)

TCP Client
TCP Server
TCP Client/Server
UDP Point-to-Point
PPP (Not supported on USB)

TCP Client: When TCP Client is selected and data is received on its serial port, the pMDDL takes the initiative to find and connect to a remote TCP server. The TCP session is terminated by this same unit when the data exchange session is completed and the connection timeout has expired. If a TCP connection cannot be established, the serial port data is discarded.



UDP: User Datagram Protocol does not provide sequencing information for the packets sent nor does it establish a 'connection' ('handshaking') and is therefore most suited to communicating small packets of data.

- **Remote Server Address**
IP address of a TCP server which is ready to accept serial port data through a TCP connection. For example, this server may reside on a LAN network server.
Default: **0.0.0.0**
- **Remote Server Port**
A TCP port which the remote server listens to, awaiting a session connection request from the TCP Client. Once the session is established, the serial port data is communicated from the Client to the Server.
Default: **20001**
- **Outgoing Connection Timeout**
This parameter determines when the pMDDL will terminate the TCP connection if the connection is in an idle state (i.e. no data traffic on the serial port).
Default: **60** (seconds)
- **Fast Recovery**
Sets the TCP session parameters and buffers to be set such that TCP sessions recover faster in environments where the wireless link is weak/unstable. This is ideal for critical, near real time applications such as flight control data. Data is not buffered during outages.
Default: **Disable**



TCP: Transmission Control Protocol in contrast to UDP does provide sequencing information and is connection-oriented; a more reliable protocol, particularly when large amounts of data are being communicated.

Requires more bandwidth than UDP.

TCP Server: In this mode, the pMDDL Series will not INITIATE a session, rather, it will wait for a Client to request a session of it (it's being the Server—it 'serves' a Client). The unit will 'listen' on a specific TCP port. If a session is established, data will flow from the Client to the Server, and, if present, from the Server to the Client. If a session is not established, both Client-side serial data, and Server-side serial data, if present, will be discarded.

- **Local Listening Port**
The TCP port which the Server listens to. It allows a TCP connection to be created by a TCP Client to carry serial port data.
Default: **20001**
- **Incoming Connection Timeout**
Established when the TCP Server will terminate the TCP connection is the connection is in an idle state.
Default: **300** (seconds)
- **Fast Recovery**
Sets the TCP session parameters and buffers to be set such that TCP sessions recover faster in environments where the wireless link is weak/unstable. This is ideal for critical, near real time applications such as flight control data. Data is not buffered during outages.
Default: **Disable**

4.0 Configuration



A UDP or TCP port is an application end-point. The IP address identifies the device and, as an extension of the IP address, the port essentially 'fine tunes' where the data is to go 'within the device'.

Be careful to select a port number that is not predetermined to be associated with another application type, e.g. HTTP uses port 80.

IP Protocol Config (Continued...)

TCP Client/Server: In this mode, the pMDDL will be a combined TCP Client and Server, meaning that it can both initiate and serve TCP connection (session) requests. Refer to the TCP Client and TCP Server descriptions and settings described previously as all information, combined, is applicable to this mode.

UDP Point-to-Point: In this configuration the pMDDL will send serial data to a specifically-defined point, using UDP packets. This same pMDDL will accept UDP packets from that same point.

- **Remote IP Address**
IP address of distant device to which UDP packets are sent when data received at serial port.
Default: **0.0.0.0**
- **Remote Port**
UDP port of distant device mentioned above.
Default: **20001**
- **Listening Port**
UDP port which the IP Series listens to (monitors). UDP packets received on this port are forwarded to the unit's serial port.
Default: **20001**
- **UDP Timeout(s)**
UDP Timeout in seconds.
Default: **10**

4.0 Configuration

IP Protocol Config (Continued...)

PPP: The serial port can be configured as a PPP server for a serial connection with a PC or other device. The attached PC could then use a dedicated serial (WindowsXP - dialup/modem) type PPP connection to access the network resources of the pMDDL.


- **PPP Mode**
Can be set for Active or Passive. If set for Active, the PPP server will initiate the PPP connection with a PPP client. The server will periodically send out link requests following PPP protocol. If set to Passive, the PPP server will not initiate the PPP connection with PPP client. The server will wait passively for the client to initiate connection.
Default: **Passive**
- **Expected String**
When a client (PC or device) initiates a PPP session with the modem, this is the handshaking string that is expected in order to allow a connection. Generally this does not need to be changed.
Default: **CLIENT**
- **Response String**
This is the handshaking string that will be sent by the modem once the expected string is received. Generally this does not need to be changed.
Default: **CLIENTSERVER**
- **PPP LCP Echo Failure Number**
The PPP server will presume the peer to be dead if the LCP echo-requests are sent without receiving a valid LCP echo-reply. If this happens, PPP server will terminate the connection. Use of this option requires a non-zero value for the LCP Echo Interval parameter. This option can be used to enable PPP server to terminate after the physical connection has been broken (e.g., the modem has hung up).
Default: **0**
- **PPP LCP Echo Interval**
The PPP server will send an LCP echo-request frame to the peer every 'n' seconds. Normally the peer should respond to the echo-request by sending an echo-reply. This option can be used with the LCP-echo-failure option to detect that the peer is no longer connected.
Default: **0**
- **PPP Local IP**
Enter the local PPP IP Address, the IP Address of the pMDDL COM Port.
Default: **192.168.0.1**
- **PPP Host IP**
Enter the PPP Host IP here. This is the IP of the PC or attached device.
Default: **192.168.0.99**
- **PPP Idle Timeout(s)**
It is the timeout for tearing down the ppp connection when there is no data traffic within the time interval. When there is data coming, new ppp connection will be created.
Default: **30**

4.0 Configuration

4.6.3 Serial > GS0

This tab only appears if the pMDDL has been set to operate as a USB Device (Pin 14 connected to GND through a 1k resistor). Microhard USB Serial Composite Drivers are available which allow the pMDDL to appear as a serial device to a USB Host (PC etc.)

The USB port can be set to "Idle" or to operate as a Data port as seen below:



The screenshot shows the Microhard pMDDL configuration interface. The top navigation bar includes tabs for System, Network, Wireless, Firewall, Serial, Diag, and Admin. The 'Serial' tab is selected, and the 'GS0' sub-tab is active. The main content area is titled 'GS0 Serial Port Configuration' and is divided into two sections: 'Port Configuration' and 'TCP Configuration'.

Port Configuration:

- Port status: Data (dropdown)
- Data Baud Rate: 115200 (dropdown)
- Data Format: 8N1 (dropdown)
- Flow Control: none (dropdown)
- Data Mode: ☒ Seamless ☐ Transparent
- Character Timeout: 24 (text input)
- Maximum Packet Size: 256 (text input)
- No-Connection Data: ☐ Disable ☒ Enable
- MODBUS TCP Status: ☒ Disable ☐ Enable
- IP Protocol Config: TCP Server (dropdown)

TCP Configuration:

- Server Mode: ☒ Monitor ☐ Polling
- Polling Timeout (seconds): 10 (text input)
- Local Listening port: 20003 (text input)
- Incoming Connection Timeout(seconds): 300 (text input)
- Fast Recovery: ☒ Disable ☐ Enable

Image 4-5-2: Serial > Settings Configuration

GS0 Serial Port Configuration

The USB port configuration is identical to the Serial Port > Settings parameters. For help or definitions of each field, refer to the previous section of this manual which describes the available settings.

4.0 Configuration

4.6 Diag

4.6.1 Diag > Ping

The Network Tools Ping feature provides a tool to test network connectivity from within the pMDDL unit. A user can use the Ping command by entering the IP address or host name of a destination device in the Ping Host Name field, use Count for the number of ping messages to send, and the Packet Size to modify the size of the packets sent.

System	Network	Wireless	Firewall	Serial	Diag	Admin
<div> <div>Ping</div> <div>Traceroute</div> <div>Iperf</div> <div>USB Tethering</div> </div>						
<p>Network Tools</p> <p>Ping</p> <p>Ping Host Name <input type="text" value="192.168.168.141"/></p> <p>Ping Count <input type="text" value="4"/> (0 = continuous)</p> <p>Ping Size <input type="text" value="56"/></p> <p><input type="button" value="Start"/> <input type="button" value="Stop"/> <input type="button" value="Clear"/></p> <pre> Please wait for output of "ping -c 4 -s 56 192.168.168.141"... PING 192.168.168.141 (192.168.168.141): 56 data bytes 13:10:35.548663 -- sending icmp request 64 bytes from 192.168.168.141: seq=0 ttl=128 time=4.112 ms 13:10:36.549214 -- sending icmp request 64 bytes from 192.168.168.141: seq=1 ttl=128 time=1.457 ms 13:10:37.549686 -- sending icmp request 64 bytes from 192.168.168.141: seq=2 ttl=128 time=1.770 ms 13:10:38.550206 -- sending icmp request 64 bytes from 192.168.168.141: seq=3 ttl=128 time=1.642 ms </pre>						

Image 4-6-1: Diagnostics > Ping

4.6.2 Diag > Traceroute

The **Traceroute** command can be used to provide connectivity data by providing information about the number of hops, routers and the path taken to reach a particular destination.

System	Network	Wireless	Firewall	Serial	Diag	Admin
<div> <div>Ping</div> <div>Traceroute</div> <div>Iperf</div> <div>USB Tethering</div> </div>						
<p>Network Tools</p> <p>Traceroute</p> <p>Traceroute Host Name <input type="text" value="192.168.168.141"/></p> <p><input type="button" value="Start"/> <input type="button" value="Stop"/> <input type="button" value="Clear"/></p> <pre> Begin traceroute test at 13:12:37... traceroute to 192.168.168.141 (192.168.168.141), 30 hops max, 38 byte packets 1 PaulH-Desktop (192.168.168.141) 3.928 ms * 0.366 ms </pre>						

Image 4-6-2: Diagnostics > Trace Route

4.0 Configuration

4.6.4 Diag > USB Tethering

The pMDDL can be Tethered to certain Android Mobile Devices to view a video stream from a remote video encoder. ***This is a preliminary feature that has limited support at this time. Contact Microhard for more information.***




Image 4-6-4: Diag > USB Tethering

USB Tethering Mode	
Enable USB Tethering. Enabling USB Tethering with open all WAN requests on the firewall to allow for proper operation	Values (selection)
	ON/OFF
Forward Video	
If enabled the pMDDL will allow video to be viewed from an attached android device from an remote video source.	Values (selection)
	Enable / Disable
Encoder's Address	
Enter the IP address of the external encoder of which the video source is located.	Values (IP Address)
	(no default)
Encoder'sPort	
Enter the port number for the video encoder's.	Values (IP Address)
	554

4.0 Configuration

4.7 Admin

4.7.1 Admin > Users

Password Change

The Password Change menu allows the password of the user 'admin' to be changed. The 'admin' username cannot be deleted, but additional users can be defined and deleted as required as seen in the Users menu below. After the modem has been reset to factory defaults, it is mandatory to change the default password for admin, the modem will prompt a user to do so upon the first login.

SystemNetworkWirelessFirewallSerialDiagAdmin

UsersSNMPDiscoveryLogout

Access Control

New password will take effect immediately after pressing "Change Password" button.

Account Name

admin

Change Password ⓘ

(5-64 characters, no space)

Confirm Password

Change Password

Add User (It will take effect immediately after pressing "Add User" button)

Username

(5-32 characters)

Password ⓘ

(5-64 characters, no space)

Confirm Password

System

Hide Submenu ▾

Network

Hide Submenu ▾

Wireless

Hide Submenu ▾

Firewall

Hide Submenu ▾

Serial

Hide Submenu ▾

Diag

Hide Submenu ▾

Admin

Hide Submenu ▾

Add User

Add User

Users Summary

No users defined.

Image 4-7-1: Users > Password Change

New Password

Enter a new password for the 'admin' user. It must be at least 5 characters in length. **The default password for 'admin' is 'admin'.**

Values (characters)

admin

Confirm Password

The exact password must be entered to confirm the password change, if there is a mistake all changes will be discarded.

Values (characters)

admin

4.0 Configuration

Add Users

Different users can be set up with customized access to the WebUI. Each menu or tab of the WebUI can be disabled on a per user basis as seen below.




Image 4-7-2: Access Control > Users

Username

Enter the desired username. Minimum of 5 character and maximum of 32 character. Changes will not take effect until the system has been restarted.

Values (characters)

(no default)
Min 5 characters
Max 32 characters

Password / Confirm Password

Passwords must be a minimum of 5 characters. The Password must be re-entered exactly in the Confirm Password box as well.

Values (characters)

(no default)
min 5 characters

4.0 Configuration

4.7.2 Admin > SNMP

The pMDDL may be configured to operate as a Simple Network Management Protocol (SNMP) agent. Network management is most important in larger networks, so as to be able to manage resources and measure performance. SNMP may be used in several ways:

- configure remote devices
- monitor network performance
- detect faults
- audit network usage
- detect authentication failures



SNMP: Simple Network Management Protocol provides a method of managing network devices from a single PC running network management software.

Managed networked devices are referred to as SNMP agents.

A SNMP management system (a PC running SNMP management software) is required for this service to operate. This system must have full access to the pMDDL. Communications is in the form of queries (information requested by the management system) or traps (information initiated at, and provided by, the SNMP agent in response to predefined events).

Objects specific to the pMDDL are hosted under private enterprise number **21703**.

An object is a variable in the device and is defined by a Management Information Database (MIB). Both the management system and the device have a copy of the MIB. The MIB in the management system provides for identification and processing of the information sent by a device (either responses to queries or device-sourced traps). The MIB in the device relates subroutine addresses to objects in order to read data from, or write data to, variables in the device.

An SNMPv1 agent accepts commands to retrieve an object, retrieve the next object, set and object to a specified value, send a value in response to a received command, and send a value in response to an event (trap).

SNMPv2c adds to the above the ability to retrieve a large number of objects in response to a single request.

SNMPv3 adds strong security features including encryption; a shared password key is utilized. Secure device monitoring over the Internet is possible. In addition to the commands noted as supported above, there is a command to synchronize with a remote management station.

The pages that follow describe the different fields required to set up SNMP on the pMDDL. MIBS may be requested from Microhard Systems Inc.

The MIB file can be downloaded directly from the unit using the '**Get MIB File**' button on the Network > SNMP menu.

Download MIB File

Get MIB File

4.0 Configuration

SNMP Settings

SystemNetworkWirelessFirewallSerialDiagAdmin

UsersSNMPDiscoveryLogout

SNMP Settings

SNMP Settings

SNMP Agent Status

Enable ▾

Read Only Community Name

public

Read Write Community Name

private

Listening Port

161

SNMP Version

Version 3 ▾

V3 User Name

userV3

V3 User Read Write Limit

Read Only ▾

V3 User Authentication Level

AuthPriv ▾

V3 Authentication Protocol

MD5 ▾

V3 Authentication Password

.....

Show Secret ☐

V3 Privacy Protocol

DES ▾

V3 Privacy Password

.....

Show Secret ☐

SNMP Trap Settings

SNMP Trap Status

Disable ▾

Download MIB File

Get MIB File

Image 4-7-3: Admin > SNMP

SNMP Agent Status

If disabled, an SNMP service is not provided from the device. Enabled, the device - now an SNMP agent - can support SNMPv1, v2, & v3.

Values (selection)

Disable / Enable

Read Only Community Name

Effectively a plain-text password mechanism used to weakly authenticate SNMP queries. Being part of the community allows the SNMP agent to process SNMPv1 and SNMPv2c requests. This community name has only READ priority.

Values (string)

public

Read Write Community Name

Also a plain-text password mechanism used to weakly authenticate SNMP queries. Being part of the community allows the SNMP agent to process SNMPv1 and SNMPv2c requests. This community name has only READ/WRITE priority.

Values (string)

private

Listening Port

Enter the UDP port on which the pMDDL listens for incoming SNMP get/set messages. The default is port 161.

Values (UDP Port)

161

SNMP Version

Values (selection)

Version 1 / **Version 2** / Version 3

SNMP V3 User Name

Defines the user name for SNMPv3.

Values (string)

V3user

V3 User Read Write Limit

Defines accessibility of SNMPv3; If Read Only is selected, the SNMPv3 user may only read information; if Read Write is selected, the SNMPv3 user may read and write (set) variables.

Values (selection)

Read Only / Read Write

V3 User Authentication Level

Defines SNMPv3 user's authentication level:

NoAuthNoPriv: No authentication, no encryption.

AuthNoPriv: Authentication, no encryption.

AuthPriv: Authentication, encryption.

Values (selection)

NoAuthNoPriv

AuthNoPriv

AuthPriv

V3 User Authentication Password

SNMPv3 user's authentication password. Only valid when V3 User Authentication Level set to AuthNoPriv or AuthPriv.

Values (string)

00000000

V3 User Privacy Password

SNMPv3 user's encryption password. Only valid when V3 User Authentication Level set to AuthPriv (see above).

Values (string)

00000000

Auth Failure Traps

If enabled, an authentication failure trap will be generated upon authentication failure. (SNMP v1 & v2 only).

Values (selection)

Disable / Enable

Trap Community Name

The community name which may receive traps. (SNMP v1 & v2 only).

Values (string)

TrapUser

Trap Manage Host IP

Defines a host IP address where traps will be sent to (e.g. SNMP management system PC IP address). (SNMP v1 & v2 only).

Values (IP Address)

0.0.0.0

SNMP Trap Settings

Image 4-7-4: Admin > SNMP Trap Settings

Enable or disable autonomous SNMP traps from the device.

Values (selection)

Disable / Enable

Effectively a plain-text password mechanism used to weakly authenticate SNMP queries. Being part of the community allows the SNMP agent to process SNMP traps.

Values (string)

TrapUser

Enter the IP address of the SNMP host to which SNMP traps are sent from the device.

Values (IP Address)

0.0.0.0

Enable or Disable authentication requirements for outgoing configured SNMP event traps.

Values (selection)

Disable / Enable

Enable or Disable RSSI traps. The threshold in which that traps are triggered can also be configured, as well as the frequency at which the traps are sent when the threshold has been crossed.

Values (selection)

Disable / Enable

90 (30-120) in -dBm

90 (0 - 65535 seconds, 0=disabled.)

4.0 Configuration


WAN IP	
Enable or Disable WAN IP Traps. Device will send a trap any time the WAN IP has been changed. Generally used with dynamic IP addresses.	<div>Values (selection)</div> <div>Disable / Enable</div>

4.0 Configuration

4.7.3 Admin > Discovery

Server Status Settings

Microhard Radios employ a discovery service that can be used to detect other Microhard devices on a network. This can be done using a stand alone utility from Microhard System's called 'IP Discovery' or from the Tools > Discovery menu. The discovery service will report the MAC Address, IP Address, Description, Product Name, Firmware Version, Operating Mode, and the Network ID.



The Microhard logo is at the top left, featuring a stylized 'M' and the word 'microhard'. Below it is a navigation bar with tabs: System, Network, Wireless, Firewall, Serial, Diag, Admin, Users, SNMP, Discovery, and Logout. The 'Discovery' tab is currently selected.

Network Discovery

Server status Settings

Discovery server status: ☐ Disable ☒ Enable

Server Port Settings

Server Port:

Network Discovery

MAC Address	IP Address	Description	Product Name	Firmware Ver	Operation Mode	Network ID
00:0F:92:04:22:84	192.168.168.1	UserDevice	pDDL-MIMO	v1.4.0-r1005	Master	MHK_Alpha

[Start discovery network again](#)

Image 4-7-5: Admin > Discovery

Discovery Service Status

Use this option to disable or enable the discovery service.

Values (selection)

Disable / **Enable**

Server Port Settings

Specify the port running the discovery service on the pMDDL unit.

Values (Port #)

20097

Network Discovery

The Network discovery tool allows the pMDDL to send a broadcast to all Microhard devices on the same network. Other units on the network will respond to the broadcast and report their MAC address, IP address (With a hyperlink to that units WebUI page), description, firmware version.

The discovery service can be a useful troubleshooting tool and can be used to quickly find and indentify other units on the network.

4.0 Configuration

4.7.4 Admin > Logout

The logout function allows a user to end the current configuration session and prompt for a login screen.




Image 4-7-6: Admin > logout

5.0 AT Command Line Interface

5.1 AT Command Overview

AT Commands can be issued to configure and manage the pMDDL, via TCP/IP (telnet).

5.1.1 Telnet (TCP/IP)

Telnet can be used to access the AT Command interface of the pMDDL. The default port is TCP Port 23. A telnet session can be made to the unit using any Telnet application (Windows Telnet, Tera Term, ProComm etc). Once communication is established, a login is required to continue.




Image 5-1: Establishing a Telnet Session

A session can be made to the WAN IP Address (if allowed in the firewall settings) for remote configuration, or to the local RJ45 interface.

Once a session is established a login is required to continue. As seen in the Serial port setup, the default login is **admin**, and the password is **admin**. Once verified, the AT Command Line Interface menu is shown and AT Commands can now be issued. (Type "?" or Help to list the commands).



The factory default network settings:

IP: 192.168.168.1
Subnet: 255.255.255.0
Gateway: 192.168.168.1




Image 5-2: Telnet AT Command Session

5.0 AT Command Line Interface

5.2 AT Command Syntax

The follow syntax is used when issuing AT Commands on the pMDDL

- All commands start with the AT characters and end with the <Enter> key
- Microhard Specific Commands start with +M
- Help will list top level commands (ATL will list ALL available AT Commands)
- To query syntax of a command: AT+<command_name>=?
- Syntax for commands that are used only to query a setting:
AT<command_name>
- Syntax for commands that can be used to query *and* set values:
AT<command_name>=parameter1,parameter2,... (Sets Values)
AT<command_name>? (Queries the setting)

Query Syntax:

AT+MSCNTO=? <Enter>

+MSCNTO:

Command Syntax: AT+MSCNTO=<Timeout_s>

Parameter:

<Timeout_s> 30 to 65535 in seconds, 0-Disable

OK

Setting a value:

AT+MSCNTO=300 <Enter>

OK

Query a setting:

AT+MSCNTO? <Enter>

+MSCNTO: 300 seconds

OK

A screen capture of the above commands entered into a unit is shown below:



```

C:\> Telnet 192.168.168.1

UserDevice> AT+MSCNTO=?
+MSCNTO:
Command Syntax:
  AT+MSCNTO=<Timeout_s>
Parameter:
  <Timeout_s> : 30 to 65535 in seconds, 0-Disable
OK
UserDevice> AT+MSCNTO=300
OK
UserDevice> AT+MSCNTO?
+MSCNTO: 300 seconds
OK
UserDevice> AT+MSCNTO
  
```

Image 5-3: Telnet AT Command Syntax

Once AT commands are entered, they must be saved into the file system to enable the changes.

- | | |
|------------|--|
| AT&W | Saves changes. |
| ATO or ATA | Exits the AT Command Line Interface, if used before AT&W, changes are discarded. |

5.0 AT Command Line Interface

5.3 Supported AT Commands

Basic AT Commands			
AT Command	Description	Syntax	Effect
AT	AT echo OK	AT <enter>	Immediate
ATE0	Disable echo	ATE0 <enter>	Immediate
ATE1	Enabled local echo	ATE1 <enter>	Immediate
ATH	Show a list of previously run commands	ATH <enter>	Immediate
ATL	Show a list of all available AT Commands	ATL <enter>	Immediate
AT&R	Read modem profile to editable profile. (Reserved)	AT&R <enter>	Immediate
AT&V	Read modem active profile	AT&V <enter>	Immediate
AT&W	Enable configuration changes that have been entered	AT&W <enter>	Immediate
ATA	Quit. Exits AT command session and returns to login prompt	ATA <enter>	Immediate
ATO	Quit. Exits AT command session and returns to login prompt	ATO <enter>	Immediate
Administrative AT Commands			
AT Command	Description	Syntax	Effect
AT+MADISS	Get/Set discovery service used by the modem	AT+MADISS[=<Mode>[,<Port>]] Mode: 0 - Disable 1 - Discoverable Port: 1 to 65535. Default is 20097	AT&W
AT+MASNMP	Get/Set SNMP service	AT+MASNMP[=<Mode>[,<ROCommunity>,<RWCommunity>,<Port>,<Version>]] <Mode>: 0 - Disable 1 - Enable <ROCommunity>: Read Only Community Name 1 to 32 characters <RWCommunity>: Read Write Community Name 1 to 32 characters <Port>: Listening Port 0 to 65535. Default is 161 <Version>: SNMP version 1 - Version 1 2 - Version 2 3 - Version 3 (Use AT+MASNMPV3 to set Authentication and Privacy parameters)	AT&W
AT+MASNMPV3	Get/Set SNMP Version 3	AT+MASNMPV3=<UserName>,<RWLimit>,<AuthLevel>[,<Auth>,<AuthPassword>[,<Privacy>,<PrivacyPassword>]] <UserName> : V3 User Name 1 to 32 characters <RWLimit> : V3 User Read Write Limit 0 - Read Only 1 - Read Write <AuthLevel> : V3 User Authentication Level 0 - NoAuthNoPriv 1 - AuthNoPriv 2 - AuthPriv <Auth> : V3 Authentication Protocol 0 - MD5 1 - SHA <AuthPassword> : V3 Authentication Password 5 to 64 characters <Privacy> : V3 Privacy Protocol 0 - DES 1 - AES <PrivacyPassword>: V3 Privacy Password 5 to 64 characters Usage: NoAuthNoPriv : AT+MASNMPV3=<UserName>,<RWLimit>,0 AuthNoPriv : AT+MASNMPV3=<UserName>,<RWLimit>,1,<Auth>,<AuthPassword> AuthPriv : AT+MASNMPV3=<UserName>,<RWLimit>,2,<Auth>,<AuthPassword>,<Privacy>,<PrivacyPassword>	AT&W

5.0 AT Command Line Interface

Administrative AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MASNMPTRAP	Get/Set SNMP Trap	AT+MASNMPTRAP[=<Mode>[,<Name>,<IP>[,<AuthFailureTraps>]]] <Mode>: 0 - Disable 1 - Enable <Name>: Trap Community Name. 1 to 32 characters <IP>: Trap Manage Host IP. Default 0.0.0.0 (Disable) <AuthFailureTraps>: 0 - Disable 1 - Enable Usage: AT+MASNMPTRAP AT+MASNMPTRAP=0 AT+MASNMPTRAP=1[,<Name>,<IP>[,<AuthFailureTraps>]]	AT&W
Serial Port AT Commands			
AT Command	Description	Syntax	Effect
AT+MCPS2	Get/Set Serial port	AT+MCPS2=<Mode> Parameters: COM2 Mode: 0 - Console 1 - Data	AT&W
AT+MCBR2	Get/Set Serial port baud rate	AT+MCBR2=<Baud Rate Type> Parameters: COM2 Baud Rate Type: 0 - 300 1 - 600 2 - 1200 3 - 2400 4 - 3600 5 - 4800 6 - 7200 7 - 9600 8 - 14400 9 - 19200 10 - 28800 11 - 38400 12 - 57600 13 - 115200 14 - 230400 15 - 460800 16 - 921600	AT&W
AT+MCDF2	Get/Set Serial port data format	AT+MCDF2=<Data Formate Type> Parameters: COM2 Data Formate Option: 0 - 8N1 2 - 8E1 3 - 8O1	AT&W
AT+MCDM2	Get/Set Serial port data mode	AT+MCDM2=<Data Mode Type> Parameters: COM2 Data Mode Option: 0 - Seamless 1 - Transparent	AT&W
AT+MCCT2	Get/Set Serial port character timeout	AT+MCCT2=<timeout> Parameters: COM2 timeout: 1 to 65535 in seconds	AT&W
AT+MCMP2	Get/Set Serial port maximum packet size	AT+MCMP2=<size> Parameters: COM2 maximum packet size: 1 to 2048	AT&W
AT+MCNCI2	Get/Set Serial port no-connection data intake	AT+MCNCI2=<Mode> Parameters: COM2 Mode Option: 0 - Disable 1 - Enable	AT&W
AT+MCMT2	Get/Set Serial port Modbus tcp configuration	AT+MCMT2=<Status> Parameters: COM2 Modbus Status: 0 - Disable 1 - Enable	AT&W

5.0 AT Command Line Interface

Serial Port AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MCIPM2	Get/Set Serial port IP protocol mode	AT+MCIPM2=<IP Protocol Config> Parameters: COM2 IP Protocol Config: 0 - TCP Client 1 - TCP Server 2 - TCP Client/Server 3 - UDP Point to Point 4 - UDP Point to Multipoint(P) 5 - UDP Point to Multipoint(MP) 8 - PPP	AT&W
AT+MCCT2	Get/Set Serial port tcp client configuration when IP protocol mode is TCP Client	AT+MCTC2=<Remote Server IP>,<Remote Server Port>,<Outgoing timeout> Parameters: COM2: Remote Server IP : valid IP address Remote Server Port : 1 to 65535 Outgoing timeout : 1 to 65535 in seconds	AT&W
AT+MCTS2	Get/Set Serial port tcp server configuration when IP protocol mode is TCP Server	AT+MCTS2=<Server Mode>,<Polling Timeout>,<Local Listening Port>,<Connection timeout> Parameters: Server Mode : 0 - Monitor; 1 - Polling Polling timeout : 1 to 65535 in seconds Local Listening Port : 1 to 65535 Connection timeout : 1 to 65535 in seconds	AT&W
AT+MCTCS2	Get/Set Serial port tcp client/server configuration when IP protocol mode is TCP Client/Server	AT+MCTCS2[=<Remote Server IP>,<Remote Server Port>,<Outgoing timeout>,<Server Mode>,<Polling Timeout>,<Local Listener Port>,<Incoming timeout>] Parameters: Remote Server IP : valid IP address Remote Server Port : 1 to 65535 Outgoing timeout : 1 to 65535 in seconds Server Mode : 0 - Monitor; 1 - Polling Polling timeout : 1 to 65535 in seconds Local Listening Port : 1 to 65535 Incoming timeout : 1 to 65535 in seconds	AT&W
AT+MCUPP2	Get/Set Serial port UDP point to point configuration when IP protocol mode is UDP point to point	AT+MCUPP2[=<Remote IP>,<Remote Port>,<Listening Port>,<UDP Timeout>] Parameters: Remote IP : valid IP address Remote Port : 1 to 65535 Listening Port : 1 to 65535 UDP Timeout : 1 to 65535 in seconds	AT&W
AT+MCPPP2	Get/Set Serial port PPP configuration when IP protocol mode is PPP	AT+MCPPP2[=<Mode>,<CCP negotiation>,<LCP Echo Failure Number>,<LCP Echo Interval>,<Local IP>,<Host IP>,<Idle Timeout>,<Expected String>,<Response String>] Parameters: COM2: Mode : 0 - Active; 1 - Passive CCP negotiation : 0 - Disable; 1 - Enable LCP Echo Failure Number : [0 .. 65535] LCP Echo Interval : [0 .. 65535] Local IP : Valid IP address Host IP : Valid IP address Idle Timeout : 1 to 65535 in seconds Expected String : (Optional) 0 - 63 characters Response String : (Optional) 0 - 63 characters	AT&W
AT+MCUPMP2	Get/Set Serial port UDP point to multipoint as point configuration when IP protocol mode is set to UDP point to multipoint (P)	AT+MCUPMP2[=<Multicast IP>,<Multicast Port>,<Listening Port>,<Time To Live>,<Multicast Interface>] Parameters: COM2: Multicast IP : valid IP address Multicast Port : 1 to 65535 Listening Port : 1 to 65535 Time To Live : 1 to 255 in seconds Multicast Interface : 0 - default 1 - LAN	AT&W
AT+MCUPMM2	Get/Set Serial port UDP point to multipoint as MP configuration when IP protocol mode be set to UDP point to multipoint (MP)	AT+MCUPMM2[=<Remote IP>,<Remote Port>,<Multicast IP>,<Multicast Port>,<Multicast Interface>] Parameters: COM2: Remote IP : valid IP address Remote Port : 1 to 65535 Multicast IP : valid IP address Multicast Port : 1 to 65535 Multicast Interface : 0 - default 1 - LAN	AT&W
AT+MCESCP2	Get/Set Serial support escape sequence configuration	AT+MCESCP2[=<Escape Mode>,<Escape Guard Interval>,<Escape Sequence String>] Parameters: COM2: Escape Mode : 0 - Disabled; 1 - Enabled Escape Guard Interval : 1 to 10 seconds Escape Sequence String : 3 to 7 characters	AT&W

5.0 AT Command Line Interface

Firewall AT Commands			
AT Command	Description	Syntax	Effect
AT+MFGEN	Get/Set firewall general configuration	AT+MFGEN[=<Config>[,<Mode>]] Parameters Config : 0 - WAN Remote Management 1 - WAN Request 2 - LAN to WAN Access Control 3 - Anti-Spoof 4 - Packet Normalization Mode : 0 - Disable (Block) 1 - Enable (Allow)	AT&W
AT+MFDZ	Get/Set firewall DMZ configuration	AT+MFDZ[=<DMZ Source>[,<DMZ Mode>[,<DMZ Server IP>,<Exception Port>]]] Parameters: DMZ Source : 0 - WAN DMZ Mode : 0 - Disable 1 - Enable DMZ Server IP : Valid IP address Exception Port : 0 - 65535	AT&W
AT+MFPORTFWD	Get/Set firewall Port Forwarding rule	AT+MFPORTFWD[=<Name>[,<Operation>[,<Source>,<Internal IP>,<Internal Port>,<Protocol>,<External Port>,<SNAT>]]] Parameters: Name : Name of Port Forwarding rule, 1 - 64 characters Operation : ADD - Add a rule EDIT - Edit a rule DEL - Delete a rule Source : 0 - WAN 1 - USB Internal IP : Valid IP address Internal Port : Valid port number, 1 - 65535 Protocol : 0 - TCP 1 - UDP 2 - TCPUDP External Port : Valid port number, 1 - 65535 Source NAT : 0 - No; 1 - Yes Usage: AT+MFPORTFWD AT+MFPORTFWD=<Name> AT+MFPORTFWD=<Name>,DEL AT+MFPORTFWD=<Name>,ADD,<Source>,<Internal IP>,<Internal Port>,<Protocol>,<External Port>,<SNAT> AT+MFPORTFWD=<Name>,EDIT,<Source>,<Internal IP>,<Internal Port>,<Protocol>,<External Port>,<SNAT>	AT&W
AT+MFMAC	Get/Set firewall MAC list	AT+MFMAC[=<Name>[,<Operation>[,<Action>,<Mac Address>]]] Parameters: Name : Name of firewall MAC list name, 1 - 64 characters Operation : ADD - Add a firewall MAC list EDIT - Edit a firewall MAC list DEL - Delete a firewall MAC list Action : 0 - Accept 1 - Drop 2 - Reject MAC Address : Valid MAC address Usage: AT+MFMAC AT+MFMAC=<Name> AT+MFMAC=<Name>,DEL AT+MFMAC=<Name>,ADD,<Action>,<Mac Address> AT+MFMAC=<Name>,EDIT,<Action>,<Mac Address>	AT&W
AT+MFIP	Get/SET firewall IP list	AT+MFIP[=<Name>[,<Operation>[,<Action>,<Source>,<IP Address>[,<Prefix>]]]]] Parameters: Name : Name of firewall IP list name, 1 - 64 characters Operation : ADD - Add a firewall IP list EDIT - Edit a firewall IP list DEL - Delete a firewall IP list Action : 0 - Accept 1 - Drop 2 - Reject Source : 0 - LAN 1 - Independent LAN 2 - WAN 3 - USB Source IP : Valid IP address Prefix : 0 ~ 32. 32 (default) - single IP address Usage: AT+MFIP AT+MFIP=<Name> AT+MFIP=<Name>,DEL AT+MFIP=<Name>,ADD,<Action>,<Source>,<IP Address>[,<Prefix>] AT+MFIP=<Name>,EDIT,<Action>,<Source>,<IP Address>[,<Prefix>]	AT&W

5.0 AT Command Line Interface

Firewall AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MFRULE	Get/Set firewall rule	AT+MFRULE=<Name>[,<Operation>[,<Action>,<Source>,<Src IP Format>,<Src IP From/Subnet>,<Src IP To/Prefix>,<Destination>,<Dest IP Format>,<Dest IP From/Subnet>,<Dest IP To/Prefix>,<Dest Port>,<Protocol>]]] Parameters: Name : Name of firewall rule name, 1 - 64 characters Operation : ADD - Add a firewall rule EDIT - Edit a firewall rule DEL - Delete a firewall rule Action : 0 - Accept 1 - Drop 2 - Reject Source : 0 - LAN 1 - Independent LAN 2 - WAN 3 - USB 4 - None IP Format : 0 - IP Range 1 - Subnet / Prefix IP From/Subnet: Valid IP address. 0 - Set to blank IP To/Prefix : Valid IP address. 0 - Set to blank; or 0 ~ 32 for Prefix Destination : 0 - LAN 1 - Independent LAN 2 - WAN 3 - USB 4 - None IP Format : 0 - IP Range 1 - Subnet / Prefix IP From/Subnet: Valid IP address. 0 - Set to blank IP To/Prefix : Valid IP address. 0 - Set to blank; or 0 ~ 32 for Prefix Port/Range : Port 0 ~ 65535 or Port range specified as 100:200 format Protocol : 0 - TCP 1 - UDP 2 - TCPUDP 3 - ICMP	AT&W
AT+MFRST	Reset to default firewall	AT+MFRST <enter>	Immediate
Network AT Commands			
AT Command	Description	Syntax	Effect
AT+MNLAN	Show/Add/Edit/Delete the network LAN interface	AT+MNLAN AT+MNLAN=<LAN Name> AT+MNLAN=<LAN Name>,DEL AT+MNLAN=<LAN Name>,ADD/EDIT,<Protocol>[,<IP>,<Netmask>[,<Gateway>]] Where <Protocol>=0 AT+MNLAN=<LAN Name>,ADD/EDIT,<Protocol> Where <Protocol>=1 or 3 AT+MNLAN=<LAN Name>,EDIT,<Protocol>[,<IP>,<Netmask>] Where <Protocol>=2 and <LAN Name>="lan" Parameters: LAN Name : Name of Network LAN interface. System built-in one is "lan" Operation : ADD - Add a new LAN interface EDIT - Edit an existing LAN interface DEL - Delete an existing LAN interface Protocol : 0 - Static IP 1 - DHCP with LAN alias disabled 2 - DHCP with LAN alias enabled, only for "lan" 3 - None. Not for "lan" IP Address : Valid IP address Netmask : Valid netmask Gateway : Valid IP address. 0 - Reset	AT&W
AT+MNLANDHCP	Get/Set LAN DHCP server on LAN interface	AT+MNLANDHCP=<LAN Name>[,<Mode>[,<Start IP>,<Limit>,<Lease Time>[,<Alt. Gateway>,<Pre. DNS>,<Alt. DNS>,<WINS/NBNS Servers>,<WINS/NBT Node>]]] Parameters: LAN Name : Name of Network LAN interface Mode : 0 - Disable DHCP Server 1 - Enable DHCP Server Start IP : The starting address DHCP assignable IP Addresses Limit : The maximum number of IP addresses. min=1 max=16777214 Lease Time : The DHCP lease time in minutes. 2~2147483647 minutes. 0 means'infinity' Alt. Gateway : Alternate Gateway for DHCP assigned devices if the default gateway is not to be used Pre. DNS : Preferred DNS server address to be assigned to DHCP devices Alt. DNS : Alternate DNS server address to be assigned to DHCP devices WINS/NBNS Server : WINS/NBNS Servers WINS/NBT Node : WINS/NBT Node Type 0 - none 1 - b-node 2 - p-node 3 - m-node 4 - h-node	AT&W

5.0 AT Command Line Interface

Network AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MNLANSTP	Get/Set the network LAN interface: Spanning Tree (STP)	AT+MNLANSTP=<LAN Name>[,<STP>] Parameters: LAN Name : Name of Network LAN interface Spanning Tree : 0 - Off 1 - On	AT&W
AT+MNLANIGMP	Get/Set the network LAN interface: IGMP Snooping	AT+MNLANIGMP=<LAN Name>[,<IGMP Snooping>] Parameters: LAN Name : Name of Network LAN interface IGMP Snooping : 0 - Off 1 - On	AT&W
AT+MNLANDR	Get/Set the network LAN interface: Default Route	AT+MNLANDR=<LAN Name>[,<Default Route>] Parameters: LAN Name : Name of Network LAN interface Default Route : 0 - No 1 - Yes	AT&W
AT+MNLANDNS	Get/Set the network LAN interface: DNS	AT+MNLANDNS=<LAN Name>[,<Mode>[,<Primary DNS>,<Secondary DNS>]] Usage: AT+MNLANDNS=<LAN Name> AT+MNLANDNS=<LAN Name>,<Mode> Where <Mode>=0 AT+MNLANDNS=<LAN Name>,<Mode>[,<Primary DNS>,<Secondary DNS>] Where <Mode>=1 Parameters: LAN Name : Name of Network LAN interface Mode : 0 - Auto 1 - Manual Primary DNS : Valid IP Address or 0 (Reset) Secondary DNS : Valid IP address or 0 (Reset)	AT&W
AT+MNWAN	Get/Set the network WAN interface	AT+MNWAN[=<Mode>[,<Protocol>[,<IP>,<Netmask>[,<Gateway>]]]] Usage: AT+MNWAN AT+MNWAN=<Mode>,<Protocol>,<IP>,<Netmask>[,<Gateway>] Where <Mode>=0 and <Protocol>=0 AT+MNWAN=<Mode>,<Protocol>,<IP>,<Netmask> Where <Mode>=2 and <Protocol>=0 AT+MNWAN=<Mode>,<Protocol> Where <Mode>=0/2 and <Protocol>=1 AT+MNWAN=<Mode>,<Protocol> Where <Mode>=2 and <Protocol>=2 AT+MNWAN=<Mode> Where <Mode>=1 Parameters: Mode : 0 - Independent WAN 1 - Bridge with LAN Port 2 - Independent LAN Protocol: 0 - Static IP 1 - DHCP 2 - None IP : Valid IP address Netmask : Valid netmask Gateway : Valid IP address. 0 - Reset	AT&W
AT+MNWANDR	Get/Set the network WAN interface: Default Route	AT+MNWANDR[=<Default Route>] Parameters: Default Route : 0 - No 1 - Yes	AT&W
AT+MNWANDNS	Get/Set DNS Server when WAN port works as Independent WAN	AT+MNWANDNS[=<Mode>[,<Primary DNS>,<Secondary DNS>]] Usage: AT+MNWANDNS AT+MNWANDNS=<Mode> Where <Mode>=0 AT+MNWANDNS=<Mode>[,<Primary DNS>,<Secondary DNS>] Where <Mode>=1 Parameters: Mode : 0 - Auto 1 - Manual Primary DNS : Valid IP Address or 0 (Reset) Secondary DNS : Valid IP address or 0 (Reset)	AT&W
AT+MNWANLANDHCP	Get/Set LAN DHCP server when the WAN port is set as Independent LAN	AT+MNWANLANDHCP[=<Mode>[,<Start IP>,<Limit>,<Lease Time>[,<Alt.Gateway>,<Pre.DNS>,<Alt.DNS>]]] Usage: AT+MNWANLANDHCP AT+MNWANLANDHCP=<Mode> Where <Mode>=0 AT+MNWANLANDHCP=<Mode>,<Start IP>,<Limit>,<Lease Time>[,<Alt.Gateway>,<Pre.DNS>,<Alt.DNS>] Where <Mode>=1 Parameters: Mode : 0 - Disable DHCP Server 1 - Enable DHCP Server Start IP : The starting address DHCP assignable IP Addresses Limit : The maximum number of IP addresses. min=1 max=16777214 Lease Time : The DHCP lease time in minutes. 2~2147483647 minutes. 0 means 'infinity' Alt. Gateway : Alternate Gateway for DHCP assigned devices if the default gateway is not to be used Pre. DNS : Preferred DNS server address to be assigned to DHCP devices Alt. DNS : Alternate DNS server address to be assigned to DHCP devices	AT&W

5.0 AT Command Line Interface

Network AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MNIPMAC	Show/Add/Delete/Release/ReleaseAll the MAC-IP address binding	AT+MNIPMAC[=<Operation>[,<Name>[,<IP Address>,<MAC Address>]]] Usage: AT+MNIPMAC AT+MNIPMAC=SHOW,<Name> AT+MNIPMAC=ADD,<Name>,<IP Address>,<MAC Address> AT+MNIPMAC=DEL,<Name> AT+MNIPMAC=RELEASE,<Name> AT+MNIPMAC=RELEASEALL Parameters: Operation : SHOW - Show the details of the MAC-IP address binding ADD - Add a new MAC-IP address binding DEL - Delete an existing MAC-IP address binding RELEASE - Release the active DHCP lease RELEASEALL - Release all active DHCP leases Name : Name of the MAC-IP binding, 1-64 characters IP Address : Valid IP address MAC Address: The physical MAC address of the device or interface	AT&W
AT+MNEMAC	Get the MAC address of the local Ethernet interface	AT+MNEMAC <enter> Sample Output: +MNEMAC: "00:0F:92:02:F9:0F" OK	Immediate
AT+MNPORT	Get/Set the Ethernet port configuration	AT+MNPORT[=<Ethernet Port>[,<Mode>[,<Auto Negotiation>,<Speed>,<Duplex>]]] Parameters: Ethernet Port : 0 - WAN 1 - LAN Mode : 0 - Auto 1 - Manual Auto-Negotiation : 0 - Off 1 - On Speed : 0 - 10 Mbit/s 1 - 100 Mbit/s Duplex : 0 - Full 1 - Half	AT&W
AT+MNSTATUS	Get the network status	AT+MNSTATUS <enter> Sample Output: LAN Port Status General Status IP Address : 192.168.168.1 Connection Type : static Subnet Mask : 255.255.255.0 MAC Address : 00:0F:92:02:F9:0F Traffic Status Receive bytes : 262.633KB Receive packets : 3345 Transmit bytes : 168.370KB Transmit packets : 2229 WAN Port Status General Status IP Address : N/A Connection Type : dhcp Subnet Mask : N/A MAC Address : 00:0F:92:03:F9:0F Traffic Status Receive bytes : 0B Receive packets : 0 Transmit bytes : 0B Transmit packets : 0 Default Gateway : 192.168.168.1 DNS Server(s) : None Kernel IP routing table Destination Gateway Subnet Mask Flags Metric Ref Use Iface 0.0.0.0 192.168.168.1 0.0.0.0 UG 0 0 0 br-lan 192.168.168.0 0.0.0.0 255.255.255.0 U 0 0 0 br-lan	Immediate

5.0 AT Command Line Interface

Network AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MNUSB	Show/Edit the network USB Interface	AT+MNUSB[=<Mode>[,<Protocol>[,<IP>,<Netmask>[,<Gateway>]]]] Usage: AT+MNUSB AT+MNUSB=<Mode>,<Protocol>,<IP>,<Netmask>[,<Gateway>] Where <Mode>=0 and <Protocol>=0 AT+MNUSB=<Mode>,<Protocol> Where <Mode>=0 and <Protocol>=1 AT+MNUSB=<Mode> Where <Mode>=1/2 Parameters: Mode : 0 - Independent LAN 1 - Bridge with LAN Port 2 - Bridge with WAN Port Protocol: 0 - Static IP 1 - DHCP IP : Valid IP address Netmask : Valid netmask Gateway : Valid IP address. 0 - Reset	AT&W
AT+MNUSBDHCP	Get/Set USB DHCP server on USB interface	AT+MNUSBDHCP[=<Mode>[,<Start IP>,<Limit>,<Lease Time>[,<Alt. Gateway>,<Pre. DNS>,<Alt. DNS>]]] Parameters: Mode : 0 - Disable DHCP Server 1 - Enable DHCP Server Start IP : The starting address DHCP assignable IP Addresses Limit : The maximum number of IP addresses Lease Time : The DHCP lease time in minutes. 2~2147483647 minutes. 0 means 'infinity' Alt. Gateway : Alternate Gateway for DHCP assigned devices if the default gateway is not to be used Pre. DNS : Preferred DNS server address to be assigned to DHCP devices Alt. DNS : Alternate DNS server address to be assigned to DHCP devices	AT&W
AT+MNUSBDR	Get/Set the network USB interface: Default Route	AT+MNUSBDR[=<Default Route>] Parameters: Default Route : 0 - No 1 - Yes	AT&W
AT+MNUSBDNS	Get/Set the network USB interface: DNS	AT+MNUSBDNS[=<Mode>[,<Primary DNS>,<Secondary DNS>]] Usage: AT+MNUSBDNS AT+MNUSBDNS=<Mode> Where <Mode>=0 AT+MNUSBDNS=<Mode>[,<Primary DNS>,<Secondary DNS>] Where <Mode>=1 Parameters: Mode : 0 - Auto 1 - Manual Primary DNS : Valid IP Address or 0 (Reset) Secondary DNS : Valid IP address or 0 (Reset)	AT&W

5.0 AT Command Line Interface

System AT Commands			
AT Command	Description	Syntax	Effect
AT+MSCNTO	Get/Set the console timeout	AT+MSCNTO=<Timeout_s> Parameter: <Timeout_s> : 30 to 65535 in seconds, 0-Disable	AT&W
AT+MSPWD	Set password	AT+MSPWD=<New Password>,<Confirm Password> Parameters: <New Password> : 5-64 characters except space <Confirm Password> : Same as <New Password>	AT&W
AT+MSGMI	Get manufacturers identification	AT+MSGMI <enter> Sample Output: +MSGMI: 2014-2016 Microhard. OK	Immediate
AT+MSSYSI	Get system summary information	AT+MSSYSI <enter> Sample Output: +MSSYSI: Ethernet Port: MAC : 00:0F:92:02:AB:22 IP : 192.168.168.1 MASK : 255.255.255.0 System: Device : UserDevice Product : pMDDL Image : PWii Hardware : Rev A Software : v1.4.0 build 1005 Copyright : 2014-2016 Microhard. System Time : Tue Jul 19 14:14:32 2017 OK	Immediate
AT+MSGMR	Get modem Record information	AT+MSGMR <enter> Sample Output: +MSGMR: Hardware Version : Rev A Software Version : v1.4.0 build 1005 Copyright : 2014-2016 Microhard. System Time : Tue Nov 29 14:15:02 2016 OK	Immediate
AT+MSMNAME	Get/Set modem Name setting	AT+MSMNAME=<Modem_Name> Parameter: <Modem_Name> : 1 - 64 characters. Must be alphanumeric or dots(.), or dashes(-) or underscores(_)	AT&W
AT+MSRTF	Reset the modem to the factory default settings from non-volatile (NV) memory	AT+MSRTF=<Action> Parameter: <Action>: 0 - Pre-set action 1 - Confirm action	AT&W
AT+MSREB	Reboot the modem	AT+MSREB <enter> Sample Output: Rebooting... OK	Immediate
AT+MSNTP	Get/Set NTP server	AT+MSNTP[=<Mode>,<Server>,<Port>,<Client Interval>]] Parameters: <Mode> : 0 - Local Time; 1 - NTP <Server> : Valid IP Address or Name <Port> : 1 to 65535, Default is 123 <Client Interval> : 15 to 65535 in seconds, 0-Disable	AT&W
AT+MSSYSLOG	Get/Set Syslog server settings	AT+MSSYSLOG[=<Server>,<Port>]] Parameters: <Server> : Valid IP Address or Name. 0.0.0.0 - Disable. 1 to 256 characters <Port> : 1 to 65535. Default is 514	AT&W
AT+MSSERVICE	Get/Set service status and port	AT+MSSERVICE[=<Service>,<Mode>,<Port>]]] Parameters: <Service> : 0 - FTP 1 - Telnet 2 - SSH <Mode> : 0 - Disable 1 - Enable <Port> : 0 to 65535. For Telnet (23 by default) and SSH (22 by default) only	AT&W
AT+MSWEBUI	Get/Set Web UI protocol and port	AT+MSWEBUI[=<Mode>,<HTTP Port>,<HTTPS Port>]]] Parameters: <Mode> : 0 - HTTP/HTTPS 1 - HTTP 2 - HTTPS 3 - Disable <HTTP Port> : 2 to 65534, 80 by default <HTTPS Port> : 2 to 65534, 443 by default	AT&W

5.0 AT Command Line Interface

Wireless (Radio) AT Commands			
AT Command	Description	Syntax	Effect
AT+MWRADIO	Get/Set radio status, On or Off	AT+MWRADIO[=<Radio>] <Radio> 0 - Off 1 - On	AT&W
AT+MWDISTANCE	Get/Set radio Wireless Distance	AT+MWDISTANCE[=<Distance>] <Distance> 1 - 200000 in meter	AT&W
AT+MWTXPOWER	Get/Set radio Tx power	AT+MWTXPOWER[=<Tx Power>] <Tx Power> 7 - 7 dbm 8 - 8 dbm 9 - 9 dbm 10 - 10 dbm 11 - 11 dbm 12 - 12 dbm 13 - 13 dbm 14 - 14 dbm 15 - 15 dbm 16 - 16 dbm 17 - 17 dbm 18 - 18 dbm 19 - 19 dbm 20 - 20 dbm 21 - 21 dbm 22 - 22 dbm 23 - 23 dbm 24 - 24 dbm 25 - 25 dbm 26 - 26 dbm 27 - 27 dbm 28 - 28 dbm 29 - 29 dbm 30 - 30 dbm	AT&W
AT+MWBAND	Get/Set radio channel bandwidth	AT+MWBAND[=<Channel Bandwidth>[,<Symbol Rate>]] Available radio channel bandwidth for pMDDL mode 0 - 8 MHz 1 - 4 MHz	AT&W
AT+MWFREQ2400	Get/Set radio channel-frequency (Options vary by channel bandwidth)	AT+MWFREQ2400[=<MHz Channel Frequency>] <Channel Frequency> : 4 - 2405 MHz . . . 78- 2479 MHz	AT&W
AT+MWMIMO	Get/Set radio MIMO	AT+MWMIMO[=<MIMO>] <MIMO> : 0 - Off 1 - On	AT&W
AT+MWMCASTR	Get/Set radio Multicast Rate	AT+MWMCASTR[=<Multicast Rate>] <Multicast Rate> : 0 - QPSK FEC 1/2 1 - QPSK FEC 3/4 2 - 16-QAM FEC 1/2 3 - 16-QAM FEC 3/4 4 - 64-QAM FEC 2/3	AT&W
AT+MWVMODE	Get/Set radio mode	AT+MWVMODE[=<Virtual Interface Mode>] <Virtual Interface Mode> : 0 - Master 1 - Slave	AT&W
AT+MWVRATE	Get/Set radio TX Rate	AT+MWVRATE[=<Virtual Interface TX Rate>] <Virtual Interface TX Rate> : 0 - auto (Recommended) 1 - 64-QAM 5/6 FEC 2 - 64-QAM 3/4 FEC 3 - 64-QAM 2/3 FEC 4 - 16-QAM 3/4 FEC 5 - 16-QAM 1/2 FEC 6 - QPSK FEC 3/4 7 - QPSK FEC 1/2	AT&W

5.0 AT Command Line Interface

Wireless (Radio) AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MWEXTADDR	Get/Set radio extended addressing	AT+MWEXTADDR[=<Extended Addressing>] <Extended Addressing> : 0 - Off 1 - On	AT&W
AT+MWNETWORKID	Get/Set radio Network ID	AT+MWNETWORKID[=<Network ID>] <Network ID> Radio Virtual Interface Network ID: 1-64 characters	AT&W
AT+MWVENCRIPT	Get/Set radio Encryption Type & Key	AT+MWVENCRIPT[=<Encryption Type>[,<Key>]] <Encryption Type> Radio Virtual Interface Encryption Type: 0 - Disabled 1 - AES-128 <Key>: Min 8 characters, Max 64 characters	AT&W
AT+MWRESYNC	RF Re-Sync from the slave side	AT+MWRESYNC <enter>	Immediate
AT+MWINTFSCAN	Generate radio channel interference information in 10 to 30 seconds	AT+MWINTFSCAN[=<Sorting>] The spectral scan action takes about 10 to 30 seconds. <Sorting> : 0 - Not sorting the scan result (default) 1 - Sorting the scan result	Immediate
AT+MWSTATUS	Get the status of RF	AT+MWSTATUS <enter> Sample Output: General Status MAC Address : 00:0F:92:FA:38:30 Operation Mode : Master Network ID : pMDDL Bandwidth : 4 MHz Frequency : 2441 Tx Power : 20 dBm Encryption Type : AES-128 Traffic Status Receive Bytes : 0B Receive Packets : 0 Transmit Bytes : 89.076KB Transmit Packets : 550 OK Connection Info MAC Address : 00:0F:92:FA:59:F9 Tx Mod : 64-QAM FEC 5/6 Rx Mod : 64-QAM FEC 2/3 SNR (dB) : 75 RSSI (dBm) : -24	Immediate
AT+MWSNR	Get the value of SNR (Slave)	AT+MWSNR <enter> Sample Output: 43 OK	Immediate
AT+MWNOISEFLOOR	Get the value of Noise Floor (Slave)	AT+MWNOISEFLOOR <enter> Sample Output: -99 OK	Immediate
AT+MWSQTHRESH	Get/Set Squelch threshold	AT+MWSQTHRESH[=<Squelch Threshold>] Squelch Threshold : -1 to -128 (-1 = Turn off the threshold)	AT&W
AT+MWRFTST	RF Test (power cycle the device after the tests)	AT+MWRFTST=<Operation> <Operation> : 0 - Start Transmit 1 - Start Receive 2 - Stop 3 - Poll the result Note : !!! Power cycle the device after the tests for the RF link to work properly!!!	AT&W
AT+MWRSSI	Get radio RSSI	AT+MWRSSI <enter> Sample Output: 00:0F:92:FA:59:F9 -74 dBm	Immediate

6.0 Installation

6.1 Path Calculation



FCC regulations allow for up to 36dBi effective isotropic radiated power (EIRP). The sum (in dBm) of the transmitted power, the cabling loss, and the antenna gain cannot exceed 36dBi.

Assuming adequate antenna heights, a basic formula to determine if an adequate radio signal path exists (i.e. there is a reasonable fade margin to ensure reliability) is:

$$\text{Fade Margin} = \text{System Gain} - \text{Path Loss}$$

where all values are expressed in dB.

As discussed on the previous page, a desired fade margin is 20dB.

System gain is calculated as follows:

$$\text{System Gain} = \text{Transmitter Power} + (\text{Transmitter Antenna Gain} - \text{Transmitter Cable and Connector Losses}) + (\text{Receiver Antenna Gain} - \text{Receiver Cable and Connector Losses}) + \text{Receiver Sensitivity}$$

where all values are expressed in dB, dBi, or dBm, as applicable.

Assuming a path loss of 113dB for this example, the fade margin = 143-113 = 30dB.

30dB exceeds the desired fade margin of 20dB, therefore this radio communications link would be very reliable and robust.

On the following page are examples of actual path loss measurements taken in an open rural environment; the path loss numbers do not apply to urban or non-LOS environments.

Example:

Tx power = 30dBm
Tx antenna gain = 6dBi
Tx cable/connector loss = 2dB
Rx antenna gain = 3dBi
Rx cable/connector loss = 2dB
Rx sensitivity = -108dBm

$$\begin{aligned} \text{System Gain} &= [30+(6-2)+(3-2)+108]\text{dB} \\ &= [30+4+1+108]\text{dB} \\ &= 143\text{dB} \end{aligned}$$

6.0 Installation



To satisfy FCC radio frequency (RF) exposure requirements for mobile transmitting devices, a separation distance of 23cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operation at less than this distance is not recommended. The antenna used for this transmitter must not be co-located in conjunction with any other antenna or transmitter.



Never work on an antenna system when there is lightning in the area.

Distance (km)	Master Height (m)	Remote Height (m)	Path Loss (dB)
5	15	2.5	116.5
5	30	2.5	110.9
8	15	2.5	124.1
8	15	5	117.7
8	15	10	105
16	15	2.5	135.3
16	15	5	128.9
16	15	10	116.2
16	30	10	109.6
16	30	5	122.4
16	30	2.5	128.8

Table 6-1: Path Loss

6.2 Installation of Antenna System Components

The installation, removal, or maintenance of any antenna system components must be undertaken only by qualified and experienced personnel.

6.2.1 Antennas

The two most common types of antenna are the omnidirectional ('omni') and directional (Yagi).

An **omni** typically has 3-6dBi gain and spreads its energy in all directions (hence the name 'omnidirectional'). The 'pattern' of the energy field is in the shape of a donut, with the antenna mounted vertically at the centre. This vertical-mounted antenna produces a signal which is vertically 'polarized'.

A **Yagi** has a more focused antenna pattern, which results in greater gain: commonly, 6-12dBi. The pattern of a Yagi is in the shape of a large raindrop in the direction in which the antenna is pointed. If the elements of the Yagi are perpendicular to the ground (most common orientation) the radiated signal will be vertically polarized; if parallel to the ground, the polarization is horizontal.

The network topology, application, and path calculation are all taken into consideration when selecting the various antenna types to be used in a radio network deployment.


6.0 Installation

6.2.2 2X2 MIMO Antenna Selection, Placement & Orientation

For optimal performance of the pMDDL modems one must consider and plan for the specific application and environment where the pMDDL modules will be used. Described below are some of the considerations that must be taken into account while using pMDDL modems.

Multipath Environments

A multipath environment is where the signal from origin to destination may not have a direct path as seen in the illustration below:



In a multipath rich conditions it is recommended that each pMDDL end have a pair (2) of omni directional antennas that have at least half-wavelength distance between them. A set of (4) Omni-directional antennas is good for a pair of pMDDL radios.

The wavelength* is determined by the specific frequency being used by the pMDDL. For example the length of a wavelength @ 2.450 MHz is 122 mm, therefore the half wavelength is 61 mm. This would mean that the pair of antennas on each pMDDL system would have to be spaced at least 61 mm apart.

** Refer to a wavelength calculator or antenna manufacturer for accurate wavelength calculations*

LOS (Line of Sight) Environments

In good LOS applications, where the main LOS signal is much stronger than other components, orthogonally polarized antennas on both radios will out perform other types of antennas in terms of spatial separation. With these types of antenna systems it is recommended to space each pair of antennas at least one or more wavelengths apart on each end of the system to achieve as much spatial diversity as possible.

- Circular polarized antennas (Left Hand Circular Polarization (LHCP) and Right Hand Circular Polarization (RHCP)) will work with circular polarized antennas (LHCP and RHCP) for best match.
- Circular polarized antennas (LHCP and RHCP) will work with linear orthogonal antennas (V-POL and H-POL) at about 3 db loss. This combination results in preferable performance for UAV applications as circular polarized antennas at GCS acquire adequate signal no matter what the UAV antennas' orientation change to.
- Linear polarized antennas (V-POL and H-POL) will work with linear orthogonal antennas (V-POL and H-POL) for best match.
- OMNI directional antennas work with OMNI directional antennas due to dimension & weight limitation, two antennas are one or more wavelengths apart.



Circular Polarized Antenna



Linear Orthogonal Antenna



OMNI Directional Antenna(s)

6.0 Installation



Direct human contact with the antenna is potentially unhealthy when a pMDDL is generating RF energy.

Always ensure that the pMDDL equipment is powered down (off) during installation.



To comply with FCC regulations, the maximum EIRP must not exceed 36dBm.



Installation, maintenance, and removal work must be done in accordance with applicable codes.

6.2.3 Coaxial Cable

The following types of coaxial cable are recommended and suitable for most applications (followed by loss at 2.4GHz, in dB, per 100 feet):

- LMR 195 (10.7)
- LMR 400 (3.9)
- LMR 600 (2.5)

For a typical application, LMR 400 may be suitable. Where a long cable run is required - and in particular within networks where there is not a lot of margin available - a cable with lower loss should be considered.

When installing cable, care must be taken to not physically damage it (be particularly careful with respect to not kinking it at any time) and to secure it properly. Care must also be taken to affix the connectors properly - using the proper crimping tools - and to weatherproof them.

6.2.4 Surge Arrestors

The most effective protection against lightning-induced damage is to install two lightning surge arrestors: one at the antenna, the other at the interface with the equipment. The surge arrestor grounding system should be fully interconnected with the transmission tower and power grounding systems to form a single, fully integrated ground circuit. Typically, both ports on surge arrestors are N-type female.

6.2.5 External Filter

Although the Pico Series is capable of filtering-out RF noise in most environments, there are circumstances that require external filtering. Paging towers and cellular base stations in close proximity to the pMDDL's antenna can desensitize the receiver. Microhard Systems Inc.'s external cavity filter eliminates this problem. The filter has two N-female connectors and should be connected inline at the interface to the RF equipment.

Appendix A: Serial Interface

Module (DCE)	Signal	Host (e.g. PC) (DTE)	
1	DCD →	IN	Arrows denote the direction that signals are asserted (e.g., DCD originates at the DCE, informing the DTE that a carrier is present).
2	RX →	IN	The interface conforms to standard RS-232 signals, so direct connection to a host PC (for example) is accommodated.
3	← TX	OUT	
4	← DTR	OUT	
5	SG		
6	DSR →	IN	
7	← RTS	OUT	The signals in the asynchronous serial interface are described below:
8	CTS →	IN	

DCD *Data Carrier Detect* - Output from Module - When asserted (TTL low), DCD informs the DTE that a communications link has been established with another device.

RX *Receive Data* - Output from Module - Signals transferred from the pMDDL are received by the DTE via RX.

TX *Transmit Data* - Input to Module - Signals are transmitted from the DTE via TX to the pMDDL.

DTR *Data Terminal Ready* - Input to Module - Asserted (TTL low) by the DTE to inform the module that it is alive and ready for communications.

SG *Signal Ground* - Provides a ground reference for all signals transmitted by both DTE and DCE.

DSR *Data Set Ready* - Output from Module - Asserted (TTL low) by the DCE to inform the DTE that it is alive and ready for communications. DSR is the module's equivalent of the DTR signal.

RTS *Request to Send* - Input to Module - A "handshaking" signal which is asserted by the DTE (TTL low) when it is ready. When hardware handshaking is used, the RTS signal indicates to the DCE that the host can receive data.

CTS *Clear to Send* - Output from Module - A "handshaking" signal which is asserted by the DCE (TTL low) when it has enabled communications and transmission from the DTE can commence. When hardware handshaking is used, the CTS signal indicates to the host that the DCE can receive data.

Notes: It is typical to refer to RX and TX from the perspective of the DTE. This should be kept in mind when looking at signals relative to the module (DCE); the module transmits data on the RX line, and receives on TX.

"DCE" and "module" are often synonymous since a module is typically a DCE device.

"DTE" is, in most applications, a device such as a host PC.

Appendix B: Firmware Recovery Procedure

In event that your unit becomes unresponsive it may be required to perform a firmware recovery procedure outlined below:

1. Download and save firmware file in a local folder, for example C:\;
2. Separate the PC from the network and set IP to static:

```
192.168.1.1
255.255.255.0
```

3. Connect PC Ethernet port to the Ethernet port of the modem to be recovered
4. Start a ping on the PC

```
C:\>ping 192.168.1.39 -t
Pinging 192.168.1.39 with 32 bytes of data:
Request timed out.
Request timed out.
```

5. Power cycle modem while pressing and holding CFG (Config) button;
6. Release the CFG button when ping responded:

```
C:\>ping 192.168.1.39 -t
Pinging 192.168.1.39 with 32 bytes of data:
Request timed out.
Request timed out.
Request timed out.
Reply from 192.168.1.39: bytes=32 time<1ms TTL=128
Reply from 192.168.1.39: bytes=32 time<1ms TTL=128
Reply from 192.168.1.39: bytes=32 time<1ms TTL=128
Reply from 192.168.1.39: bytes=32 time<1ms TTL=128
```

Note, If ping responds as shown above, then you can probably recover the unit, please proceed. Otherwise, send the unit back for RMA.

7. Now use TFTP to push firmware file into the corrupted unit:

For example, on Windows 7 using following command line:

```
tftp -i 192.168.1.39 put pMDDL-v1_3_0-r1005.bin (use the filename saved).
```

8. Wait until above command to successfully transferred the image, similar message should show


Transfer successful: xxxxxxxx bytes in 5 seconds, nnnnnnnn bytes/s, note the number might change for different firmware file

Note, if you see message above, the unit will re-flash itself and reboot, otherwise call for help or send back for RMA.

9. Wait for the unit to recover and reboot.

Appendix D: Serial Port Extension

The pMDDL can support a second serial port by utilizing a FT234XD USB to serial UART interfaced to the USB lines of the pMDDL. The sample circuit below shows how this is done.



Drawing App-D: FTDI USB to Basic UART

