

Operating Manual

pMDDL900
2x2 MIMO OEM 900 MHz Digital Data Link

Document: pMDDL900.Operating Manual.v1.0.0.pdf
FW: v1.4.0 Build 1013-2



Important User Information (continued)

Regulatory Requirements / Exigences Réglementaires



WARNING:

To satisfy FCC RF exposure requirements for mobile transmitting devices, a separation distance of 23 cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended. The antenna used for this transmitter must not be co-located in conjunction with any other antenna or transmitter.



WARNING:

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.



WARNING:

Changes or modifications not expressly approved by Microhard Systems Inc. could void the user's authority to operate the equipment. This device has been tested with UFL to Reverse Polarity SMA connectors with the antennas listed in Appendix A. When integrated in OEM products, fixed antennas require installation preventing end-users from replacing them with non-approved antennas. Antennas not listed in the tables must be tested to comply with FCC Section 15.203 (unique antenna connectors) and Section 15.247 (emissions).



WARNING:

MAXIMUM EIRP

FCC Regulations allow up to 36 dBm equivalent isotropically radiated power (EIRP). Therefore, the sum of the transmitted power (in dBm), the cabling loss and the antenna gain cannot exceed 36 dBm.



WARNING:

EQUIPMENT LABELING

The FCC and IC numbers depend on the model of the radio module. Do NOT use the Marketing Name of the product but the Model to distinguish the Certifications Numbers. This device has been modularly approved. The manufacturer, product name, and FCC and Industry Canada identifiers of this product must appear on the outside label of the end-user equipment.



WARNING:

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

(1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

SAMPLE LABEL REQUIREMENT / EXIGENCE D'ÉTIQUETTE:

pMDDL900:

FCCID: Pending
IC: Pending

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

Applicable Regulatory Approvals

Model	FCC	Industry Canada

Please Note: These are only sample labels; different products contain different identifiers. The actual identifiers should be seen on your devices if applicable.

1.0 Overview

1.2 Specifications

For detailed specifications, please see the specification sheets available on the Microhard website @ <http://www.microhardcorp.com> for your specific model.

Electrical/General

Frequency:	902 - 928 MHz
Link Rate:	See <u>Section 1.3 Performance Specifications</u>
TX Power:	7 dBm - 30 dBm Total (Adjustable)
Channel Bandwidth:	4 or 8 MHz (Selectable)
Error Detection/Control:	CRC, ARQ
Data Encryption*: <i>(*Requires Export Permit)</i>	128-bit AES (Optional 256-bit)
Serial Port:	300bps to 921kbps - TTL Level RS232
Ethernet:	Dual 10/100 BaseT, Auto - MDI/X, IEEE 802.3
USB:	2.0
Network Protocols:	TCP, UDP, TCP/IP, ARP, ICMP, DHCP, HTTP, HTTPS*, SSH*, SNMP, FTP, DNS, Serial over IP (*May require an export permit)
Operating Modes:	Master, Slave/Remote, Repeater, Mesh Node
Management:	Local Serial Console, Telnet, WebUI, SNMP, FTP & Wireless Upgrade
Diagnostics:	Status LED's, RSSI, remote diagnostics, SNR
Input Voltage:	OEM: Digital Voltage: 3.3 VDC (500mA) RF Voltage: 5.0 VDC (1.5A)

Current:


	Tx Power (dBm)	MIMO ON		MIMO OFF	
		Vcc @ 3.3V	VRF @ 5V	Vcc @ 3.3V	VRF @ 5V
Peak Avg. Transmit Current (mA)	20	250 - 720	630	250 - 560	350
	22	250 - 720	720	250 - 560	400
	24	250 - 720	800	250 - 560	440
	26	250 - 720	880	250 - 560	510
	28	250 - 720	1020	250 - 560	600
	30	250 - 720	1250	250 - 560	780
Instantaneous Current Draw	-	500	1500	500	1500
Typical Receive Current Draw (mA)	-	250-720	-	250 - 560	

Table 1-1: pMDDL900 Current Consumption


2.0 Quick Start

2.2 Simple Master and Slave - Auto (Using Defaults)

This **Quick Start** example requires (2) pMDDL900 units, one will be configured as a Master (M), the second unit will be configured as a Slave/Remote (S). This example will use factory defaults to set up each unit so that a simple network will be established.



- ✓ Use [Section 2.1 Getting Started](#) to power up a pair of pMDDL900 modules mounted in a Pico Ethernet Motherboard.
- ✓ **Master:** Once the pMDDL900 is fully booted (solid blue CPU LED), press and hold the CFG button. Once the CPU LED begins to flash, continue to hold for at least **10 seconds**, then release.




- ✓ The pMDDL900 will then reset all settings to default values, and set the following settings that are required to automatically create a link with a slave:
 - IP Address: **192.168.168.1**, Operating Mode: **Master**
 - Network ID: **pMDDL**, Channel Bandwidth: **8 MHz**
 - Channel-Frequency: **917 MHz**
- ✓ **Slave:** Ensure the pMDDL900 is fully booted (solid blue CPU LED), then press and hold the CFG button. Once the CPU LED begins to flash, continue to hold for **5 seconds**, then release.
- ✓ The pMDDL900 will then reset all settings to default values, and set the following settings that are required to automatically create a link with a slave:
 - IP Address: **192.168.168.2**, Operating Mode: **Slave**
 - Network ID: **pMDDL**, Channel Bandwidth: **8 MHz**
 - Channel-Frequency: **917 MHz**
- ✓ Once both units have finished changing settings (~60 seconds) a wireless link should automatically be established between them, this can be seen by observing the RSSI LEDs, they should be on solid, indicating a link (the more LEDs illuminated = stronger the link).

2.0 Quick Start

2.3.1 Configuring the Master (Con't)

- ✓ Configure the pMDDL900 as a Master

Select **Wireless** from the top/main navigation, and then **RF** from the submenu list.





In the **RF Configuration** ensure the **Compatibility Mode**, **Channel Bandwidth** and **Channel-Frequency** are set the same on each module.

For bench or close proximity testing it is best to use a lower power setting to prevent RF saturation. Select 20dBm from the **TX Power** setting.

Select **Master** from the **Operation Mode** dropdown box.

Set a **Network ID**, which will need to be the same on each unit in the network. This example uses **TEST_ID**.



The remaining settings in the **Wireless** menu should be left as defaults for this exercise.

Refer to **Section 5.3 Wireless** for additional information.

Click on the **Submit** button to write the changes to the pMDDL900. The **Cancel** button will revert back to previously saved values



If any additional settings need to be changed, ensure they are also changed on the Slave.

3.0 Hardware Features



Caution: During power up or reset, output pins from the Pico are in an unknown state. It is advised to use pull up or pull down resistors as appropriate.

Pin Name	No.	Description	Dir
GND	1,17,25-26,39-40,65-80, 81-116	Ground reference for logic, radio, and I/O pins.	
DNC	2,3,4,5,6	Reserved for factory use only.	
NC	7,8,9,10,12,27,33,35,36,37,38,45,46,47,48,50,51,52,53,54,59	<i>*Currently Not Supported. For Future Expansion*</i>	
CPU STATUS LED	11	Active high output indicates CPU/Module status. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
ETH_BIAS	13	Bias Voltage to Ethernet PHY transformer	
USB_MODE	14	Indicates if the interface is in host/device mode. 0 = Device (Connected through 1K resistor to GND), 1 = Host.	I
Config	15	Active low. In normal mode, pull it low and hold for more than 8 seconds will reset the system to default settings. Pull it low upon power up will put the module into recovery mode.	I
RESET	16	Active low input will reset module	I
USBDP	18	USB D+ signal; carries USB data to and from the USB 2.0 PHY	
USBDM	19	USB D- signal; carries USB data to and from the USB 2.0 PHY	
LED_1 (RSSI1)	20	Receive Signal Strength Indicator 1. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
LED_2 (RSSI2)	21	Receive Signal Strength Indicator 2. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
LED_3 (RSSI3)	22	Receive Signal Strength Indicator 3. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
LED_RX	23	Active high output indicates receive and synchronization status. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
LED_TX	24	Active high output indicates module is transmitting data over the RF channel. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
Serial RxD	28	Receive Data. Logic level input into the modem. It is recommended to wire this pin out through a zero ohm resistor to a header and jumper block for external access to the serial port for modem recovery procedures.	I
Serial TxD	29	Transmit Data. Logic level Output from the modem. It is recommended to wire this pin out through a zero ohm resistor to a header and jumper block for external access to the serial port for modem recovery procedures.	O
Serial DSR	30	Data Set Ready. Active low output. <i>The DSR line set high enables the transmitter of the RS485 driver.</i>	O
Serial CTS	31	Clear To Send. Active low output.	O
Serial DTR	32	Data Terminal Ready. Active Low output.	O
Serial RTS	34	Request To Send. Active low input.	I

Table 3-3: pMDDL900 Pin Description

All serial communications signals are logic level (0 and 3.3V). DO NOT connect RS-232 level (+12, -12VDC) signals to these lines without shifting the signals to logic levels.

3.0 Hardware Features



Caution: During power up or reset, output pins from the Pico are in an unknown state. It is advised to use pull up or pull down resistors as appropriate.

Pin Name	No.	Description	Dir
RX_N4	41	Ethernet Port 4 (WAN) Receive Pair	
RX_P4	42		
TX_N4	43	Ethernet Port 4 (WAN) Transmit Pair	
TX_P4	44		
ETH4 LINK_LED	49	Active high output indicates Ethernet port 4 link status. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
TX_P0	55	Ethernet Port 0 (LAN) Transmit Pair	
TX_N0	56		
RX_N0	57	Ethernet Port 0 (LAN) Receive Pair	
RX_P0	58		
ETH0 LINK_LED	60	Active high output indicates Ethernet port 0 link status. Active high, cannot drive LED directly. Requires current limiting resistor. 8mA maximum.	O
Vdd	61,62	Positive voltage supply voltage for the digital section of the module (3.3V).	I
Vpa	63,64	Positive voltage supply voltage for the radio module (3.3-5V).	I


Table 3-3: pMDDL900 Pin Description (continued)

All serial communications signals are logic level (0 and 3.3V). DO NOT connect RS-232 level (+12, -12VDC) signals to these lines without shifting the signals to logic levels.

See **Appendix D: Sample Interface Schematic** for a sample schematic that can be used to interface to the pMDDL900 OEM module.

3.1.5 USB Device Mode

The pMDDL900 can be set to operate as a USB Device. When set as a USB device, Microhard Composite Drivers can be installed on a USB Host to provide Ethernet and Serial functionality to the USB port on the pMDDL900. To enable USB Device mode, Pin 14 must be connect to GND through a 1K resistor as shown below:



Drawing 3-6: pMDDL900 USB Device Mode

3.0 Hardware Features

3.2.2 pMDDL900 Development Board Connectors & Indicators




Figure 3-4: pMDDL900 Development Board

Antennas:

The pMDDL900 OEM module uses a UFL connectors, Ensure proper orientation as seen above to prevent damage to the pMDDL900 module and to the development board. ANT1 and ANT2 are marked on the module.

Ethernet LAN:

The Ethernet LAN port is a standard RJ45 port to connect local network devices. The default IP address for this port is 192.168.168.1.

Ethernet WAN:


The Ethernet WAN port is a standard RJ45 Port that can be used as a separate WAN port for Router functions, or can be bridged (via software) to the LAN as a additional switch port for local devices.

The pMDDL900 development board can be powered using **Passive PoE from 12–30 VDC Maximum** on the WAN port using a PoE injector that meets the following requirements:

Ethernet RJ45 Connector Pin Number								
Source Voltage	1	2	3	4	5	6	7	8
12 - 30 Vdc	Data	Data	Data	DC+	DC+	Data	DC-	DC-

Table 3-2: Ethernet (WAN) PoE Connections

Power



Power:

The pMDDL900 development board can powered using an input voltage in the 9-30 VDC range.

3.0 Hardware Features

Config Button:

The Config button on the pMDDL900 can be used to either reset the modem into its factory default configuration, or it can be used to perform a firmware recovery procedure.

Factory Default Settings: While power is applied and the pMDDL900 in an operational state, press and hold the *Config* Button for more than 10 seconds to reset to a factory default Master, alternatively hold the button for 5 seconds for a factory default Slave.

Firmware Recovery: To load the firmware on the unit it is recommended to use the normal WebUI to perform a firmware update (Maintenance). In the event that the firmware cannot be loaded using the standard WebUI (non responsive unit), pressing and holding the *Config* Button while powering-up the module will force the pMDDL900 into a firmware recovery mode. There are 3 main modes, HTTP, TFTP and Master Reset. The table below shows the time required to hold the *Config* button while power is applied:

0 to 5 seconds HTTP Recovery	5 to 10 seconds TFTP Recovery	10 to 15 seconds Master Reset	15+ seconds No Effect
---------------------------------	----------------------------------	----------------------------------	--------------------------

HTTP Recovery: Set an IP on a PC to 192.168.1.1. Open a web browser and Navigate to 192.168.1.39. This will open a simple webpage which will allow a firmware file to be loaded.

TFTP Recovery: Set an IP on a PC to 192.168.1.1. Use a TFTP session to push the firmware file to the modems recovery IP of 192.168.1.39. See Appendix for Firmware Recovery Procedure.

Master Reset: Runs Master Reset, file system is erased.

RS232 Serial:

The RS232/485 Serial data port can be used to communicate with Serial devices or it can be configured to operate as a console port. See Table 3-3 for pin assignments.

RS232/RS485 modes are selected through the serial port configuration in the WebUI.

CPU/Status:

The CPU/Status LED indicates that power has been applied to the module. A Solid LED indicates normal operation, while flashing indicates boot or firmware upgrade status.

TX/RX LEDs:

The TX/RX LEDs indication wireless traffic to/from the pMDDL900 module.

RSSI LEDs:

The RSSI LEDs indicate the Received Signal Strength on the Wireless Link. On a Master it will indicate an average RSSI value based on connected units. On a Slave the RSSI LEDs will represent the signal strength between the Slave and the Master it is connected to. (The more LEDs illuminated, the stronger the signal)

Pin No.	RS232	RS485 Full-Dup	RS485 Half-Dup
1	DCD		
2	RXD	TX-	Data-
3	TXD	RX+	
4	DTR		
5	Ground		
6	DSR		
7	RTS	RX-	
8	CTS	TX+	Data+
9	N/C		

Table 3-3: Data DE9 RS232 Pin Assignment

4.0 Configuration

4.1 System

The main category tabs located at the top of the navigation bar separate the configuration of the pMDDL900 into different groups based on function. The System Tab contains the following submenus:

- Summary - Status summary of entire radio including network settings, version information, and radio connection status.
- Settings - Host Name, System Log Settings, System Time/Date.
- Services - Enable/Disable and configure port numbers for SSH, Telnet, HTTP and HTTPS services.
- Maintenance - Remote firmware Upgrades, reset to defaults, configuration backup and restore.
- Reboot - Remotely reboot the system.

4.1.1 System > Summary

The System Summary screen is displayed immediately after initial login, showing a summary and status of all the functions of the pMDDL900 in a single display. This information includes System Status, LAN/WAN network information, version info, Radio Status etc.

System	Network	Wireless	Firewall	Serial	Diag	Admin
<div style="background-color: #333; color: white; padding: 2px;"> Summary Settings Services Maintenance Reboot </div>						
System Information						
System Information						
Host Name	UserDevice	Description	mypMDDL900			
Product Name	pMDDL900	System Date	2018-10-16 16:46:40			
Hardware Version	Rev A	System Uptime	5 min			
Software Version	v1.4.0	Build Date	2018-10-16			
Software Build	1013-2	Build Time	16:41:05			
LAN Status						
MAC Address	00:0F:92:04:1A:EF	Connection Type	static			
IP Address	192.168.168.1	Gateway	192.168.168.1			
Subnet Mask	255.255.255.0					
WAN Status						
MAC Address	00:0F:92:05:1A:EF	Connection Type	dhcp			
IP Address	N/A	Gateway	N/A			
Subnet Mask	N/A	Secondary DNS	N/A			
Primary DNS	N/A					
RF Status						
General Status						
MAC Address	Operation Mode	Network ID	Bandwidth	Frequency	Tx Power	Encryption Type
00:0F:92:11:11:11	Master	pMDDL	8 MHz	917 MHz	20 dBm	AES-128
Traffic Status						
Receive Bytes	Receive Packets	Transmit Bytes	Transmit Packets			
0B	0	41.491KB	345			
<input type="button" value="Stop Refreshing"/> Interval: 20(in seconds)						
Copyright © 2017-2018 Microhard Systems Inc. pMDDL900						

Image 4-1-1: System Summary Window

4.0 Configuration

CFG Reset to Default Button

Enabled by default, when the CFG button on the front of the pMDDL900 is held down for 10s while the unit is powered up, the unit will reset and all settings will be reset to factory defaults. When disabled the unit will reset, but the settings will not be overwritten.

Values (Selection)

Enable
Disable

System Log Server IP

The pMDDL900 can report system level events to a third party System Log server, which can be used to monitor events reported by the pMDDL900.

IP Address

0.0.0.0

System Log Server Port

Enter the UDP listening port of the System Log Server. The default port number is generally 514, but could vary from Server to Server.

UDP Port

514

Time Settings

The pMDDL900 can be set to use a local time source, thus keeping time on its own, or it can be configured to synchronize the date and time via a NTP Server. The options and menus available will change depending on the current setting of the Date and Time Setting Mode, as seen below.

Time Settings	
Current Date(yyyy-mm-dd)	2018-10-12
Current Time(hh:mm:ss)	14:43:40
Date and Time Setting Mode	<input checked="" type="radio"/> Local Time <input type="radio"/> NTP
Date (yyyy-mm-dd)	<input type="text" value="2018-10-12"/>
Time (hh:mm:ss)	<input type="text" value="14:43:40"/>

Time Settings	
Current Date(yyyy-mm-dd)	2018-10-12
Current Time(hh:mm:ss)	14:43:40
Date and Time Setting Mode	<input type="radio"/> Local Time <input checked="" type="radio"/> NTP
Timezone	<input type="text" value="Mountain Time"/>
POSIX TZ String	<input type="text" value="MST7MDT,M3.2.0,M11.1.0"/>
NTP Server IP/Name	<input type="text" value="pool.ntp.org"/>
NTP Local Port	<input type="text" value="123"/>
NTP Client Interval (seconds)	<input type="text" value="0"/> [15 ~ 65535] 0-Disable

Image 4-1-3: System Settings > Time Settings



Network Time Protocol (NTP) can be used to synchronize the time and date of computer systems with a centralized, referenced server. This can help ensure all systems on a network have the same time and date.

Date and Time Setting Mode

Select the Date and Time Setting Mode required. If set for 'Local Time' the unit will keep its own time and not attempt to synchronize with a network server. If 'NTP' is selected, a NTP server can be defined.

Values (selection)

Local Time
NTP

4.0 Configuration


	Date
The calendar date may be entered in this field. Note that the entered value is lost should the pMDDL900 lose power for some reason.	Values (yyyy-mm-dd) 2016-01-12 (varies)
	Time
The time may be entered in this field. Note that the entered value is lost should the pMDDL900 lose power for some reason.	Values (hh:mm:ss) 11:27:28 (varies)
	Timezone
If connecting to a NTP time server, specify the time zone from the dropdown list.	Values (selection) <i>(varies)</i>
	POSIX TZ String
This displays the POSIX TZ String used by the unit as determined by the Timezone setting.	Values (read only) <i>(varies)</i>
	NTP Server
Enter the IP Address or domain name of the desired NTP time server.	Values (address) pool.ntp.org
	NTP Port
Enter the IP Address or domain name of the desired NTP time server.	Values (port#) 123
	NTP Client Interval
By default the modem only synchronizes the time and date during system boot up (default: 0), but it can be modified to synchronize at a regular interval. <i>This process does consume data and should be set accordingly.</i>	Values (seconds) 0

4.0 Configuration

4.2 Network

4.2.1 Network > Status

The Network Summary display gives a overview of the currently configured network interfaces including the Connection Type (Static/DHCP), IP Address, Net Mask, Default Gateway, DNS, and IPv4 Routing Table.



Network Status

LAN Port Status

General Status

IP Address	Connection Type	Subnet Mask	MAC Address
192.168.168.1	static	255.255.255.0	00:0F:92:02:AA:15

Traffic Status

Receive bytes	Receive packets	Transmit bytes	Transmit packets
355.176KB	3849	857.981KB	3322

WAN Port Status

General Status

IP Address	Connection Type	Subnet Mask	MAC Address
N/A	dhcp	N/A	00:0F:92:03:AA:15

Traffic Status

Receive bytes	Receive packets	Transmit bytes	Transmit packets
0B	0	0B	0

Default Gateway

Gateway
192.168.168.1

DNS

DNS Server(s)
None

IPv4 Routing Table

Destination	Gateway	Subnet Mask	Flags	Metric	Ref	Use	Interface
0.0.0.0	192.168.168.1	0.0.0.0	UC	0	0	0	(br-lan)
192.168.168.0	0.0.0.0	255.255.255.0	U	0	0	0	(br-lan)

[Stop Refreshing](#) Interval: 20 (in seconds)

Image 4-2-1: Network > Network Status

4.0 Configuration



The factory default network settings:

IP: 192.168.168.1
Subnet: 255.255.255.0
Gateway: 192.168.168.1



A SUBNET MASK is a bit mask that separates the network and host (device) portions of an IP address.

The 'unmasked' portion leaves available the information required to identify the various devices on the subnet.



A GATEWAY is a point within a network that acts as an entrance to another network.

In typical networks, a router acts as a gateway.



Within any IP network, each device must have its own unique IP address.

IGMP Snooping

Enable or disable IGMP snooping on the pMDDL900. **IGMP snooping** is the process of listening to Internet Group Management Protocol traffic. This allows the pMDDL900 to listen in on the **IGMP** conversations between network devices. The pMDDL900 then maintains a map of which links need which IP multicast streams.

Values (selection)

On
Off

Connection Type

This selection determines if the pMDDL900 will obtain an IP address from a DHCP server on the attached network, or if a static IP address will be entered. If a Static IP Address is chosen, the fields that follow must also be populated.

Values (selection)

DHCP
Static

IP Address

If 'Static' Connection Type is selected, a valid IPv4 Address for the network being used must be entered in the field. If 'DHCP' is chosen this field will not appear and it will be populated automatically from the DHCP server.

Values (IP Address)

192.168.168.1

Netmask

If 'Static' Connection Type is selected, the Network Mask must be entered for the Network. If 'DHCP' is chosen this field will not appear and it will be populated automatically from the DHCP server.

Values (IP Address)

255.255.255.0

Default Gateway

If the pMDDL900 is integrated into a network which has a defined gateway, then, as with other hosts on the network, this gateway's IP address will be entered into this field. If there is a DHCP server on the network, and the Connection Type (see previous page) is selected to be DHCP, the DHCP server will populate this field with the appropriate gateway address.

Values (IP Address)

(no default)

A simple way of looking at what the gateway value should be is: If a device has a packet of data it does not know where to send, send it to the gateway. If necessary - and applicable - the gateway can forward the packet onwards to another network.

DNS

Set the DNS (Domain Name Server) for use by devices on the LAN port, if required.

Values (IP Address)

(no default)

4.0 Configuration

Metric

In some cases there may be multiple routes to reach a destination. The Metric can be set to give certain routes priority, the lower the metric is, the better the route. The more hops it takes to get to a destination, the higher the metric.

Values (Integer)

0

Interface

Define the exit interface. Is the destination a device on the LAN, LAN1 (If physical WAN port is bridged as an independent LAN), or the WAN?

Values (Selection)

LAN / LAN1 / WAN / USB /
None

4.0 Configuration

4.2.8 Network > Device List

The Network > Device List shows the current ARP table for the local network adapter. The MAC address and IP address are shown, however not only DHCP assigned devices are listed in the device list, any devices, even those statically assigned, that are connected through the local network interface (s) are displayed, including those connected through a hub or switch.

Devices can also be filtered by the network that they are attached to. Devices with a MAC and no IP and vice versa can also be filtered.



Network Device List

Select networks: LAN WAN

Show MACs without IP

Show IPs without MAC

Network	MAC Address	IP Address	State	Ageing Timer
LAN	a6:12:20:f4:9a:0d	192.168.168.132	REACHABLE	0.22

Image 4-2-11: Network > Device List

4.0 Configuration

4.3 Wireless

4.3.1 Wireless > Status

The Status window gives a summary of all radio or wireless related settings and connections.

The **General Status** section shows the MAC address of the current radio, the Operating Mode (Master, Slave etc), the Network ID being used, the Compatibility Mode, Channel Bandwidth and frequency information and the type of security used.

Traffic Status shows statistics about the transmitted and received data.


The pMDDL900 shows information about all Wireless connections in the **Connection Info** section. The MAC address, TX & RX Modulation, Signal to Noise ratio (SNR), Signal Strength (RSSI), and a graphical representation of the signal level or quality, as well as a RSSI Graph Link.

System	Network	Wireless	Firewall	Serial	Diag	Admin
Status RF						
Wireless Interfaces						
RF Status						
General Status						
MAC Address	Operation Mode	Network ID	Bandwidth	Frequency	Tx Power	Encryption Type
00:0F:92:11:11:11	Master	pMDDL	8 MHz	917 MHz	20 dBm	AES-128
Traffic Status						
Receive Bytes	Receive Packets	Transmit Bytes	Transmit Packets			
0B	0	42.954KB	361			
Connection Info (0)						
MAC Address	Tx Mod (MIMO)	Rx Mod (MIMO)	SNR (dB)	RSSI (dBm)	Signal Level	RSSI Graph

RSSI Graph - 00:0F:92:FE:00:B8

RSSI -75 dBm

History: Min -77 Max -70



-25 dBm

-50 dBm

-75 dBm

Copyright © 2014-2015 Microhard Systems Inc. pDDL

Image 4-3-1: Wireless > Status (RSSI Graph Shown Below)

4.0 Configuration

TX Rate

This setting determines the modulation type and in turn the rate at which the data is to be wirelessly transferred.

The default and recommended setting for both Master and Slave units is 'Auto'. When in 'Auto' the unit will transfer data at the highest possible rate in consideration of the receive signal strength (RSSI).

Refer to Section 1.3 Performance Specifications for a table breakdown of performance at selected rates. If setting a fixed TX Rate It is recommended to retain a fade margin of at least 10 dBm for optimum performance. For example, for a link (8MHz channel) with a signal strength of at least -75dBm , a TX rate of 16-QAM 3/4 FEC is recommended. Setting to the highest rate with a poor link may result in reduced performance.

Values (selection)

Auto (recommended)

64-QAM 5/6 FEC
64-QAM 3/4 FEC
64-QAM 2/3 FEC
16-QAM 3/4 FEC
16-QAM 1/2 FEC
QPSK FEC 3/4
QPSK FEC 1/2

Extended Addressing

Enable or disable extended addressing.

For multicast traffic sending from the Master to multiple receivers, it is recommended to configure the system with "Extended Addressing" disabled and also select a proper multicast rate defined by the link budget. In this case, the multicast traffic will be delivered on the specified RF rate to multiple receivers without adding extra overhead to the RF link. Devices on the Slaves side just need to subscribe the multicast address being used by the transmitting device connected on the Master side.

Values (selection)

On / Off



Change the default value for the Network ID to something unique for your network. Do this for an added measure of security and to differentiate your network from others which may be operating nearby.

Multicast Rate

When the Operation Mode is set to Repeater, this parameter will appear allowing the rate selection of multicast traffic.

Values (selection)

QPSK FEC 1/2
QPSK FEC 3/4
16-QAM 1/2 FEC
16-QAM 3/4 FEC
64-QAM 2/3 FEC

Network ID / Mesh ID

Each network of pMDDL900 modules must an a unique Network ID. This Network ID must be set in each unit on the network.

When configured to operate as a Mesh Network, this becomes the Mesh ID and must be specified on every unit to participate.

Values

pMDDL

Encryption Type

The encryption types defines the type of security used for the Wireless Interface, to join a network a device must know the correct Encryption Key. Security options are dependent on the version type. Export versions may not have all optional available to meet regulatory requirements set government policies.

Values (selection)

Disabled
AES-128

4.0 Configuration

4.4.2 Firewall > General

The General Firewall settings allow users to enable or disable the firewall, and to decide which areas of the modem to protect. The Firewall can also be reset to factory defaults from this area of the WebUI.

System	Network	Wireless	Firewall	Serial	Diag	Admin
Summary	General	Port Forwarding	MAC-IP List	Rules	Firewall Default	
Firewall General						
Firewall General Configuration						
WAN Remote Management		<input checked="" type="radio"/> Enable <input type="radio"/> Disable				
WAN Request		<input type="radio"/> Block <input type="radio"/> Allow				
LAN to WAN Access Control		<input type="radio"/> Block <input checked="" type="radio"/> Allow				
Anti-Spoof		<input type="radio"/> Enable <input checked="" type="radio"/> Disable				
Packet Normalization		<input type="radio"/> Enable <input checked="" type="radio"/> Disable				

Image 4-4-2: Firewall > General

WAN Remote Management

Allow remote management of the pMDDL900 on the WAN side using the WebUI on port 80(HTTP), and 443 (HTTPS). If disabled, the configuration can only be accessed from the LAN.

Values

Enable / Disable

WAN Request

When Blocked the pMDDL900 will block all requests from devices on the WAN unless specified otherwise in the Access Rules, MAC List, IP List configurations. Access to ports 80 (HTTP) and 443 (HTTPS-if enabled), is still available unless disabled in the **WAN Remote Management** option.

Values

Block / Allow

LAN to WAN Access Control

Allows or Blocks traffic from the LAN accessing the WAN unless specified otherwise using the Access Rules, MAC, and IP List configuration.

Values

Block / Allow

Anti-Spoof

The Anti-Spoof protection is to create some firewall rules assigned to the external interface (WAN) of the firewall that examines the source address of all packets crossing that interface coming from outside. If the address belongs to the internal network or the firewall itself, the packet is dropped.

Values

Enable / Disable

Packet Normalization

Packet Normalization is the normalization of packets so there are no ambiguities in interpretation by the ultimate destination of the packet. The scrub directive also reassembled fragmented packets, protecting some operating systems from some forms of attack, and drops TCP packets that have invalid flag combinations.

Values


Enable / Disable

4.0 Configuration

4.4.3 Firewall > Port Forwarding

The pMDDL900 can be used to provide remote access to connected devices. To access these devices a user must define how incoming traffic is handled by the pMDDL900. If all incoming traffic is intended for a specific connected device, DMZ could be used to simplify the process, as all incoming traffic can be directed towards a specific IP address.

In the case where there is multiple devices, or only specific ports need to be passed, Port forwarding is used to forward traffic coming in from the WAN to specific IP Addresses and Ports on the LAN. Port forwarding can be used in combination with other firewall features, but the Firewall must be enabled for Port forwarding to be in effect. If the WAN Request is blocked on the General Tab, additional rules and/or IP Lists must be set up to allow the port forwarding traffic to pass through the firewall.



Firewall Port Forwarding

Notice

Port Forwarding Rules are taken into consideration after the General firewall settings are applied. If the WAN traffic is blocked, additional rules must be created:

1. Add rules in the Rules configuration to open ports or allow IP addresses.
2. Create a firewall rule in the Firewall->Rules page to allow desired connections.

Firewall DMZ Configuration

DMZ Source: WAN

DMZ Mode:

DMZ Server IP:

Exception Ports:

Combined with source NAT:

Firewall Port Forwarding Configuration

Name:

Source:

Internal Server IP:

Internal Ports:

Protocol:

External Ports:

Combined with source NAT:

Firewall Port Forwarding Summary

Name	Source	Internal IP	Internal Port	Protocol	External Port	SNAT
forward1	WAN	192.168.2.1	3000	TCP	2000	No



If DMZ is enabled and an exception port for the WebUI is not specified, remote management will not be possible. The default port for remote management is TCP 80.

Image 4-4-3: Firewall > Port Forwarding

DMZ Mode

Enable or disable DMZ Mode. DMZ can be used to forward all traffic to the DMZ Server IP listed below.

Values (selection)

Disable / Enable

DMZ Server IP

Enter the IP address of the device on the LAN side of the pMDDL900 where all the traffic will be forwarded to.

Values (IP Address)

192.168.100.100

4.0 Configuration

4.4.5 Firewall > Rules

The Rules configuration can be used to define specific rules on how local and remote devices access different ports and services. MAC List and IP List are used for general access, and are applied before rules are processed.

It is highly recommended to block as much traffic as possible from the modem, especially when using a public IP address. The best security would be to allow traffic only from trusted IP addresses, and only the specific ports being used, and block everything else. Not configuring the firewall and the firewall rules correctly could result in unpredictable data charges from your provider.




Image 4-4-5: Firewall > Rules

Rule Name

The rule name is used to identify the created rule. Each rule must have a unique name and up to 10 characters can be used.

Values (10 Chars)

characters

Rule Type

Specify the rule type by the direction and source/destination.

Values (selection)

Input: Data entering the modem (Example: Serial Data)

Output: Data exiting the modem

Forward: Data passing through the modem to an external device (A forward rule is required in Port Forwarding is used and the WAN Request is set to block traffic.)

Input
Output
Forward

Action

The Action is used to define how the rule handles the connection request.

Values (selection)

ACCEPT will allow a connection, while REJECT (error) and DROP (quietly dropped), will refuse connections.

This is configured based on how the **WAN Request** and **LAN to WAN Access Control** are configured in the previous menus.

ACCEPT
DROP
REJECT

4.0 Configuration

4.5 Serial

4.5.1 Serial > Summary

The Serial > Summary window gives a summary of the on board serial data port. A second serial port can be added to the pMDDL900 OEM by interfacing a FTDI USB to Basic UART IC as shown in **Appendix D: Serial Port Extension**.

GS0 - If the pMDDL900 has been set to USB Device mode (Pin 14 connected to GND through a 1K resistor), the GS0 tab will appear and the USB port can be used to connect to a USB host that has the Microhard Composite Drivers installed. The USB port will appear as a serial device on the host system.

The Summary window shows a number of status items that aid in viewing the operation, statistics, and troubleshooting of the RS232/485 & USB Serial Ports.

General Status

- Port - Shows if the data port has been configured for RS232, RS485-FD or RS485-HD
- Port Status - Shows if the data port has been enabled in the configuration.
- Baud Rate - The current baud rate used to interface with the connected device.
- Connect As - The type of IP Protocol Config is displayed here (TCP, UDP, SMTP, PPP, etc)
- Connect Status - Shows if there are any current connections / if the port is active.



Port	Status	Baud Rate	Connect As	Connect Status	Receive bytes	Receive packets	Transmit bytes	Transmit packets
RS232	Enable	115200	TCP Server	Not Active	0 B	0	0 B	0
GS0	Enable	115200	TCP Server	Not Active	0 B	0	0 B	0


Stop Refreshing Interval: 20 (in seconds)

Image 4-5-1: Serial > Summary

4.0 Configuration

4.6.2 Serial > Settings

This menu option is used to configure the serial device server for the serial communications port. Serial device data may be brought into the IP network through TCP, UDP, or multicast; it may also exit the pMDDL900 network on another pMDDL900 serial port. The fully-featured RS232 interface supports hardware handshaking.



The screenshot shows the 'Serial Port Configuration' settings page. The interface includes a navigation menu with 'System', 'Network', 'Wireless', 'Firewall', 'Serial', 'Diag', and 'Admin'. The 'Serial' menu is selected, and the 'Settings' sub-menu is active. The configuration is divided into two sections: 'Port Configuration' and 'TCP Configuration'.

Port Configuration	
Port status	Data
Port Mode	RS232
Escape Sequence	Disabled
Data Baud Rate	115200
Data Format	8N1
Data Mode	<input checked="" type="radio"/> Seamless <input type="radio"/> Transparent
Character Timeout	24
Maximum Packet Size	256
No-Connection Data	<input type="radio"/> Disable <input checked="" type="radio"/> Enable
MODBUS TCP Status	<input checked="" type="radio"/> Disable <input type="radio"/> Enable
IP Protocol Config	TCP Client

TCP Configuration	
Remote Server IP Address	0.0.0.0
Remote Server port	20002
Outgoing Connection Timeout(seconds)	5
Fast Recovery	<input checked="" type="radio"/> Disable <input type="radio"/> Enable

Image 4-5-2: Serial > Settings Configuration

4.0 Configuration

Port Status

Select operational status of the Serial Port. The port is in console mode by default.

Values (selection)

Data / **Console**

Port Mode

Select the operational mode of the serial data port.

Values (selection)

RS232
RS485 Full Duplex
RS485 Half Duplex

Escape Sequence

Enabling the escape sequence allows users to temporarily exit data mode and enter console mode for the serial port.

Values (selection)

Enabled / **Disabled**

Escape Guard Interval

Appears only when the Escape Sequence is enabled. Enter the time interval in which the escape sequence must be entered fully.

Values (seconds)

1

Escape Sequence String

Only shown when the escape sequence is enabled. Enter the characters to be used for the escape sequence.

Values (characters)

+++

Data Baud Rate

The serial baud rate is the rate at which the modem is to communicate with the attached local asynchronous device.

Values (bps)

230400	9600
115200	7200
57600	4800
38400	3600
28800	2400
19200	1200
14400	600
	300

Data Format

This setting determines the format of the data on the serial port. The default is 8 data bits, No parity, and 1 Stop bit.

Values (selection)

8N1
8E1
8O1



Note: Most PCs do not readily support serial communications greater than 115200bps.

4.0 Configuration

IP Protocol Config

This setting determines which protocol the serial server will use to transmit serial port data over the pMDDL900 network.

The protocol selected in the IP Protocol Config field will determine which configuration options appear in the remainder of the RS232 Configuration Menu.

Values (selection)

TCP Client
 TCP Server
 TCP Client/Server
 UDP Point-to-Point
 PPP (Not supported on USB)

TCP Client: When TCP Client is selected and data is received on its serial port, the pMDDL900 takes the initiative to find and connect to a remote TCP server. The TCP session is terminated by this same unit when the data exchange session is completed and the connection timeout has expired. If a TCP connection cannot be established, the serial port data is discarded.

- **Remote Server Address**
 IP address of a TCP server which is ready to accept serial port data through a TCP connection. For example, this server may reside on a LAN network server.
 Default: **0.0.0.0**
- **Remote Server Port**
 A TCP port which the remote server listens to, awaiting a session connection request from the TCP Client. Once the session is established, the serial port data is communicated from the Client to the Server.
 Default: **20001**
- **Outgoing Connection Timeout**
 This parameter determines when the pMDDL900 will terminate the TCP connection if the connection is in an idle state (i.e. no data traffic on the serial port).
 Default: **60** (seconds)
- **Fast Recovery**
 Sets the TCP session parameters and buffers to be set such that TCP sessions recover faster in environments where the wireless link is weak/unstable. This is ideal for critical, near real time applications such as flight control data. Data is not buffered during outages.
 Default: **Disable**



UDP: User Datagram Protocol does not provide sequencing information for the packets sent nor does it establish a 'connection' ('handshaking') and is therefore most suited to communicating small packets of data.



TCP: Transmission Control Protocol in contrast to UDP does provide sequencing information and is connection-oriented; a more reliable protocol, particularly when large amounts of data are being communicated.

Requires more bandwidth than UDP.

TCP Server: In this mode, the pMDDL900 Series will not INITIATE a session, rather, it will wait for a Client to request a session of it (it's being the Server—it 'serves' a Client). The unit will 'listen' on a specific TCP port. If a session is established, data will flow from the Client to the Server, and, if present, from the Server to the Client. If a session is not established, both Client-side serial data, and Server-side serial data, if present, will be discarded.

- **Local Listening Port**
 The TCP port which the Server listens to. It allows a TCP connection to be created by a TCP Client to carry serial port data.
 Default: **20001**
- **Incoming Connection Timeout**
 Established when the TCP Server will terminate the TCP connection is the connection is in an idle state.
 Default: **300** (seconds)
- **Fast Recovery**
 Sets the TCP session parameters and buffers to be set such that TCP sessions recover faster in environments where the wireless link is weak/unstable. This is ideal for critical, near real time applications such as flight control data. Data is not buffered during outages.
 Default: **Disable**

4.0 Configuration

4.6.4 Diag > USB Tethering

The pMDDL900 can be Tethered to certain Android Mobile Devices to view a video stream from a remote video encoder. **This is a preliminary feature that has limited support at this time. Contact Microhard for more information.**



Image 4-6-4: Diag > USB Tethering

USB Tethering Mode

Enable USB Tethering. Enabling USB Tethering with open all WAN requests on the firewall to allow for proper operation

Values (selection)

ON/OFF

Forward Video

If enabled the pMDDL900 will allow video to be viewed from an attached android device from an remote video source.

Values (selection)

Enable / Disable

Encoder's Address

Enter the IP address of the external encoder of which the video source is located.

Values (IP Address)

(no default)

Encoder'sPort

Enter the port number for the video encoder's.


Values (IP Address)

554

4.0 Configuration

Add Users

Different users can be set up with customized access to the WebUI. Each menu or tab of the WebUI can be disabled on a per user basis as seen below.



The screenshot shows the 'Add Users' configuration page. The 'Account Name' field is set to 'admin'. Below it are 'Change Password' and 'Confirm Password' fields. The 'Add User' section includes 'Username', 'Password', and 'Confirm Password' fields. A 'System' dropdown menu is open, showing a list of system components with 'Disable' or 'Hide Submenu' options for each. The 'System' dropdown is currently set to 'Hide Submenu'.

Image 4-7-2: Access Control > Users

Username

Enter the desired username. Minimum of 5 character and maximum of 32 character. Changes will not take effect until the system has been restarted.

Values (characters)

(no default)
Min 5 characters
Max 32 characters

Password / Confirm Password

Passwords must be a minimum of 5 characters. The Password must be re-entered exactly in the Confirm Password box as well.

Values (characters)

(no default)
min 5 characters

4.0 Configuration

SNMP Trap Settings

SNMP Trap Settings	
SNMP Trap Status	Enable ▾
Trap Community Name	TrapUser
Trap Manage Host IP	0.0.0.0 0.0.0.0-Disable
Auth Failure Traps	Disable ▾
Trap Selection:	
RSSI	<input type="radio"/> Disable <input checked="" type="radio"/> Enable
RSSI Threshold	90 [30 - 120] (- dBm)
Resend Interval (seconds)	90 [0 - 65535] 0-Disable
WAN IP	<input type="radio"/> Disable <input checked="" type="radio"/> Enable

Image 4-7-4: Admin > SNMP Trap Settings

SNMP Trap Status

Enable or disable autonomous SNMP traps from the device.

Values (selection)

Disable / Enable

Trap Community Name

Effectively a plain-text password mechanism used to weakly authenticate SNMP queries. Being part of the community allows the SNMP agent to process SNMP traps.

Values (string)

TrapUser

Trap Manage Host IP

Enter the IP address of the SNMP host to which SNMP traps are sent from the device.

Values (IP Address)

0.0.0.0

Auth Failure Traps

Enable or Disable authentication requirements for outgoing configured SNMP event traps.

Values (selection)

Disable / Enable

RSSI

Enable or Disable RSSI traps. The threshold in which that traps are triggered can also be configured, as well as the frequency at which the traps are sent when the threshold has been crossed.

Values (selection)

Disable / Enable

90 (30-120) in -dBm

90 (0 - 65535 seconds, 0=disabled.)

4.0 Configuration

WAN IP

Enable or Disable WAN IP Traps. Device will send a trap any time the WAN IP has been changed. Generally used with dynamic IP addresses.

Values (selection)

Disable / Enable

4.0 Configuration

4.7.4 Admin > Logout

The logout function allows a user to end the current configuration session and prompt for a login screen.




Image 4-7-6: Admin > logout

5.0 AT Command Line Interface

5.3 Supported AT Commands

Basic AT Commands			
AT Command	Description	Syntax	Effect
AT	AT echo OK	AT <enter>	Immediate
ATE0	Disable echo	ATE0 <enter>	Immediate
ATE1	Enabled local echo	ATE1 <enter>	Immediate
ATH	Show a list of previously run commands	ATH <enter>	Immediate
ATL	Show a list of all available AT Commands	ATL <enter>	Immediate
AT&R	Read modem profile to editable profile. (Reserved)	AT&R <enter>	Immediate
AT&V	Read modem active profile	AT&V <enter>	Immediate
AT&W	Enable configuration changes that have been entered	AT&W <enter>	Immediate
ATA	Quit. Exits AT command session and returns to login prompt	ATA <enter>	Immediate
ATO	Quit. Exits AT command session and returns to login prompt	ATO <enter>	Immediate
Administrative AT Commands			
AT Command	Description	Syntax	Effect
AT+MADISS	Get/Set discovery service used by the modem	AT+MADISS [=<Mode>[,<Port>]] Mode: 0 - Disable 1 - Discoverable Port: 1 to 65535. Default is 20097	AT&W
AT+MASNMP	Get/Set SNMP service	AT+MASNMP [=<Mode>[,<ROCommunity>,<RWCommunity>,<Port>,<Version>]] <Mode>: 0 - Disable 1 - Enable <ROCommunity>: Read Only Community Name 1 to 32 characters <RWCommunity>: Read Write Community Name 1 to 32 characters <Port>: Listening Port 0 to 65535. Default is 161 <Version>: SNMP version 1 - Version 1 2 - Version 2 3 - Version 3 (Use AT+MASNMPV3 to set Authentication and Privacy parameters)	AT&W
AT+MASNMPV3	Get/Set SNMP Version 3	AT+MASNMPV3 =<UserName>,<RWLimit>,<AuthLevel>[,<Auth>,<AuthPassword>[,<Privacy>,<PrivacyPassword>]] <UserName> : V3 User Name 1 to 32 characters <RWLimit> : V3 User Read Write Limit 0 - Read Only 1 - Read Write <AuthLevel> : V3 User Authentication Level 0 - NoAuthNoPriv 1 - AuthNoPriv 2 - AuthPriv <Auth> : V3 Authentication Protocol 0 - MD5 1 - SHA <AuthPassword> : V3 Authentication Password 5 to 64 characters <Privacy> : V3 Privacy Protocol 0 - DES 1 - AES <PrivacyPassword>: V3 Privacy Password 5 to 64 characters Usage: NoAuthNoPriv : AT+MASNMPV3=<UserName>,<RWLimit>,0 AuthNoPriv : AT+MASNMPV3=<UserName>,<RWLimit>,1,<Auth>,<AuthPassword> AuthPriv : AT+MASNMPV3=<UserName>,<RWLimit>,2,<Auth>,<AuthPassword>,<Privacy>,<PrivacyPassword>	AT&W

5.0 AT Command Line Interface

Administrative AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MASNMPTRAP	Get/Set SNMP Trap	AT+MASNMPTRAP[=<Mode>[,<Name>,<IP>[,<AuthFailureTraps>]] <Mode>: 0 - Disable 1 - Enable <Name>: Trap Community Name. 1 to 32 characters <IP>: Trap Manage Host IP. Default 0.0.0.0 (Disable) <AuthFailureTraps>: 0 - Disable 1 - Enable Usage: AT+MASNMPTRAP AT+MASNMPTRAP=0 AT+MASNMPTRAP=1[,<Name>,<IP>[,<AuthFailureTraps>]]	AT&W
Serial Port AT Commands			
AT Command	Description	Syntax	Effect
AT+MCPS2	Get/Set Serial port	AT+MCPS2=<Mode> Parameters: COM2 Mode: 0 - Console 1 - Data	AT&W
AT+MCBR2	Get/Set Serial port baud rate	AT+MCBR2=<Baud Rate Type> Parameters: COM2 Baud Rate Type: 0 - 300 1 - 600 2 - 1200 3 - 2400 4 - 3600 5 - 4800 6 - 7200 7 - 9600 8 - 14400 9 - 19200 10 - 28800 11 - 38400 12 - 57600 13 - 115200 14 - 230400 15 - 460800 16 - 921600	AT&W
AT+MCDF2	Get/Set Serial port data format	AT+MCDF2=<Data Formate Type> Parameters: COM2 Data Formate Option: 0 - 8N1 2 - 8E1 3 - 8O1	AT&W
AT+MCDM2	Get/Set Serial port data mode	AT+MCDM2=<Data Mode Type> Parameters: COM2 Data Mode Option: 0 - Seamless 1 - Transparent	AT&W
AT+MCCT2	Get/Set Serial port character timeout	AT+MCCT2=<timeout> Parameters: COM2 timeout: 1 to 65535 in seconds	AT&W
AT+MCMP2	Get/Set Serial port maximum packet size	AT+MCMP2=<size> Parameters: COM2 maximum packet size: 1 to 2048	AT&W
AT+MCNCI2	Get/Set Serial port no-connection data intake	AT+MCNCI2=<Mode> Parameters: COM2 Mode Option: 0 - Disable 1 - Enable	AT&W
AT+MCMT2	Get/Set Serial port Modbus tcp configuration	AT+MCMT2=<Status> Parameters: COM2 Modbus Status: 0 - Disable 1 - Enable	AT&W

5.0 AT Command Line Interface

Serial Port AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MCIPM2	Get/Set Serial port IP protocol mode	AT+MCIPM2=<IP Protocol Config> Parameters: COM2 IP Protocol Config: 0 - TCP Client 1 - TCP Server 2 - TCP Client/Server 3 - UDP Point to Point 4 - UDP Point to Multipoint(P) 5 - UDP Point to Multipoint(MP) 8 - PPP	AT&W
AT+MCTC2	Get/Set Serial port tcp client configuration when IP protocol mode is TCP Client	AT+MCTC2=<Remote Server IP>,<Remote Server Port>,<Outgoing timeout> Parameters: COM2: Remote Server IP : valid IP address Remote Server Port : 1 to 65535 Outgoing timeout : 1 to 65535 in seconds	AT&W
AT+MCTS2	Get/Set Serial port tcp server configuration when IP protocol mode is TCP Server	AT+MCTS2=<Server Mode>,<Polling Timeout>,<Local Listening Port>,<Connection timeout> Parameters: Server Mode : 0 - Monitor; 1 - Polling Polling timeout : 1 to 65535 in seconds Local Listening Port : 1 to 65535 Connection timeout : 1 to 65535 in seconds	AT&W
AT+MCTCS2	Get/Set Serial port tcp client/server configuration when IP protocol mode is TCP Client/Server	AT+MCTCS2[=<Remote Server IP>,<Remote Server Port>,<Outgoing timeout>,<Server Mode>,<Polling Timeout>,<Local Listening Port>,<Incoming timeout>] Parameters: Remote Server IP : valid IP address Remote Server Port : 1 to 65535 Outgoing timeout : 1 to 65535 in seconds Server Mode : 0 - Monitor; 1 - Polling Polling timeout : 1 to 65535 in seconds Local Listening Port : 1 to 65535 Incoming timeout : 1 to 65535 in seconds	AT&W
AT+MCUPP2	Get/Set Serial port UDP point to point configuration when IP protocol mode is UDP point to point	AT+MCUPP2[=<Remote IP>,<Remote Port>,<Listening Port>,<UDP Timeout>] Parameters: Remote IP : valid IP address Remote Port : 1 to 65535 Listening Port : 1 to 65535 UDP Timeout : 1 to 65535 in seconds	AT&W
AT+MCP2	Get/Set Serial port PPP configuration when IP protocol mode is PPP	AT+MCP2[=<Mode>,<CCP negotiation>,<LCP Echo Failure Number>,<LCP Echo Interval>,<Local IP>,<Host IP>,<Idle Timeout>,<Expected String>,<Response String>] Parameters: COM2: Mode : 0 - Active; 1 - Passive CCP negotiation : 0 - Disable; 1 - Enable LCP Echo Failure Number : [0 .. 65535] LCP Echo Interval : [0 .. 65535] Local IP : Valid IP address Host IP : Valid IP address Idle Timeout : 1 to 65535 in seconds Expected String : (Optional) 0 - 63 characters Response String : (Optional) 0 - 63 characters	AT&W
AT+MCUPMP2	Get/Set Serial port UDP point to multipoint as point configuration when IP protocol mode is set to UDP point to multipoint (P)	AT+MCUPMP2[=<Multicast IP>,<Multicast Port>,<Listening Port>,<Time To Live>,<Multicast Interface> Parameters: COM2: Multicast IP : valid IP address Multicast Port : 1 to 65535 Listening Port : 1 to 65535 Time To Live : 1 to 255 in seconds Multicast Interface : 0 - default 1 - LAN	AT&W
AT+MCUPMM2	Get/Set Serial port UDP point to multipoint as MP configuration when IP protocol mode be set to UDP point to multipoint (MP)	AT+MCUPMM2[=<Remote IP>,<Remote Port>,<Multicast IP>,<Multicast Port>,<Multicast Interface>] Parameters: COM2: Remote IP : valid IP address Remote Port : 1 to 65535 Multicast IP : valid IP address Multicast Port : 1 to 65535 Multicast Interface : 0 - default 1 - LAN	AT&W
AT+MCESCP2	Get/Set Serial support escape sequence configuration	AT+MCESCP2[=<Escape Mode>,<Escape Guard Interval>,<Escape Sequence String>] Parameters: COM2: Escape Mode : 0 - Disabled; 1 - Enabled Escape Guard Interval : 1 to 10 seconds Escape Sequence String : 3 to 7 characters	AT&W

5.0 AT Command Line Interface

Firewall AT Commands			
AT Command	Description	Syntax	Effect
AT+MFGEN	Get/Set firewall general configuration	AT+MFGEN[=<Config>[,<Mode>]] Parameters Config : 0 - WAN Remote Management 1 - WAN Request 2 - LAN to WAN Access Control 3 - Anti-Spoof 4 - Packet Normalization Mode : 0 - Disable (Block) 1 - Enable (Allow)	AT&W
AT+MFDMZ	Get/Set firewall DMZ configuration	AT+MFDMZ[=<DMZ Source>[,<DMZ Mode>[,<DMZ Server IP>[,<Exception Port>]]] Parameters: DMZ Source : 0 - WAN DMZ Mode : 0 - Disable 1 - Enable DMZ Server IP : Valid IP address Exception Port : 0 - 65535	AT&W
AT+MFPORTFWD	Get/Set firewall Port Forwarding rule	AT+MFPORTFWD[=<Name>[,<Operation>[,<Source>[,<Internal IP>[,<Internal Port>[,<Protocol>[,<External Port>[,<SNAT>]]]]]]] Parameters: Name : Name of Port Forwarding rule, 1 - 64 characters Operation : ADD - Add a rule EDIT - Edit a rule DEL - Delete a rule Source : 0 - WAN 1 - USB Internal IP : Valid IP address Internal Port : Valid port number, 1 - 65535 Protocol : 0 - TCP 1 - UDP 2 - TCPUDP External Port : Valid port number, 1 - 65535 Source NAT : 0 - No; 1 - Yes Usage: AT+MFPORTFWD AT+MFPORTFWD=<Name> AT+MFPORTFWD=<Name>,DEL AT+MFPORTFWD=<Name>,ADD,<Source>,<Internal IP>,<Internal Port>,<Protocol>,<External Port>,<SNAT> AT+MFPORTFWD=<Name>,EDIT,<Source>,<Internal IP>,<Internal Port>,<Protocol>,<External Port>,<SNAT>	AT&W
AT+MFMAC	Get/Set firewall MAC list	AT+MFMAC[=<Name>[,<Operation>[,<Action>[,<Mac Address>]]] Parameters: Name : Name of firewall MAC list name, 1 - 64 characters Operation : ADD - Add a firewall MAC list EDIT - Edit a firewall MAC list DEL - Delete a firewall MAC list Action : 0 - Accept 1 - Drop 2 - Reject MAC Address : Valid MAC address Usage: AT+MFMAC AT+MFMAC=<Name> AT+MFMAC=<Name>,DEL AT+MFMAC=<Name>,ADD,<Action>,<Mac Address> AT+MFMAC=<Name>,EDIT,<Action>,<Mac Address>	AT&W
AT+MFIP	Get/SET firewall IP list	AT+MFIP[=<Name>[,<Operation>[,<Action>[,<Source>[,<IP Address>[,<Prefix>]]]]] Parameters: Name : Name of firewall IP list name, 1 - 64 characters Operation : ADD - Add a firewall IP list EDIT - Edit a firewall IP list DEL - Delete a firewall IP list Action : 0 - Accept 1 - Drop 2 - Reject Source : 0 - LAN 1 - Independent LAN 2 - WAN 3 - USB Source IP : Valid IP address Prefix : 0 ~ 32 (default) - single IP address Usage: AT+MFIP AT+MFIP=<Name> AT+MFIP=<Name>,DEL AT+MFIP=<Name>,ADD,<Action>,<Source>,<IP Address>[,<Prefix>] AT+MFIP=<Name>,EDIT,<Action>,<Source>,<IP Address>[,<Prefix>]	AT&W

5.0 AT Command Line Interface

Firewall AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MFRULE	Get/Set firewall rule	AT+MFRULE [=<Name>[,<Operation>[,<Action>,<Source>,<Src IP Format>,<Src IP From/Subnet>,<Src IP To/Prefix>,<Destination>,<Dest IP Format>,<Dest IP From/Subnet>,<Dest IP To/Prefix>,<Dest Port>,<Protocol>]]] Parameters: Name : Name of firewall rule name, 1 - 64 characters Operation : ADD - Add a firewall rule EDIT - Edit a firewall rule DEL - Delete a firewall rule Action : 0 - Accept 1 - Drop 2 - Reject Source : 0 - LAN 1 - Independent LAN 2 - WAN 3 - USB 4 - None IP Format : 0 - IP Range 1 - Subnet / Prefix IP From/Subnet: Valid IP address. 0 - Set to blank IP To/Prefix : Valid IP address. 0 - Set to blank; or 0 ~ 32 for Prefix Destination : 0 - LAN 1 - Independent LAN 2 - WAN 3 - USB 4 - None IP Format : 0 - IP Range 1 - Subnet / Prefix IP From/Subnet: Valid IP address. 0 - Set to blank IP To/Prefix : Valid IP address. 0 - Set to blank; or 0 ~ 32 for Prefix Port/Range : Port 0 ~ 65535 or Port range specified as 100:200 format Protocol : 0 - TCP 1 - UDP 2 - TCPUDP 3 - ICMP	AT&W
AT+MFRST	Reset to default firewall	AT+MFRST <enter>	Immediate
Network AT Commands			
AT Command	Description	Syntax	Effect
AT+MNLAN	Show/Add/Edit/Delete the network LAN interface	AT+MNLAN AT+MNLAN =<LAN Name> AT+MNLAN =<LAN Name>,DEL AT+MNLAN =<LAN Name>,ADD/EDIT,<Protocol>[,<IP>,<Netmask>[,<Gateway>]] Where <Protocol>=0 AT+MNLAN =<LAN Name>,ADD/EDIT,<Protocol> Where <Protocol>=1 or 3 AT+MNLAN =<LAN Name>,EDIT,<Protocol>[,<IP>,<Netmask>] Where <Protocol>=2 and <LAN Name>="lan" Parameters: LAN Name : Name of Network LAN interface. System built-in one is "lan" Operation : ADD - Add a new LAN interface EDIT - Edit an existing LAN interface DEL - Delete an existing LAN interface Protocol : 0 - Static IP 1 - DHCP with LAN alias disabled 2 - DHCP with LAN alias enabled, only for "lan" 3 - None. Not for "lan" IP Address : Valid IP address Netmask : Valid netmask Gateway : Valid IP address. 0 - Reset	AT&W
AT+MNLANDHCP	Get/Set LAN DHCP server on LAN interface	AT+MNLANDHCP =<LAN Name>[,<Mode>[,<Start IP>,<Limit>,<Lease Time>[,<Alt. Gateway>,<Pre. DNS>,<Alt. DNS>,<WINS/NBNS Servers>,<WINS/NBT Node>]]] Parameters: LAN Name : Name of Network LAN interface Mode : 0 - Disable DHCP Server 1 - Enable DHCP Server Start IP : The starting address DHCP assignable IP Addresses Limit : The maximum number of IP addresses. min=1 max=16777214 Lease Time : The DHCP lease time in minutes. 2~2147483647 minutes. 0 means'infinity' Alt. Gateway : Alternate Gateway for DHCP assigned devices if the default gateway is not to be used Pre. DNS : Preferred DNS server address to be assigned to DHCP devices Alt. DNS : Alternate DNS server address to be assigned to DHCP devices WINS/NBNS Server : WINS/NBNS Servers WINS/NBT Node : WINS/NBT Node Type 0 - none 1 - b-node 2 - p-node 3 - m-node 4 - h-node	AT&W

5.0 AT Command Line Interface

Network AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MNLANSTP	Get/Set the network LAN interface: Spanning Tree (STP)	AT+MNLANSTP=<LAN Name>[,<STP>] Parameters: LAN Name : Name of Network LAN interface Spanning Tree : 0 - Off 1 - On	AT&W
AT+MNLANIGMP	Get/Set the network LAN interface: IGMP Snooping	AT+MNLANIGMP=<LAN Name>[,<IGMP Snooping>] Parameters: LAN Name : Name of Network LAN interface IGMP Snooping : 0 - Off 1 - On	AT&W
AT+MNLANDR	Get/Set the network LAN interface: Default Route	AT+MNLANDR=<LAN Name>[,<Default Route>] Parameters: LAN Name : Name of Network LAN interface Default Route : 0 - No 1 - Yes	AT&W
AT+MNLANDNS	Get/Set the network LAN interface: DNS	AT+MNLANDNS=<LAN Name>[,<Mode>[,<Primary DNS>,<Secondary DNS>]] Usage: AT+MNLANDNS=<LAN Name> AT+MNLANDNS=<LAN Name>,<Mode> Where <Mode>=0 AT+MNLANDNS=<LAN Name>,<Mode>[,<Primary DNS>,<Secondary DNS>] Where <Mode>=1 Parameters: LAN Name : Name of Network LAN interface Mode : 0 - Auto 1 - Manual Primary DNS : Valid IP Address or 0 (Reset) Secondary DNS : Valid IP address or 0 (Reset)	AT&W
AT+MNWAN	Get/Set the network WAN interface	AT+MNWAN[=<Mode>[,<Protocol>[,<IP>,<Netmask>[,<Gateway>]]]] Usage: AT+MNWAN AT+MNWAN=<Mode>,<Protocol>,<IP>,<Netmask>[,<Gateway>] Where <Mode>=0 and <Protocol>=0 AT+MNWAN=<Mode>,<Protocol>,<IP>,<Netmask> Where <Mode>=2 and <Protocol>=0 AT+MNWAN=<Mode>,<Protocol> Where <Mode>=0/2 and <Protocol>=1 AT+MNWAN=<Mode>,<Protocol> Where <Mode>=2 and <Protocol>=2 AT+MNWAN=<Mode> Where <Mode>=1 Parameters: Mode : 0 - Independent WAN 1 - Bridge with LAN Port 2 - Independent LAN Protocol: 0 - Static IP 1 - DHCP 2 - None IP : Valid IP address Netmask : Valid netmask Gateway : Valid IP address. 0 - Reset	AT&W
AT+MNWANDR	Get/Set the network WAN interface: Default Route	AT+MNWANDR[=<Default Route>] Parameters: Default Route : 0 - No 1 - Yes	AT&W
AT+MNWANDNS	Get/Set DNS Server when WAN port works as Independent WAN	AT+MNWANDNS[=<Mode>[,<Primary DNS>,<Secondary DNS>]] Usage: AT+MNWANDNS AT+MNWANDNS=<Mode> Where <Mode>=0 AT+MNWANDNS=<Mode>[,<Primary DNS>,<Secondary DNS>] Where <Mode>=1 Parameters: Mode : 0 - Auto 1 - Manual Primary DNS : Valid IP Address or 0 (Reset) Secondary DNS : Valid IP address or 0 (Reset)	AT&W
AT+MNWANLANDHCP	Get/Set LAN DHCP server when the WAN port is set as Independent LAN	AT+MNWANLANDHCP[=<Mode>[,<Start IP>,<Limit>,<Lease Time>[,<Alt.Gateway>,<Pre.DNS>,<Alt.DNS>]]] Usage: AT+MNWANLANDHCP AT+MNWANLANDHCP=<Mode> Where <Mode>=0 AT+MNWANLANDHCP=<Mode>,<Start IP>,<Limit>,<Lease Time>[,<Alt.Gateway>,<Pre.DNS>,<Alt.DNS>] Where <Mode>=1 Parameters: Mode : 0 - Disable DHCP Server 1 - Enable DHCP Server Start IP : The starting address DHCP assignable IP Addresses Limit : The maximum number of IP addresses. min=1 max=16777214 Lease Time : The DHCP lease time in minutes. 2~2147483647 minutes. 0 means 'infinity' Alt. Gateway : Alternate Gateway for DHCP assigned devices if the default gateway is not to be used Pre. DNS : Preferred DNS server address to be assigned to DHCP devices Alt. DNS : Alternate DNS server address to be assigned to DHCP devices	AT&W

5.0 AT Command Line Interface

Network AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MNIPMAC	Show/Add/Delete/Release/ReleaseAll the MAC-IP address binding	AT+MNIPMAC[=<Operation>[,<Name>,<IP Address>,<MAC Address>]] Usage: AT+MNIPMAC AT+MNIPMAC=SHOW,<Name> AT+MNIPMAC=ADD,<Name>,<IP Address>,<MAC Address> AT+MNIPMAC=DEL,<Name> AT+MNIPMAC=RELEASE,<Name> AT+MNIPMAC=RELEASEALL Parameters: Operation : SHOW - Show the details of the MAC-IP address binding ADD - Add a new MAC-IP address binding DEL - Delete an existing MAC-IP address binding RELEASE - Release the active DHCP lease RELEASEALL - Release all active DHCP leases Name : Name of the MAC-IP binding, 1-64 characters IP Address : Valid IP address MAC Address: The physical MAC address of the device or interface	AT&W
AT+MNEMAC	Get the MAC address of the local Ethernet interface	AT+MNEMAC <enter> Sample Output: +MNEMAC: "00:0F:92:02:F9:0F" OK	Immediate
AT+MNPORT	Get/Set the Ethernet port configuration	AT+MNPORT[=<Ethernet Port>[,<Mode>,<Auto Negotiation>,<Speed>,<Duplex>]] Parameters: Ethernet Port : 0 - WAN 1 - LAN Mode : 0 - Auto 1 - Manual Auto-Negotiation : 0 - Off 1 - On Speed : 0 - 10 Mbit/s 1 - 100 Mbit/s Duplex : 0 - Full 1 - Half	AT&W
AT+MNSTATUS	Get the network status	AT+MNSTATUS <enter> Sample Output: LAN Port Status General Status IP Address : 192.168.168.1 Connection Type : static Subnet Mask : 255.255.255.0 MAC Address : 00:0F:92:02:F9:0F Traffic Status Receive bytes : 262.633KB Receive packets : 3345 Transmit bytes : 168.370KB Transmit packets : 2229 WAN Port Status General Status IP Address : N/A Connection Type : dhcp Subnet Mask : N/A MAC Address : 00:0F:92:03:F9:0F Traffic Status Receive bytes : 0B Receive packets : 0 Transmit bytes : 0B Transmit packets : 0 Default Gateway : 192.168.168.1 DNS Server(s) : None Kernel IP routing table Destination Gateway Subnet Mask Flags Metric Ref Use Iface 0.0.0.0 192.168.168.1 0.0.0.0 UG 0 0 0 br-lan 192.168.168.0 0.0.0.0 255.255.255.0 U 0 0 0 br-lan	Immediate

5.0 AT Command Line Interface

Network AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MNUUSB	Show/Edit the network USB Interface	AT+MNUUSB[=<Mode>[,<Protocol>[,<IP>,<Netmask>[,<Gateway>]]]] Usage: AT+MNUUSB AT+MNUUSB=<Mode>,<Protocol>,<IP>,<Netmask>[,<Gateway>] Where <Mode>=0 and <Protocol>=0 AT+MNUUSB=<Mode>,<Protocol> Where <Mode>=0 and <Protocol>=1 AT+MNUUSB=<Mode> Where <Mode>=1/2 Parameters: Mode : 0 - Independent LAN 1 - Bridge with LAN Port 2 - Bridge with WAN Port Protocol: 0 - Static IP 1 - DHCP IP : Valid IP address Netmask : Valid netmask Gateway : Valid IP address. 0 - Reset	AT&W
AT+MNUBDHCP	Get/Set USB DHCP server on USB interface	AT+MNUBDHCP[=<Mode>[,<Start IP>,<Limit>,<Lease Time>[,<Alt. Gateway>,<Pre. DNS>,<Alt. DNS>]]] Parameters: Mode : 0 - Disable DHCP Server 1 - Enable DHCP Server Start IP : The starting address DHCP assignable IP Addresses Limit : The maximum number of IP addresses Lease Time : The DHCP lease time in minutes. 2~2147483647 minutes. 0 means 'infinity' Alt. Gateway : Alternate Gateway for DHCP assigned devices if the default gateway is not to be used Pre. DNS : Preferred DNS server address to be assigned to DHCP devices Alt. DNS : Alternate DNS server address to be assigned to DHCP devices	AT&W
AT+MNUBDR	Get/Set the network USB interface: Default Route	AT+MNUBDR[=<Default Route>] Parameters: Default Route : 0 - No 1 - Yes	AT&W
AT+MNUBDNS	Get/Set the network USB interface: DNS	AT+MNUBDNS[=<Mode>[,<Primary DNS>,<Secondary DNS>]]] Usage: AT+MNUBDNS AT+MNUBDNS=<Mode> Where <Mode>=0 AT+MNUBDNS=<Mode>[,<Primary DNS>,<Secondary DNS>] Where <Mode>=1 Parameters: Mode : 0 - Auto 1 - Manual Primary DNS : Valid IP Address or 0 (Reset) Secondary DNS : Valid IP address or 0 (Reset)	AT&W

5.0 AT Command Line Interface

System AT Commands			
AT Command	Description	Syntax	Effect
AT+MSCNTO	Get/Set the console timeout	AT+MSCNTO=<Timeout_s> Parameter: <Timeout_s> : 30 to 65535 in seconds, 0-Disable	AT&W
AT+MSPWD	Set password	AT+MSPWD=<New Password>,<Confirm Password> Parameters: <New Password> : 5-64 characters except space <Confirm Password> : Same as <New Password>	AT&W
AT+MSGMI	Get manufacturers identification	AT+MSGMI <enter> Sample Output: +MSGMI: 2017-2018 Microhard.	Immediate
AT+MSSYSI	Get system summary information	AT+MSSYSI <enter> Sample Output: +MSSYSI: LAN Port: MAC : 00:0F:92:04:1A:E0 IP : 192.168.168.1 MASK : 255.255.255.0 System: Device : UserDevice Product : pMDDL900 Image : pMDDL Hardware : Rev A Software : v1.4.0 build 1013-1 Copyright : 2017-2018 Microhard Systems Inc. System Time : Fri Oct 12 14:59:50 2018	Immediate
AT+MSGMR	Get modem Record information	AT+MSGMR <enter> Sample Output: +MSGMR: Hardware Version : Rev A Software Version : v1.4.0 build 1013-1 Copyright : 2017-2018 Microhard Systems Inc. System Time : Fri Oct 12 15:00:55 2018	Immediate
AT+MSIMG	Get the image status for both active and inactive images	AT+MSIMG <enter> Active Version : v1.4.0-r1013-1 Active Build Time : 2018-10-12 14:08:55 Inactive Version : v1.4.0-r1013-1 Inactive Build Time : 2018-09-20 14:26:19	Immediate
AT+MSMNAME	Get/Set modem Name setting	AT+MSMNAME=<Modem_Name> Parameter: <Modem_Name> : 1 - 64 characters. Must be alphanumeric or dots(.), or dashes(-) or underscores(_)	AT&W
AT+MSRTF	Reset the modem to the factory default settings from non-volatile (NV) memory	AT+MSRTF=<Action> Parameter: <Action>: 0 - Pre-set action 1 - Confirm action	AT&W
AT+MSREB	Reboot the modem	AT+MSREB <enter> Sample Output: Rebooting...	Immediate
AT+MSNTP	Get/Set NTP server	AT+MSNTP[=<Mode>[,<Server>,<Port>,<Client Interval>]] Parameters: <Mode> : 0 - Local Time; 1 - NTP <Server> : Valid IP Address or Name <Port> : 1 to 65535. Default is 123 <Client Interval> : 15 to 65535 in seconds, 0-Disable	AT&W
AT+MSSYSLOG	Get/Set Syslog server settings	AT+MSSYSLOG[=<Server>[,<Port>]] Parameters: <Server> : Valid IP Address or Name. 0.0.0.0 - Disable. 1 to 256 characters <Port> : 1 to 65535. Default is 514	AT&W
AT+MSSERVICE	Get/Set service status and port	AT+MSSERVICE[=<Service>[,<Mode>[,<Port>]]] Parameters: <Service> : 0 - FTP 1 - Telnet 2 - SSH <Mode> : 0 - Disable 1 - Enable <Port> : 0 to 65535. For Telnet (23 by default) and SSH (22 by default) only	AT&W
AT+MSWEBUI	Get/Set Web UI protocol and port	AT+MSWEBUI[=<Mode>[,<HTTP Port>[,<HTTPS Port>]]] Parameters: <Mode> : 0 - HTTP/HTTPS 1 - HTTP 2 - HTTPS 3 - Disable <HTTP Port> : 2 to 65534. 80 by default <HTTPS Port> : 2 to 65534. 443 by default	AT&W
AT+MSTR	Get Traffic status on interfaces	AT+MSTR[=<Interfaces>] <Interfaces> : 0 - WIFI 1 - Serial COM 2 - WAN 3 - LAN AT+MSTR=0 <enter> WIFI RX packets: 408 RX bytes : 57.301KB TX packets: 0 TX bytes : 0B	Immediate

5.0 AT Command Line Interface

Serial USB - AT Commands			
AT Command	Description	Syntax	Effect
AT+MUSBPS	Get/Set Serial USB Port Status *Only available when valid USB to Serial Adapter is connected*	AT+MUSBPS[=<USB Serial>[,<Mode>]] Parameters: USB Serial : 0 - GS0 Mode : 0 - Idle 1 - Data	AT&W
AT+MUSBBR	Get/Set Serial USB port baud rate *Only available when valid USB to Serial Adapter is connected*	AT+MUSBR[=<USB Serial>[,<Baud Rate>]] Parameters: USB Serial: 0 - GS0 Baud Rate : 0 - 300 1 - 600 2 - 1200 3 - 2400 4 - 3600 5 - 4800 6 - 7200 7 - 9600 8 - 14400 9 - 19200 10 - 28800 11 - 38400 12 - 57600 13 - 115200 14 - 230400 15 - 460800 16 - 921600	AT&W
AT+MUSBDF	Get/Set Serial USB data format *Only available when valid USB to Serial Adapter is connected*	AT+MUSBDF[=<USB Serial>[,<Data Format>]] Parameters: USB Serial: 0 - GS0 Data Format: 0 - 8N1 1 - 8E1 2 - 8O1	AT&W
AT+MUSBFC	Get/Set Serial USB port flow control	AT+MUSBFC[=<USB Serial>[,<Flow Control>]] Parameters: USB Serial: 0 - GS0 Flow Control: 0 - none 1 - RTS/CTS	AT&W
AT+MUSBDM	Get/Set Serial USB port data mode	AT+MUSBDM[=<USB Serial>[,<Data Mode>]] Parameters: USB Serial: 0 - GS0 Data Mode: 0 - Seamless 1 - Transparent	AT&W
AT+MUSBCT	Get/Set USB port character timeout	AT+MUSBCT[=<USB Serial>[,<Timeout>]] Parameters: USB Serial: 0 - GS0 Timeout: 1 to 65535 in seconds	AT&W
AT+MUSBMPS	Get/Set Serial USB port maximum packet size	AT+MUSBMPS[=<USB Serial>[,<Maximum Packet Size>]] Parameters: USB Serial : 0 - GS0 Maximum Packet Size : 1 to 2048	AT&W
AT+MUSBNCDI	Get/Set Serial USB port no-connection data intake	AT+MUSBNCDI[=<USB Serial>[,<No-Connection Data>]] Parameters: USB Serial: 0 - GS0 No-Connection Data: 0 - Disable 1 - Enable	AT&W
AT+MUSBMTC	Get/Set Serial USB port modbus tcp configuration	AT+MUSBMTC[=<USB Serial>[,<Modbus Status>]] Parameters: USB Serial: 0 - GS0 Modbus Status: 0 - Disable 1 - Enable	AT&W
AT+MUSBIPM	Get/Set Serial USB port IP protocol mode	AT+MUSBIPM[=<USB Serial>[,<IP Protocol Config>]] Parameters: USB Serial : 0 - GS0 IP Protocol Config : 0 - TCP Client 1 - TCP Server 2 - TCP Client/Server 3 - UDP Point to Point 4 - UDP Point to Multipoint(P) 5 - UDP Point to Multipoint(MP)	AT&W

5.0 AT Command Line Interface

Serial USB - AT Commands			
AT Command	Description	Syntax	Effect
AT+MUSBTC	Get/Set Serial USB port tcp client configuration when IP protocol mode is TCP Client	AT+MUSBTC [=<USB Serial>[,<Remote Server IP>,<Remote Server Port>,<Outgoing timeout>[,<Fast Recovery>]]] Parameters: USB Serial : 0 - GS0 Remote Server IP : valid IP address Remote Server Port : 1 to 65535 Outgoing timeout : 1 to 65535 in seconds Fast Recovery : 0 - Disable; 1 - Enable	AT&W
AT+MUSBTS	Get/Set Serial USB port tcp server configuration when IP protocol mode is TCP Server	AT+MUSBTS [=<USB Serial>[,<Server Mode>,<Polling Timeout>,<Local Listening Port>,<Connection timeout>[,<Fast Recovery>]]] Parameters: USB Serial : 0 - GS0 Server Mode : 0 - Monitor; 1 - Polling Polling timeout : 1 to 65535 in seconds Local Listening Port : 1 to 65535 Connection timeout : 1 to 65535 in seconds Fast Recovery : 0 - Disable; 1 - Enable	AT&W
AT+MUSBTCS	Get/Set Serial USB port tcp client/server configuration when IP protocol mode is TCP Client/Server	AT+MUSBTCS [=<USB Serial>[,<Remote Server IP>,<Remote Server Port>,<Outgoing timeout>,<Server Mode>,<Polling Timeout>,<Local Listener Port>,<Incoming timeout>[,<Fast Recovery>]]] Parameters: USB Serial : 0 - GS0 Remote Server IP : valid IP address Remote Server Port : 1 to 65535 Outgoing timeout : 1 to 65535 in seconds Server Mode : 0 - Monitor; 1 - Polling Polling timeout : 1 to 65535 in seconds Local Listening Port : 1 to 65535 Incoming timeout : 1 to 65535 in seconds Fast Recovery : 0 - Disable; 1 - Enable	AT&W
AT+MUSBUPP	Get/Set Serial USB port UDP point to point configuration when IP protocol mode is UDP point to point	AT+MUSBUPP [=<USB Serial>[,<Remote IP>,<Remote Port>,<Listening Port>,<UDP Timeout>]] Parameters: USB Serial : 0 - GS0 Remote IP : valid IP address Remote Port : 1 to 65535 Listening Port : 1 to 65535 UDP Timeout : 1 to 65535 in seconds	AT&W
AT+MUSBUPMP	Get/Set Serial USB port UDP point to multipoint as point configuration when IP protocol mode be set to UDP point to multipoint (P)	AT+MUSBUPMP [=<USB Serial>[,<Multicast IP>,<Multicast Port>,<Listening Port>,<Time To Live>,<Multicast Interface>]] Parameters: USB Serial: 0 - GS0 Multicast IP: valid IP address Multicast Port: 1 to 65535 Listening Port: 1 to 65535 Time To Live: 1 to 255 in seconds Multicast Interface: 0 - default 1 - LAN	AT&W
AT+MUSBUPMM	Get/Set Serial USB port UDP point to multipoint as MP configuration when IP protocol mode be set to UDP point to multipoint (MP)	AT+MUSBUPMM [=<USB Serial>[,<Remote IP>,<Remote Port>,<Multicast IP>,<Multicast Port>,<Multicast Interface>]] Parameters: USB Serial: 0 - GS0 Remote IP: valid IP address Remote Port: 1 to 65535 Multicast IP: valid IP address Multicast Port: 1 to 65535 Multicast Interface: 0 - default 1 - LAN	AT&W

5.0 AT Command Line Interface

Wireless (Radio) AT Commands			
AT Command	Description	Syntax	Effect
AT+MWRADIO	Get/Set radio status, On or Off	AT+MWRADIO[=<Radio>] <Radio> 0 - Off 1 - On	AT&W
AT+MWDISTANCE	Get/Set radio Wireless Distance	AT+MWDISTANCE[=<Distance>] <Distance> 1 - 200000 in meter	AT&W
AT+MWTXPOWER	Get/Set radio Tx power	AT+MWTXPOWER[=<Tx Power>] <Tx Power> 7 - 7 dbm 8 - 8 dbm 9 - 9 dbm 10 - 10 dbm 11 - 11 dbm 12 - 12 dbm 13 - 13 dbm 14 - 14 dbm 15 - 15 dbm 16 - 16 dbm 17 - 17 dbm 18 - 18 dbm 19 - 19 dbm 20 - 20 dbm 21 - 21 dbm 22 - 22 dbm 23 - 23 dbm 24 - 24 dbm 25 - 25 dbm 26 - 26 dbm 27 - 27 dbm 28 - 28 dbm 29 - 29 dbm 30 - 30 dbm	AT&W
AT+MWBAND	Get/Set radio channel bandwidth	AT+MWBAND[=<Channel Bandwidth>,<Symbol Rate>] Available radio channel bandwidth for pMDDL mode 0 - 8 MHz 1 - 4 MHz	AT&W
AT+MWMIMO	Get/Set radio MIMO	AT+MWMIMO[=<MIMO>] <MIMO> : 0 - Off 1 - On	AT&W
AT+MWMCASTRT	Get/Set radio Multicast Rate	AT+MWMCASTRT[=<Multicast Rate>] <Multicast Rate> : 0 - QPSK FEC 1/2 1 - QPSK FEC 3/4 2 - 16-QAM FEC 1/2 3 - 16-QAM FEC 3/4 4 - 64-QAM FEC 2/3	AT&W

5.0 AT Command Line Interface

Wireless (Radio) AT Commands (Continued)			
AT Command	Description	Syntax	Effect
AT+MWMODE	Get/Set radio mode	AT+MWMODE [=<Virtual Interface Mode>] <Virtual Interface Mode> : 0 - Master 1 - Slave 2 - Repeater	AT&W
AT+MWRATE	Get/Set radio TX Rate	AT+MWRATE [=<Virtual Interface TX Rate>] <Virtual Interface TX Rate> : 0 - auto (Recommended) 1 - 64-QAM 5/6 FEC 2 - 64-QAM 3/4 FEC 3 - 64-QAM 2/3 FEC 4 - 16-QAM 3/4 FEC 5 - 16-QAM 1/2 FEC 6 - QPSK FEC 3/4 7 - QPSK FEC 1/2	AT&W
AT+MWEXTADDR	Get/Set radio extended addressing	AT+MWEXTADDR [=<Extended Addressing>] <Extended Addressing> : 0 - Off 1 - On	AT&W
AT+MWNWID	Get/Set radio Network ID	AT+MWNWID [=<Network ID>] <Network ID> Radio Virtual Interface Network ID: 1-64 characters	AT&W
AT+MWVENC	Get/Set radio Encryption Type & Key	AT+MWVENC [=<Encryption Type>[,<Key>]] <Encryption Type> Radio Virtual Interface Encryption Type: 0 - Disabled 1 - AES-128 <Key>: Min 8 characters, Max 64 characters	AT&W
AT+MWRESYNC	RF Re-Sync from the slave side	AT+MWRESYNC <enter>	Immediate
AT+MWSTATUS	Get the status of RF	AT+MWSTATUS <enter> Sample Output: General Status MAC Address : 00:0F:92:A1:A2:A3 Operation Mode : Master Network ID : pMDDL Bandwidth : 8 MHz Frequency : 5745 MHz Tx Power : 20 dBm Encryption Type : AES-128 Traffic Status Receive Bytes : 0B Receive Packets : 0 Transmit Bytes : 55,766KB Transmit Packets : 473	Immediate
AT+MWSNR	Get the value of SNR (Slave)	AT+MWSNR <enter> Sample Output: 43 OK	Immediate
AT+MWNOISEFLOOR	Get the value of Noise Floor (Slave)	AT+MWNOISEFLOOR <enter> Sample Output: -99 OK	Immediate
AT+MWSQTHRESH	Get/Set Squelch threshold	AT+MWSQTHRESH [=<Squelch Threshold>] Squelch Threshold : -1 to -128 (-1 = Turn off the threshold)	AT&W
AT+MWRSSI	Get radio RSSI	AT+MWRSSI <enter> Sample Output: 00:0F:92:FA:59:F9 -74 dBm	Immediate

6.0 Installation

Distance (km)	Master Height (m)	Remote Height (m)	Path Loss (dB)
5	15	2.5	116.5
5	30	2.5	110.9
8	15	2.5	124.1
8	15	5	117.7
8	15	10	105
16	15	2.5	135.3
16	15	5	128.9
16	15	10	116.2
16	30	10	109.6
16	30	5	122.4
16	30	2.5	128.8

Table 6-1: Path Loss



To satisfy FCC radio frequency (RF) exposure requirements for mobile transmitting devices, a separation distance of 23cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operation at less than this distance is not recommended. The antenna used for this transmitter must not be collocated in conjunction with any other antenna or transmitter.



Never work on an antenna system when there is lightning in the area.

6.2 Installation of Antenna System Components

The installation, removal, or maintenance of any antenna system components must be undertaken only by qualified and experienced personnel.

6.2.1 Antennas

The two most common types of antenna are the omnidirectional ('omni') and directional (Yagi).

An **omni** typically has 3-6dBi gain and spreads its energy in all directions (hence the name 'omnidirectional'). The 'pattern' of the energy field is in the shape of a donut, with the antenna mounted vertically at the centre. This vertical-mounted antenna produces a signal which is vertically 'polarized'.

A **Yagi** has a more focused antenna pattern, which results in greater gain: commonly, 6-12dBi. The pattern of a Yagi is in the shape of a large raindrop in the direction in which the antenna is pointed. If the elements of the Yagi are perpendicular to the ground (most common orientation) the radiated signal will be vertically polarized; if parallel to the ground, the polarization is horizontal.

The network topology, application, and path calculation are all taken into consideration when selecting the various antenna types to be used in a radio network deployment.

Appendix A: Serial Interface

Module (DCE)	Signal	Host (e.g. PC) (DTE)	
1	DCD →	IN	Arrows denote the direction that signals are asserted (e.g., DCD originates at the DCE, informing the DTE that a carrier is present).
2	RX →	IN	The interface conforms to standard RS-232 signals, so direct connection to a host PC (for example) is accommodated.
3	← TX	OUT	
4	← DTR	OUT	
5	SG		
6	DSR →	IN	
7	← RTS	OUT	The signals in the asynchronous serial interface are described below:
8	CTS →	IN	

DCD *Data Carrier Detect* - Output from Module - When asserted (TTL low), DCD informs the DTE that a communications link has been established with another device.

RX *Receive Data* - Output from Module - Signals transferred from the pMDDL900 are received by the DTE via RX.

TX *Transmit Data* - Input to Module - Signals are transmitted from the DTE via TX to the pMDDL900.

DTR *Data Terminal Ready* - Input to Module - Asserted (TTL low) by the DTE to inform the module that it is alive and ready for communications.

SG *Signal Ground* - Provides a ground reference for all signals transmitted by both DTE and DCE.

DSR *Data Set Ready* - Output from Module - Asserted (TTL low) by the DCE to inform the DTE that it is alive and ready for communications. DSR is the module's equivalent of the DTR signal.

RTS *Request to Send* - Input to Module - A "handshaking" signal which is asserted by the DTE (TTL low) when it is ready. When hardware handshaking is used, the RTS signal indicates to the DCE that the host can receive data.

CTS *Clear to Send* - Output from Module - A "handshaking" signal which is asserted by the DCE (TTL low) when it has enabled communications and transmission from the DTE can commence. When hardware handshaking is used, the CTS signal indicates to the host that the DCE can receive data.

Notes: It is typical to refer to RX and TX from the perspective of the DTE. This should be kept in mind when looking at signals relative to the module (DCE); the module transmits data on the RX line, and receives on TX.

"DCE" and "module" are often synonymous since a module is typically a DCE device. "DTE" is, in most applications, a device such as a host PC.

Appendix C: Sample Interface Schematic
